

OMNERA[®] 500A

Auto-Positioning Digital Radiographic System

Installation and Service Manual



Technical Publication: 1000-095-072-EN Rev. 1.1

Canon

CANON MEDICAL SYSTEMS USA, INC.

Disclaimer

The standard warranty is void if the product has been intentionally modified, or damaged by accident, abuse or misuse. Additionally, this warranty is void if untrained personnel service the OMNERA® 500A equipment.

Lost profits, downtime, goodwill, damage to or replacement of property, and any costs of repairing the OMNERA® 500A resulting from a breach of warranty are not the responsibility of Canon Medical Systems

Specifications are subject to change without notice. Not responsible for typographical errors.

Notices

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Canon Medical Systems

Note: Photos and drawings used in this guide may be slightly different from the actual product.



Dispose of electronic equipment in accordance with local, state, and federal regulations.

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND SUCH INFORMATION
MAY NOT BE DISCLOSED TO OTHERS FOR ANY PURPOSE NOR USED FOR
MANUFACTURING PURPOSES WITHOUT WRITTEN PERMISSION FROM CANON
MEDICAL SYSTEMS.

Trademarks

OMNERA® is a registered trademarks of Canon Medical
Systems

All third-party brand names, product names, or logos
appearing in this manual are the trademarks or registered
trademarks of their respective owners.

Canon® is a registered trademark of Canon, Inc. and may
also be a registered trademark or a trademark in other
countries.

| Revision history | Rev | Date |
|------------------|-----|---------|
| New Release | 1.1 | 2020-09 |

| | | |
|----------|---|-----------|
| 1 | Introduction | 1 |
| 1.1 | Document information..... | 1 |
| 1.1.1 | <i>System documentation</i> | 1 |
| 1.1.2 | <i>System documentation</i> | 1 |
| 1.1.3 | <i>Stylistic conventions</i> | 1 |
| 1.1.4 | <i>Document producer</i> | 1 |
| 1.1.5 | <i>Copyright</i> | 1 |
| 1.1.6 | <i>Text emphasis</i> | 2 |
| 1.2 | Identification Labels..... | 3 |
| 1.3 | System description..... | 6 |
| 1.3.1 | <i>General</i> | 6 |
| 1.3.2 | <i>Intended Use</i> | 6 |
| 1.3.3 | <i>Configuration</i> | 6 |
| 1.3.3.1 | Table models and designs..... | 6 |
| 1.3.3.2 | Wall stand models and designs..... | 6 |
| 1.3.4 | <i>System Overview</i> | 7 |
| 1.3.5 | <i>Overhead Tube Crane, overview</i> | 8 |
| 1.3.6 | <i>Table overview</i> | 8 |
| 1.3.7 | <i>Wall stand Overview</i> | 9 |
| 2 | Safety | 11 |
| 2.1 | Compliance..... | 11 |
| 2.2 | Precautions, safety..... | 12 |
| 2.3 | Qualifications of Personnel..... | 15 |
| 2.3.1 | <i>Operating Personnel</i> | 15 |
| 2.3.2 | <i>Service Personnel</i> | 15 |
| 2.4 | Service and Maintenance..... | 16 |
| 2.4.1 | <i>Operation, Installation and Repair</i> | 16 |
| 2.5 | Installation and repair..... | 18 |
| 2.6 | Safety and Warning Symbols..... | 19 |
| 2.7 | Safety and Warning Labels on the Equipment..... | 20 |
| 2.8 | Applied Parts..... | 21 |
| 2.9 | Emergency stop..... | 22 |
| 2.10 | Radiation and X-ray tube..... | 23 |
| 2.10.1 | <i>Radiation protection</i> | 24 |
| 2.10.1.1 | Protection against primary radiation (patient)..... | 24 |
| 2.10.1.2 | Protection against secondary radiation..... | 24 |
| 2.10.1.3 | Protection against residual radiation..... | 28 |
| 2.11 | Mechanical safety..... | 29 |
| 2.11.1 | <i>General</i> | 29 |
| 2.11.1.1 | General..... | 29 |
| 2.11.2 | <i>Overhead tube crane</i> | 30 |
| 2.11.3 | <i>Cabinet</i> | 32 |
| 2.11.4 | <i>Table</i> | 33 |
| 2.11.4.1 | Safety issues when positioning a patient..... | 34 |
| 2.11.4.2 | Working area, table..... | 37 |
| 2.11.5 | <i>Wall stand</i> | 39 |
| 2.11.5.1 | Safety issues when position patient..... | 39 |
| 2.11.5.2 | Working area, wall stand..... | 39 |
| 2.11.5.3 | Standard version..... | 39 |
| 2.11.5.4 | Motorized wall stand..... | 40 |
| 2.12 | Safety functions..... | 41 |
| 2.12.1 | <i>System</i> | 41 |
| 2.12.1.1 | Collision detection..... | 41 |
| 2.12.1.2 | Malfunctioning Node..... | 42 |
| 2.12.1.3 | Dead man's grip..... | 42 |

Contents

| | |
|---|----|
| 2.12.1.4 Watchdog | 42 |
| 2.12.1.5 PID controller | 43 |
| 2.12.1.6 Two column table | 44 |
| 2.12.1.7 Wall stand | 46 |
| 2.13 Safety zone, definition..... | 47 |
| 2.13.1 Table Safety zone | 47 |
| 2.13.2 Two column table | 47 |
| 2.14 Electromagnetic compatibility (EMC)..... | 48 |

3 Theory of operation 55

| | |
|---|-----|
| 3.1 User interface description | 55 |
| 3.2 Basic concepts..... | 56 |
| 3.3 Overhead tube crane | 57 |
| 3.3.1 General user interface..... | 57 |
| 3.3.2 System Display Overview | 57 |
| 3.3.3 Automatic Collimator Control | 58 |
| 3.3.3.1 Automatic collimator | 59 |
| 3.3.3.2 Display user interface | 62 |
| 3.3.3.3 Patient Information | 63 |
| 3.3.3.4 Position Information..... | 63 |
| 3.3.3.5 Adjustment of Generator Parameters (kV, mA, ms, mAs, Density)..... | 64 |
| 3.3.3.6 Settings | 64 |
| 3.3.3.7 System Mode | 71 |
| 3.3.3.8 Hospital manual | 76 |
| 3.3.3.9 Selection of Technique Mode..... | 77 |
| 3.3.3.10 Patient Size..... | 79 |
| 3.3.3.11 Collimator Centering | 80 |
| 3.3.3.12 Servo State Mode..... | 81 |
| 3.3.3.13 Grid Status | 82 |
| 3.3.3.14 Light indication | 84 |
| 3.3.4 Information field | 85 |
| 3.3.4.1 Detector information, table | 85 |
| 3.3.4.2 Detector information, wall stand | 86 |
| 3.3.4.3 Grid status information | 87 |
| 3.4 Motorized movements | 89 |
| 3.5 Perform examination | 90 |
| 3.5.1 Select patient..... | 90 |
| 3.5.2 Start examination..... | 91 |
| 3.5.3 Position the system..... | 92 |
| 3.5.4 Adjust position and collimator for chosen examination and patient | 92 |
| 3.5.5 Exposure..... | 93 |
| 3.5.6 Review image..... | 95 |
| 3.5.7 Change work space | 95 |
| 3.5.8 Basic exposure error handling..... | 97 |
| 3.6 Mechanical design..... | 98 |
| 3.6.1 Table..... | 98 |
| 3.6.2 Wall stand | 98 |
| 3.7 Table | 99 |
| 3.7.1 Controls | 99 |
| 3.7.2 Motorized Imaging Unit Movement | 100 |
| 3.7.2.1 Synchronization Function | 100 |
| 3.7.3 Motorized imaging unit movement..... | 100 |
| 3.7.3.1 Synchronization function | 100 |
| 3.7.3.2 Synchronization function | 100 |
| 3.8 Wall stand..... | 102 |

Contents

| | |
|---|------------|
| 3.8.1 Motorized movement..... | 102 |
| 3.9 Remote control (option) | 105 |
| 4 Installation..... | 107 |
| 4.1 Installation of Subsystem 0072 | 107 |
| 4.1.1 Software installation | 107 |
| 4.1.2 Unloading..... | 107 |
| 4.1.3 General..... | 107 |
| 4.1.4 Precautions | 107 |
| 4.1.5 Installation Preparations | 109 |
| 4.1.5.1 Tools Required | 109 |
| 4.1.6 Cable marking | 109 |
| 4.1.7 Shipping/receiving | 110 |
| 4.1.7.1 Receiving..... | 110 |
| 4.1.7.2 Storage precautions | 110 |
| 4.1.7.3 Return authorizations..... | 110 |
| 4.1.8 Mechanical installation of OTC..... | 111 |
| 4.1.8.1 Installation Rails (Unistrut) | 111 |
| 4.1.8.2 Traverse | 114 |
| 4.1.8.3 Tooth Belt | 115 |
| 4.1.8.4 Ceiling Rails Y..... | 116 |
| 4.1.8.5 Traverse Rail X | 124 |
| 4.1.8.6 Electrical Plate Y and Drive Unit Y..... | 125 |
| 4.1.8.7 Ceiling Wagon..... | 128 |
| 4.1.8.8 Cable support..... | 131 |
| 4.1.8.9 Cable channel | 132 |
| 4.1.8.10 Wall attachment for cable (option)..... | 139 |
| 4.1.8.11 X-ray Tube | 139 |
| 4.1.9 Mechanical installation of system cabinet..... | 140 |
| 4.1.9.1 Remove covers, cabinet..... | 142 |
| 4.1.10 Electrical installation..... | 142 |
| 4.1.10.1 General | 142 |
| 4.1.10.2 Cable path | 143 |
| 4.1.10.3 Electrical Installation of OTC..... | 144 |
| 4.1.11 Mechanical Installation of wall stand | 146 |
| 4.1.11.1 Orientation of wall stand | 146 |
| 4.1.11.2 Unload wall stand | 147 |
| 4.1.12 Electrical Installation of wall stand | 150 |
| 4.1.12.1 Connect wall stand | 150 |
| 4.1.13 Mechanical installation of table..... | 153 |
| 4.1.13.1 Orientation of the table | 153 |
| 4.1.13.2 Unload table..... | 154 |
| 4.1.14 Electrical Installation of table | 156 |
| 4.1.14.1 Connect table | 156 |
| 4.1.15 Connect options..... | 159 |
| 4.1.15.1 Foot control, wireless (option)..... | 159 |
| 4.1.15.2 Room lights..... | 161 |
| 4.1.15.3 Installation of wireless access point (option) | 162 |
| 4.1.15.4 Electrical installation image system | 163 |
| 4.1.15.5 Electrical installation of mini console | 168 |
| 4.1.15.6 External Servo Button | 169 |
| 4.2 Measure protective earth | 170 |
| 4.2.1 Measure insulation between hospital protective earth and system | 170 |
| 4.2.2 Protective earth subsystem..... | 171 |
| 4.3 Electrical building installation | 174 |
| 4.3.1 Power ratings and line requirements..... | 174 |

Contents

| | |
|--|-----|
| 4.3.2 Tap configuration 380 VAC / 400 VAC..... | 176 |
| 4.3.3 Tap configuration 480 VAC..... | 181 |
| 4.4 Electrical installation mains..... | 185 |
| 4.5 Collimator..... | 186 |
| 4.6 Start-up procedure..... | 187 |
| 4.6.1 Start-up procedure..... | 187 |
| 4.6.1.1 Check voltage to the subsystem..... | 187 |
| 4.6.2 Check alignment, OTC..... | 189 |
| 4.6.2.1 Adjust Alpha Index..... | 192 |
| 4.6.2.2 Adjust Beta Index..... | 192 |
| 4.6.2.3 Adjust Index Magnet..... | 193 |
| 4.6.2.4 Adjust the Mechanical End Stop, Beta..... | 194 |
| 4.6.2.5 Alignment of OTC, X- and Y-direction..... | 196 |
| 4.6.3 Alignment of wall stand..... | 197 |
| 4.6.4 Wall stand attachment..... | 197 |
| 4.6.4.1 Wall stand Insulation and Attachment to Floor..... | 197 |
| 4.6.5 Horizontal alignment of table..... | 199 |
| 4.6.6 Table attachment..... | 200 |
| 4.6.6.1 Insulation..... | 200 |
| 4.6.7 Measure insulation between hospital protective earth and system..... | 202 |
| 4.6.8 Calibration OTC..... | 203 |
| 4.6.8.1 Definitions..... | 203 |
| 4.6.9 Password..... | 206 |
| 4.6.10 System setup..... | 206 |
| 4.6.10.1 Hardware key..... | 209 |
| 4.6.10.2 Motorized movements..... | 211 |
| 4.6.10.3 Beta resolution..... | 221 |
| 4.6.11 Calibration of bucky-axis on table..... | 223 |
| 4.6.12 Calibration of wall stand..... | 225 |
| 4.6.12.1 Patient protection end stop..... | 226 |
| 4.6.12.2 Calibration of wall stand tilt..... | 227 |
| 4.6.13 Calibration of table..... | 228 |
| 4.6.13.1 Table safety zone..... | 231 |
| 4.6.13.2 Transport interval zone..... | 232 |
| 4.6.13.3 Focal spot to detector holder offset..... | 234 |
| 4.6.13.4 Table top offset..... | 234 |
| 4.6.13.5 Movement short-cut zones..... | 235 |
| 4.6.13.6 Wall stand movement short-cut zone..... | 238 |
| 4.6.13.7 Beta offset..... | 240 |
| 4.6.13.8 WallFlexible parameters..... | 241 |
| 4.6.13.9 Detector parameters..... | 244 |
| 4.6.13.10 Calibration of guard function (Z-axis)..... | 245 |
| 4.6.13.11 Calibration service software for table..... | 247 |
| 4.6.13.12 Save parameters (settings) table..... | 258 |
| 4.6.14 Calibration of collimator..... | 259 |
| 4.6.14.1 Detector X/Y orientation..... | 259 |
| 4.6.15 Calibration of tube..... | 260 |
| 4.6.16 Installation of AEC..... | 260 |
| 4.6.17 Gain adjustment of AID (ICX-3922) AEC..... | 261 |
| 4.6.17.1 Wall stand..... | 261 |
| 4.6.17.2 Table..... | 262 |
| 4.6.18 Calibration of auto positions..... | 262 |
| 4.6.19 Tomo/pendulum parameters..... | 263 |
| 4.6.20 Tests..... | 265 |
| 4.6.20.1 System test..... | 265 |
| 4.6.20.2 Balancing the wall stand detector movement..... | 266 |
| 4.6.20.3 Emergency button test..... | 268 |

Contents

| | |
|---|------------|
| 4.6.20.4 Indication light test | 268 |
| 4.6.20.5 Generator software file | 268 |
| 4.6.21 <i>Back-up parameters</i> | 269 |
| 4.6.21.1 Save OTC parameters | 269 |
| 4.6.22 <i>Collimator light and X-ray field alignment</i> | 270 |
| 4.6.23 <i>Collimator Adjustments</i> | 271 |
| 4.6.23.1 Accuracy of the Light field indication to X-ray field | 271 |
| 4.6.23.2 Verification of the Light field indication to X-ray field | 271 |
| 4.6.23.3 Field light size fine adjustment | 271 |
| 4.6.24 <i>Calibration of tube</i> | 272 |
| 4.6.25 <i>AEC calibration</i> | 273 |
| 4.6.25.1 Measurement of system attenuation factor | 273 |
| 4.6.25.2 Check of AEC chamber field versus image system AEC fields | 273 |
| 4.6.25.3 Adjustment of balance between the three fields | 274 |
| 4.6.25.4 Fine tuning of KV compensation | 275 |
| 4.7 Image system | 278 |
| 4.8 Configuring the protocol settings in Protocol Editor | 279 |
| 4.9 DAP test | 280 |
| 4.10 Install table top | 282 |
| 4.11 Automatic collimator test | 283 |
| 4.12 Display test | 284 |
| 4.13 System communication | 285 |
| 4.14 Image quality test | 286 |
| 4.15 Send installation report to Arcoma service | 287 |
| 5 Setup..... | 289 |
| 5.1 Computer network settings | 289 |
| 5.1.1 <i>Canon software IP settings</i> | 292 |
| 5.1.2 <i>Generator settings</i> | 294 |
| 5.2 Static protocol setup | 298 |
| 5.3 Stitching protocol setup (option) | 301 |
| 6 Maintenance | 309 |
| 6.1 General | 309 |
| 6.2 Generator | 311 |
| 6.3 Imaging system | 312 |
| 6.4 Detector | 313 |
| 6.5 OTC | 314 |
| 6.6 Two column table | 320 |
| 6.6.1 <i>Y-brakes, adjustment</i> | 321 |
| 6.6.1.1 Low brake force or brake release problems | 322 |
| 6.6.1.2 High brake force | 322 |
| 6.6.2 <i>X-brakes, adjustment</i> | 323 |
| 6.6.2.1 Low brake force or brake release problems | 323 |
| 6.6.2.2 High brake force | 323 |
| 6.7 Wall stand | 324 |
| 6.7.1 <i>Tiltable wagon</i> | 325 |
| 6.8 System | 326 |
| 6.8.1 <i>Check the positioning index of the OTC</i> | 327 |
| 6.9 Battery replacement | 330 |
| 6.9.1 <i>Foot control</i> | 330 |
| 6.9.2 <i>Remote Control</i> | 331 |
| 6.9.3 <i>Generator Control Board</i> | 331 |
| 6.10 Software version / update | 332 |

Contents

| | |
|---|------------|
| 6.10.1 The software and its update location point..... | 332 |
| 7 Diagnostic..... | 333 |
| 7.1 General | 333 |
| 7.1.1 Description | 333 |
| 7.1.2 Error handling two column table | 333 |
| 7.1.3 System message two column table | 335 |
| 7.1.3.1 General | 335 |
| 7.1.3.2 Description | 335 |
| 7.1.3.3 All Nodes | 336 |
| 7.1.3.4 Motor Nodes | 337 |
| 7.1.3.5 Master Node | 351 |
| 7.1.4 CB800-board | 353 |
| 7.1.4.1 Fault handling | 353 |
| 8 Electrical drawings | 361 |
| 8.1 System block diagram | 362 |
| 8.1.1 System..... | 362 |
| 8.1.1.1 1000 System C | 363 |
| 8.1.2 Image system | 365 |
| 8.1.2.1 Image system C | 365 |
| 8.1.2.2 CXDI TS and WS 401 or 701 Wireless | 367 |
| 8.1.2.3 CXDI TS and WS 401 or 701C Wireless WS with charging | 369 |
| 8.1.2.4 CXDI TS 401 or 701C Wireless and WS 401 compact | 371 |
| 8.1.2.5 CXDI TS 401 or 701 CXDI TS 401 with charging and WS 401 or 701C wireless | 373 |
| 8.1.2.6 CXDI TS and WS 401_701 wireless with charging | 375 |
| 8.1.2.7 CXDI TS 401 701 wireless with charging and WS 401 compact | 377 |
| 8.1.2.8 CXDI TS 401 compact and WS 401 or 701C Wireless | 379 |
| 8.1.2.9 CXDI TS 401 compact and WS 401 Wireless with charging | 381 |
| 8.1.2.10 CXDI TS 401 or 701C Wireless with charging and WS 401 or 701C Wireless | 383 |
| 8.1.2.11 CXDI TS and WS 401 compact | 385 |
| 8.1.2.12 CXDI TS and WS 401 compact 2 x free | 387 |
| 8.1.2.13 CXDI TS 401C and WS 410 or 710C Wireless | 389 |
| 8.1.2.14 CXDI TS 401C and WS 410 or 710C Wireless with charging | 391 |
| 8.1.2.15 CXDI TS 410 or 710C Wireless and WS 401 compact | 393 |
| 8.1.2.16 CXDI TS and WS 410 or 710C Wireless | 395 |
| 8.1.2.17 CXDI TS and WS 410 or 710C Wireless, WS with charging | 397 |
| 8.1.2.18 CXDI TS 410 or 710C Wireless with charging and WS 401 compact | 399 |
| 8.1.2.19 CXDI TS 410 or 710C Wireless with charging and WS 410 or 710C Wireless | 401 |
| 8.1.2.20 CXDI TS and WS 410 or 710C Wireless with charging | 403 |
| 8.1.3 Subsystem | 405 |
| 8.1.3.1 System 0073 2 | 405 |
| 8.1.4 Overhead tube crane | 407 |
| 8.1.4.1 Overhead tube crane | 407 |
| 8.1.5 System cabinet | 409 |
| 8.1.5.1 System cabinet | 409 |
| 8.1.6 Two column table | 411 |
| 8.1.6.1 Table 2 columns | 411 |
| 8.1.7 Wall stand | 413 |

Contents

| | |
|---|-----|
| 8.1.7.1 Wall stand 0073..... | 413 |
| 8.1.7.2 Detector holder 14x17, top, center | 415 |
| 8.1.7.3 Detector holder 14x17 or 17x17 | 417 |
| 8.1.7.4 Detector holder 17x17 | 419 |
| 8.1.7.5 Detector holder 17x17_fix | 421 |
| 8.2 Unit block diagram..... | 423 |
| 8.2.1 Image system | 423 |
| 8.2.1.1 Image system C | 423 |
| 8.2.2 Two column table | 425 |
| 8.2.2.1 Bluetooth foot switch..... | 425 |
| 8.2.2.2 Detector holder 14x17..... | 427 |
| 8.2.2.3 Detector holder 17x17..... | 429 |
| 8.2.2.4 Detector holder 17x17 Fix | 431 |
| 8.2.2.5 Detector holder 14x17 17x17, table..... | 433 |
| 8.2.2.6 Detector movement | 435 |
| 8.2.2.7 Emergency stop | 437 |
| 8.2.2.8 Power..... | 439 |
| 8.2.2.9 Table top brakes | 441 |
| 8.2.2.10 Z Movement..... | 443 |
| 8.2.3 Wall stand | 445 |
| 8.2.3.1 Bluetooth foot switch..... | 445 |
| 8.2.3.2 CAN | 447 |
| 8.2.3.3 Detector holder 14x17, top, center | 449 |
| 8.2.3.4 Detector holder 14x17 or 17x17, top, center | 451 |
| 8.2.3.5 Detector holder 17x17 Fix | 453 |
| 8.2.3.6 Detector holder 17x17 | 455 |
| 8.2.3.7 Emergency stop | 457 |
| 8.2.3.8 Handlebar..... | 459 |
| 8.2.3.9 Power..... | 461 |
| 8.2.3.10 Tilt drive | 463 |
| 8.2.3.11 WS tilt, ind, top, bottom, R or L..... | 465 |
| 8.2.3.12 Z-movement..... | 467 |
| 8.2.4 OTC..... | 469 |
| 8.2.4.1 Wiring diagram: OTC — WRD-0073-CS 2_p1 | 469 |
| 8.2.4.2 Wiring diagram: OTC — WRD-0073-CS 2_p2..... | 471 |
| 8.2.4.3 Wiring diagram: OTC — WRD-0073-CS 2_p3..... | 473 |
| 8.2.4.4 Wiring diagram: OTC — WRD-0073-CS 2_p4..... | 475 |
| 8.2.4.5 Wiring diagram: OTC — WRD-0073-CS 2_p5..... | 477 |
| 8.2.4.6 Wiring diagram: OTC — WRD-0073-CS 2_p6..... | 479 |
| 8.2.4.7 Wiring diagram: OTC — WRD-0073-CS 2_p7..... | 481 |
| 8.2.4.8 Wiring diagram: OTC — WRD-0073-CS 2_p8..... | 483 |
| 8.2.4.9 Wiring diagram: Z Column — WRD_0070-003-250..... | 485 |
| 8.2.4.10 Wiring diagram: Drive unit X-Y — WRD-0070-099-223..... | 487 |
| 8.2.4.11 Collimator control, AL02 | 489 |
| 8.2.4.12 Collimator control OP30 | 491 |
| 8.2.4.13 Remote control | 493 |
| 8.2.4.14 DAP meter | 495 |
| 8.2.4.15 X-ray tube | 497 |
| 8.2.4.16 Display | 499 |
| 8.2.5 System cabinet..... | 501 |
| 8.2.5.1 AEC chamber..... | 501 |
| 8.2.5.2 Collimator control | 503 |
| 8.2.5.3 Generator system..... | 505 |
| 8.2.5.4 Power 380V, 400V or 480V 3 phase, page 1 | 507 |
| 8.2.5.5 Power 380V, 400V or 480V 3 phase, page 2 | 509 |

9 Fuses511

Contents

| | |
|---|------------|
| 9.1 OTC | 511 |
| 9.2 System cabinet | 512 |
| 9.3 Two column table | 513 |
| 9.4 Wall stand Z motorized | 514 |
| 10 Technical specification..... | 515 |
| 10.1 Electrical Characteristics | 515 |
| 10.2 Environmental Requirements | 516 |
| 10.3 Ceiling suspended X-ray tube support | 517 |
| 10.3.1 General | 517 |
| 10.3.2 Configuration | 517 |
| 10.3.3 Weight | 517 |
| 10.3.4 Electrical Characteristics | 517 |
| 10.3.5 Classification | 517 |
| 10.3.6 Speed | 518 |
| 10.4 Cabinet | 519 |
| 10.4.1 Dimensions | 519 |
| 10.4.2 Weight | 519 |
| 10.5 Table | 520 |
| 10.5.1 Column | 520 |
| 10.5.2 Table Top | 520 |
| 10.5.3 Weight | 520 |
| 10.5.4 Electrical Characteristics | 520 |
| 10.5.5 Attenuation Equivalent | 520 |
| 10.6 Wall stand | 521 |
| 10.6.1 Attenuation equivalent | 521 |
| 10.6.2 Weight | 521 |
| 10.6.3 Speed | 521 |
| 11 Options | 523 |
| 12 Accessories | 525 |
| 12.1 General | 525 |
| 12.1.1 Table | 525 |
| 12.1.2 Wallstand | 526 |
| 12.1.3 Detector | 526 |
| 12.1.4 Grid | 526 |
| 13 Spare parts | 527 |
| 13.1 General | 527 |
| 14 Waste disposal | 529 |
| 15 Appendix A | 531 |
| 15.1 Glossary | 531 |
| 16 Appendix B | 535 |
| 16.1 Maintenance checklists | 535 |
| 16.1.1 Annual maintenance checklist | 535 |
| 16.1.1.1 System | 535 |
| 16.1.1.2 OTC | 535 |
| 16.1.1.3 Two column table | 537 |

Contents

| | |
|-------------------------------------|------------|
| 16.1.1.4 Wall stand | 538 |
| 16.1.1.5 System part 2 | 539 |
| 16.1.1.6 Remark..... | 540 |
| 17 Installation report | 541 |
| 17.1 Attention | 541 |

Contents

1 Introduction

1.1 Document information

- It is important to keep this document for the life of the equipment, and pass the document on to any subsequent holder or user of the equipment.
- The original version of this manual is written in English.
- Training is provided by or via Arcoma. Training material consists of the Operation manual and the Installation and service manual.

1.1.1 System documentation

The following documentation is available for the system:

- 1000 System installation and service manual
- 1000 System operation manual
- 0072 Subsystem planning guide
- Image system service manual
- Image system user manual
- Detector user's manual

1.1.2 System documentation

The following documentation is available for the system:

- Installation and service manual
- Operation manual
- Planning guide

1.1.3 Stylistic conventions

All warning label texts are shown in *italic* style in this manual.

All references are shown in *italic* style in this manual.

1.1.4 Document producer

This document has been produced by:

Arcoma AB
Annavägen 1
S-352 46 VÄXJÖ,
Sweden

www.arcoma.se

1.1.5 Copyright

Copyright © 2020. — All rights reserved

The reproduction, transmission or use of this document or its content is not permitted without express written authority. Offered will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved.

Introduction

Document information

1.1.6 Text emphasis



WARNING!

All texts labelled with “WARNING” call attention to potential risk to health or life.

CAUTION!

All texts labelled with “CAUTION” contain information about dangerous situations and measures to avoid risk.

Note!

All texts labelled with “NOTE” contain additional information regarding the work step, and is provided for a better understanding or as a warning about unnecessary and avoidable difficulties.

1.2 Identification Labels

The figure shows the location of the identification labels on the equipment.










Fig. 1-1

Introduction

Identification Labels





1.3 System description

1.3.1 General

Arcoma Precision includes:

- Overhead tube crane (OTC) with x-ray tube and collimator
- Table
- Wall stand
- System cabinet with a high voltage generator
- Image Acquisition system
- Flat panel detectors

1.3.2 Intended Use

The system is a stationary X-ray system intended for obtaining radiographic images of various portions of the human body in a clinical environment.

The system is not intended for mammography.

1.3.3 Configuration

The basic system consists of system Cabinet (including generator), Image acquisition system, Flat panel detectors, and Overhead tube crane. The basic system can be equipped with one of the following three configurations:

- Table and Wall Stand
- Wall Stand
- Table

1.3.3.1 Table models and designs

The table is prepared for different types of detectors, fixed or portable in different sizes.

1.3.3.2 Wall stand models and designs

The wall stand has different options:

- Tilttable detector holder wagon.
- Motorized Z movement
- Prepared for different types of detectors; fixed or portable in different sizes.
- The detector holder for the portable detector is available for either left-hand or right-hand loading.

1.3.4 System Overview




Fig. 1-2 System Overview

1. Overhead tube crane, OTC
2. Table
3. Detector holder
4. Wall stand
5. System cabinet
6. Computer and monitor

Introduction

System description

1.3.5 Overhead Tube Crane, overview




Fig. 1-3 Overhead Tube Crane, OTC

- | | |
|----------------------|---------------------|
| 1. Ceiling rail (Y) | 5. X-ray tube |
| 2. Traverse rail (X) | 6. Manoeuvre handle |
| 3. Ceiling wagon | 7. Collimator |
| 4. Column (Z) | 8. Display |

1.3.6 Table overview




Fig. 1-4 Table overview

- | |
|---------------|
| 1. Foot plate |
| 2. Column |
| 3. Table top |

- | | |
|---|--|
| 4. Table hand control (X/Y/Z, Ceiling tube pendulum movement) | 8. Foot control table top (X/Y/Z) (Option) |
| 5. Detector holder | 9. Collimator hand control (option) |
| 6. Brake release for detector holder | 10. Head end |
| 7. XY foot control strip type (Option) | 11. Foot end |

1.3.7 Wall stand Overview




Fig. 1-5 Wall stand overview, T = Tilt

- | | |
|--------------------|---|
| 1. Lateral armrest | 5. Hand control (Collimator and movement adjustments) |
| 2. Detector holder | |
| 3. Column | |
| 4. Foot plate | |

2 Safety

2.1 Compliance

External equipment intended for connection to signal input, signal output or other connectors shall comply with the relevant product standard e.g. IEC 60950–1 for IT equipment and the IEC 60601–series for medical electrical equipment.

In addition, all such combinations – systems – shall comply with the safety requirements stated in the collateral standard IEC 60601–1–1 or the general standard IEC 60601–1, edition 3.1, clause 16. Any equipment not complying with the leakage current requirements in IEC 60601–1 shall be kept outside the patient environment i.e. at least 1.5 m from the patient support.

Any person who connects external equipment to signal input, signal output or other connectors has formed a system and is therefore responsible for the system to comply with the requirements.

If in doubt, contact qualified medical technician or your local representative.

If external equipment is connected, an isolation device is needed to isolate the equipment located outside the patient environment from the equipment located inside the patient environment. In particular such a separation device is required when a network connection is made. The requirements on the separation device is defined in IEC 60601–1–1 and in IEC 60601–1, edition 3.1, clause 16.

Safety

Precautions, safety

2.2 Precautions, safety



WARNING!

No modification of this equipment is allowed.



WARNING!

The equipment is intended for use in radiographic examinations under the guidance of trained health care professionals. Operating personnel must be familiar with the equipment and the instructions given in this manual before using the equipment.



WARNING!

Safety devices must not be removed or modified. Any modification or removal will immediately impair the safety.



WARNING!

All motorized movements shall be supervised by trained personnel.



WARNING!

Do not use non-medical electrical devices in the X-ray room.

CAUTION!

Do not use any flammable or explosive gases near the device.

CAUTION!

Before using this device, read the manuals supplied with the devices in order to understand functions, operation, and performance. Follow the manuals for correct procedures.

CAUTION!

Before using the device again after a longer period of time, check the correct operation of the system.

CAUTION!

The system is provided with air intakes and outlets to prevent the equipment from overheating. Do not block these air intakes and outlets.

CAUTION!

Handle loose objects with care, so they will not fall down on patient or at the surrounding articles.

CAUTION!

When using this device, be sure to observe the installation environment requirements regarding temperature, humidity, and power rating conditions, or restriction of use near a device generating strong magnetic or electromagnetic waves.

CAUTION!

The installation environment and location, device configuration, network, power supply, and other conditions are optimized for this device. If you want to change any condition, contact your nearest service representative. Otherwise, the functions and performance of this device may be impaired.

CAUTION!

No objects shall be positioned within the working area. If necessary, they must be removable.

CAUTION!

Do not put liquids, or foreign objects such as pins and clips into the equipment.

Otherwise, fires, electric shocks, or malfunctions may result.

Turn OFF the power source breaker immediately and unplug the equipment if any foreign objects have fallen into the equipment. Contact your nearest service representative.

Never disassemble the device.

CAUTION!

The display must not be used for diagnostic purposes.

CAUTION!

If cracks appear on the display, immediately stop using it. Never use it when the display is damaged.

Safety

Precautions, safety

CAUTION!

When references are made to a sub-manual, always make sure to read the Safety Chapter, Warnings and Cautions carefully in both the System Manual and the sub-manuals.

Note!

Radio interference standard Federal Communications Commission (FCC) Part 15 Class B applies to this equipment.

Note!

The equipment may only be used as intended.

2.3 Qualifications of Personnel

CAUTION! _____

Federal law restricts this device to be sold by or on the order of a physician.

CAUTION! _____

This equipment is intended for use in radiographic examinations under the guidance of trained health care professionals.

2.3.1 Operating Personnel

Before using the product it is required that the operating personnel is thoroughly familiar with the product and its operating instructions, in particular:

- Safety
- Function and Safety Checks

2.3.2 Service Personnel



WARNING! _____

Before working with service and maintenance, always turn off the power and make sure to lock it, so it cannot be mistakenly turned on.

The equipment shall be serviced only by service technicians who:

- are completely familiar with the System
- have read and understood *Operation Manual* and *Installation and Service Manual*.
- know how to remove power to the unit in case of an emergency
- are trained in the use of equipment and procedures of this type.

Failure to follow the instructions given in this Manual could result in serious injury to the service person, patient and operator.

Note! _____

It is the responsibility of the owner to ensure that the technicians have the correct training and knowledge to perform service and maintenance.

Note! _____

It is the responsibility of the owner to ensure that the product is operated only by trained radiologist, service technicians or product specialists.

2.4 Service and Maintenance



WARNING!

When service or maintenance is to be performed the service technician shall lock the equipment from all energy sources.

Be aware of that there are live parts even some time after having switched off the mains.

Due to remaining energy, always wait at least 15 seconds before working on the System.



WARNING!

There will still be live parts even when the System is switched off.



WARNING!

The equipment must not be serviced or maintained while in use with the patient.

- *Risk for personal injury.*

Service and maintenance shall only be performed when no patient is present.

The equipment must be checked according to the to maintain reliability and serviceability, and to ensure the safety of the patients, the operator and third parties.

If national rules or regulations specify more frequent checks and/or maintenance, such regulations must be observed.

2.4.1 Operation, Installation and Repair



WARNING!

To avoid risk of electric shock, this equipment must only be connected to a supply mains with protective earth.



WARNING!

Only medical-approved products shall be in the X-ray room.

Risk of electric shock to patient or user.

- *No non-medical electrical devices shall be used in the x-ray room.*
 - *Note that the monitor and the PC for the Image system, are none-medical approved products.*
-



WARNING!

The Manufacturer can not assume responsibility for the safety features or for the reliability and performance of the equipment, if:

- *installation of equipment is not carried out by persons authorized by the Manufacturer.*
 - *components are not replaced by original spare parts in case of a malfunction.*
 - *the electrical installation of the room concerned does not meet the requirements or the corresponding national regulations.*
 - *the product is not used in accordance with the operating instructions.*
-

CAUTION!

Only service technicians are allowed to open the covers

CAUTION!

When installing this equipment in a different location, contact the manufacturer or the designated dealer.

Safety

Installation and repair

2.5 Installation and repair



WARNING!

To avoid risk of electric shock, this equipment must only be connected to a supply mains with protective earth.

CAUTION!

Only service technicians are allowed to open the covers.

CAUTION!

Do not remove, disassemble, change, modify, repair, or add any part.

CAUTION!

When installing this equipment in a different location, contact the manufacturer or the designated dealer.

Note!

For exchange of the collimator light field lamp, see the Collimator manual.













Modifications of, or additions to, the product must be made in accordance with the legal regulations and generally accepted engineering standards.

The manufacturer cannot assume responsibility for the safety features and for the reliability and performance of the equipment, if:

- installation of equipment expansions or modification are not approved by the manufacturer.
- installation of equipment expansions or modification are not carried out by persons authorized by the manufacturer.
- components are not replaced by original spare parts in case of a malfunction.
- the electrical installation of the room concerned does not meet the requirements or the corresponding national regulations.
- the product is not used in accordance with the operating instructions.

2.6 Safety and Warning Symbols

The following symbols are used for the product.

| | |
|---|---|
|  | Attention consult accompanying documents. |
|  | To signify a general warning. This symbol is used in various places throughout the Manual where special precaution shall be observed. |
|  | Type B applied part. |
|  | Protective earth terminal. |
|  | Earth terminal. |
| N | Connection point for the neutral conductor on permanently installed equipment. |
|  | Squeezing hazard. |
|  | This symbol indicates compliance of the equipment with Directive 93/42/EEC. |
|  | Separate collection for electrical and electronic equipment. |
|  | Manufacturer |
|  | Manufacture date producer |
|  | To indicate the emission or the imminent emission of X-radiation. |
|  | Marking on the emergency stop button. Activation of the actuator interrupts all mechanical movements and prohibits exposures. |

Safety

Safety and Warning Labels on the Equipment

2.7 Safety and Warning Labels on the Equipment

The figure shows the location of the safety and warning labels.




Fig. 2-1 Locations of safety and warning labels

2.8 Applied Parts

Applied parts are intended for the patient to touch.




Fig. 2-2 Applied parts, System

2.9 Emergency stop

Note!

It is recommended to train the operator regularly in the use of the emergency stop function so the operator feels confident in using it.

The System has six internal emergency stops; one connected to the OTC and one on the servo button, one on each side of the table (at the head end) and two on the wall stand.

Pressing one of the emergency stop buttons immediately cuts the power to all motorized movements. The emergency stop is also connected to the generator. The emergency stop prevents a new exposure and terminates an ongoing exposure.

A system message is displayed in OTC display when the button is activated.

To reset the emergency stop position, turn the emergency stop button clockwise. The button is released and the system is ready for use again.

When the emergency stop is activated, it is possible to change the position of the tube/collimator manually, by lifting the overhead tube crane upwards and pushing or pulling sideways if needed.

There are additional external emergency stops as option.




Fig. 2-3 Emergency stop buttons

2.10 Radiation and X-ray tube



WARNING!

The patients, the operators and third parties must be protected against unnecessary X-ray radiation according to the local regulations.



WARNING!

*The surfaces on the collimator and the X-ray tube can be warm.
The X-ray tube may be up to 85 °C, the collimator will not reach 60 °C.*



WARNING!

Verify that correct collimator filter is used during exposure.

CAUTION!

*To minimize the X-ray dose, keep the distance between the focal spot and patient as large as possible.
The beam size should be as small as possible.*

Note!

Audio and visual communication must be possible between the operator and the patient when exposure is performed.

Note!

The X-ray beam should not be outside the boundaries of the detector holder.

2.10.1 Radiation protection

Because of the ionizing nature of x-ray radiation, precautions have to be taken to minimize the harmful effects to patients and operators/staff during exposures. The aim is to achieve dose levels “as low as reasonable achievable”. National regulatory dose limitation requirements have to be followed.

Following four main factors control the amount (dose) of radiation received from a source:

Patient and operator dose:

Loading factors: Reducing the loading factors reduces the effective dose proportionally. Lower values will give more noise in the image.

Distance: Increasing the distance reduces dose levels according to the inverse square law.

Beam size: Keep the beam size as small as possible.

Shielding: Whenever possible/necessary protective shielding should be used to limit dose levels.

2.10.1.1 Protection against primary radiation (patient)

Following measures should to be taken to limit patient dose.

- Observe national dose limit regulations.
- Exposure parameters (time/mA) should be set as low as possible with an acceptable image noise level.
- Set focus to skin distance as large as possible.
- Always collimate the exposure field to the area of interest. This will both decrease the dose level and improve the image quality (less scattered radiation).
- If possible/necessary use protective shielding.

2.10.1.2 Protection against secondary radiation

As the patient is the most significant source of scattered radiation during an x-ray exam, the staff and/or operator will unavoidable be exposed to ionizing radiation when inside the x-ray room during an exposure. Radiation doses from scattered radiation can be significantly high. Following safety measures should be taken to minimize scattered radiation to the staff.

- Increasing the distance to the central beam reduces dose levels according to the inverse square law.
- Protective clothing, e.g. lead apron, should always be used.
- Exposure parameters (time/mA) should be set as low as possible.
- Using high kV and low mA produces less scatter.
- Always collimate the exposure field to the area of interest.
- Added collimator filter reduces the scatter.
- Compression of patient.

Profile of stray radiation for table

The diagram below, Fig. 2-4 *Scattered radiation rate expressed in percent of central beam dose rate, with and without shielding*, shows the dependency of the scattered radiation on the distance from the central beam, height above the floor and kV potential. The decrease of the scattered radiation is expressed in percent of the central beam exposure rate (100%). The diagram also shows the decrease of scattered radiation when using protective clothing, also this expressed in percent of the central beam dose rate.

Fig. 2-4 *Scattered radiation rate expressed in percent of central beam dose rate, with and without shielding*, shows that a higher kV increases the scattered radiation slightly. The diagram also shows that the best way to minimize the effect of the scattered radiation is an increased distance to the patient and by using a lead apron.

Central beam exposure parameters used:

KVP: 70, 100, 120 kV

Tube current: 100 mA

Exposure time: 100 ms

Field size: 43x43 cm

Film-Focus distance: 1 m

Patient simulation: 150 mm PMMA

Filter: 0 mm

Central beam dose rate measured on top of PMMA (750 mm from focus).





Fig. 2-4 *Scattered radiation rate expressed in percent of central beam dose rate, with and without shielding*

Safety

Radiation and X-ray tube

Fig. 2-5 *Zone of occupancy*, shows a top view of the table and the zone of occupancy, the arrows showing the direction of decreasing scatter radiation levels.



S = significant zone of occupancy

Fig. 2-5 Zone of occupancy

Profile of stray radiation for wall stand

The diagram below, Fig. 2-6 *Scattered radiation rate expressed in percent of central beam dose rate, with and without shielding*, shows the dependency of the scattered radiation on the distance from the central beam, height above the floor and kV potential. The decrease of the scattered radiation is expressed in percent of the central beam exposure rate (100%). The diagram also shows the decrease of scattered radiation when using protective clothing, also this expressed in percent of the central beam dose rate.

Fig. 2-6 *Scattered radiation rate expressed in percent of central beam dose rate, with and without shielding* shows that a higher kV increases the scattered radiation slightly. The diagram also shows that the best way to minimize the effect of the scattered radiation is with an increased distance to the patient and by using a lead apron.

Central beam exposure parameters:

KVP: 70, 100, 120 kV

Tube current: 100 mA

Exposure time: 100 ms

Field size: 40x40 cm

Film-Focus distance: 1,5 m

Patient simulation: 150 mm PMMA

Filter: 0 mm

Central beam dose rate measured on top of PMMA (1250 mm from focus)




Fig. 2-6 *Scattered radiation rate expressed in percent of central beam dose rate, with and without shielding*

Fig. 2-7 *Zone of occupancy*, shows a top view of the wall stand and the zone of occupancy, the arrow showing the direction of decreasing scatter radiation levels.




Fig. 2-7 *Zone of occupancy*

2.10.1.3 Protection against residual radiation

The remaining part of the X-ray beam after having passed the plane of the image reception area (detector and detector holder) can be significantly high. Never stand behind the wall stand during an exposure, see Fig. 2-7 *Zone of occupancy*.

2.11 Mechanical safety

2.11.1 General



WARNING!

All motorized movements shall be supervised by trained personnel.



WARNING!

Tracking shall be supervised by trained personnel.



WARNING!

Wheelchair patients shall always be placed outside the working area, when operating any motorized movement.

Note!

Surrounding equipment are not subject of the collision warning.

2.11.1.1 General

It is the operator's duty, before any movements are activated, to ensure that any danger to the patient and/or third person is prevented.

2.11.2 Overhead tube crane



WARNING!

Squeezing hazard between the wall stand and the table.

The operator should be beside the patient for support to avoid any risk of injury when handling the OTC.



WARNING!

Squeezing hazard can occur between column segments and beta rotational assembly interface.




WARNING!

Squeezing hazard can occur between the column and the plastic corner around the alpha movement.



WARNING!

Squeezing hazard can occur between support arm and high tension cable inlet to the tube.



Possible squeezing hazard areas and placement of warning label:

Squeezing hazard can occur between the:

- column (1) and the column bottom plate (4) when the column is moving upward (Z-direction).
- cover (2) and the column (Z) when the X-ray tube is moving in beta (β) direction.

Fig. 2-8 Overhead tube crane, mechanical safety

1. Column (Z)
2. Cover
3. X-ray tube
4. Column bottom plate

2.11.3 Cabinet

Placement of warning and safety label:




Fig. 2-9 Cabinet, mechanical safety

2.11.4 Table



WARNING!

Squeezing hazard can occur between the:

- *table top and the top of the detector holder*
 - *table top and the detector holder rail*
 - *detector holder rail and the detector holder*
 - *detector holder and the cover*
 - *columns and the footplate*
 - *cover and the column foot cover*
 - *detector holder and vertical lift segment*
-

Possible squeezing hazard areas and placement of warning labels:




Fig. 2-10 Squeeze hazard, table

2.11.4.1 Safety issues when positioning a patient



WARNING!

Be aware of unwanted motion when releasing the brakes.



WARNING!

Risk of injury during transfer of the patient between the hospital bed and the table.

The hospital bed shall be placed in direct contact with and in the same height as the table.

The table top shall be locked.



WARNING!

Risk of squeezing hazards.

The patients shall always have their extremities placed over the table top.

Note!

Do not lean against the floating table top.



WARNING!

Wheelchair patients shall always be placed outside the working area, when operating any motorized movement.




Fig. 2-11 Transfer patient to table

Lock and center the table top when transferring the patient to the table.

The hospital bed shall always be placed in direct contact and in the same height as the table.

To reduce the lateral forces on the table the operator should be placed on the opposite longitudinal side of the patient and the hospital bed. The operator should drag the mattress with the patient from the hospital bed to the table.

Patient weight restrictions

The following figures show the maximum load at different positions of the table.




Fig. 2-12 Table top centered

Table top centered over the table frame

- Maximum load of a patient lying or sitting
 - 300 kg, see Fig. 2-12 Table top centered




Fig. 2-13 Table top outside table frame

Table top positioned outside the table frame

- Maximum load of a patient lying on the table top:
 - 200 kg, see Fig. 2-13 Table top outside table frame
- Maximum load of a patient sitting on the table top:
 - 150 kg.




Fig. 2-14 Maximum patient weight label

The table frame is marked on the upper side with the maximum weight when positioning in outer positions, see Fig. 2-14 Maximum patient weight label.

2.11.4.2 Working area, table



WARNING!

Risk of squeezing hazard.

Patients shall be outside the working area or placed on the table, when operating any motorized movement.



WARNING!

Risk of squeezing hazard.

All obstacles placed within the working area, must be moveable for easy patient release.

CAUTION!

To avoid any injuries to patient, user or damage to system, peripherals should always be placed outside the working area.

The working area is the size of the table top including the stroke length of the table top in the X- and Y-direction. The measurements in the figure show the length of stroke in the X- and Y-direction. The dimensions have some tolerances and can differ from the manufacturer.

Two column table




Fig. 2-15 Table top stroke length




Fig. 2-16 Working area underneath table

The detector movement is up to 850 mm, depending on detector type.




Fig. 2-17 Detector movement

2.11.5 Wall stand

2.11.5.1 Safety issues when position patient



WARNING!

Be aware of unwanted motion when releasing the brakes.

Note!

Maximum weight on the wall stand lateral armrest is 25 kg.

2.11.5.2 Working area, wall stand

The wall stand working area is in front of the detector holder.




Fig. 2-18 Working area, wall stand

2.11.5.3 Standard version



WARNING!

Risk of squeezing between the tilted image receptor holder and the floor.

Getting stuck in the detector holder slide opening causes squeezing hazard if the detector holder is moving downward (Z-direction).

Possible squeeze hazard areas and placement of warnings and safety labels:




Fig. 2-19 Possible squeeze hazards

1. Slide opening of the detector holder

2.11.5.4 Motorized wall stand

CAUTION!

Patients shall be outside the working area when operating any motorized movement.

2.12 Safety functions

2.12.1 System

2.12.1.1 Collision detection

Input check

To secure that the system is operational and fully functional the system performs a self test at start up. The system checks that no inputs are activated during start up. In that case the system takes actions to inhibit the function to be used. If a safety related input, such a switch in the foot control or in the handle is active, the system stops sending the watchdog signal to the trig relay and the power to the motor is cut.

Motorized movements

Motorized movements are performed using a PID-controller with position feed-back. An absolute encoder or a potentiometer or both a potentiometer and a quadrature encoder may be used as position transducer. The speed of the movement follows a trapezoid shaped curve.

The movement is stopped when a collision or a faulty position transducer is detected. A collision is detected if the control error is too large. The control error is defined as the difference between the set point and the actual position. The set point is given by the ramp generation and the actual position is given from the position transducer. The maximum allowed difference is set by a parameter.

Z Column

A guard plate installed on top of the column, registers vertical pressure on the column, for instance a vertical impact.

When the pressure exceeds the trig level vertically, all movements are stopped and a warning message is displayed. To be able to release the pressure, a movement in the opposite direction is allowed. When the pressure on the column has returned to normal, see Fig. 2-20 *Collision detection* the warning message is removed and motorized movements are allowed again.




Fig. 2-20 Collision detection

A Zero force level
B Hysteresis

C Upper trig level
D Lower trig level

Note!

In some situations it is possible to force a false detection of a collision. This can occur if the column is affected by a pressure at the time the movement starts. This could be for example the case if the collimator rests on the Table, when the operator moves the column upward, a collision is detected.

The reason for the collision detection is that, when the movement starts, the zero force level is calculated based on the actual pressure affecting the column at that moment. As soon as the movement starts and the collimator is no longer resting on the Table, the guard plate catch a change in pressure and a collision is detected.

To solve the problem the operator must affect pressure on the column, for example manually pull the column up or down. The System will take this as a sign that the operator has re-moved the obstacle and that no collision exists any more. If the problem is yet not solved, the System must be restarted.

Motor node

Every motor node has a collision detection on their own movements. A collision can be detected in different ways, for instance, if:

- The control error in the motor node's regulator is too large.
- The final position is not reached in time.
- The position transducer has not moved although the drive unit has had an output voltage for a given time.

A detected collision makes the stand stop all movements and display an error message.

Quick abortion of an auto positioning

When any of the buttons on the stand is pressed while the stand is moving toward its position, it has the same effect as when the servo button is released, all movements are stopped.

Opposite buttons pressed

If, at any time, two from each other opposite buttons are pressed, for example movements up and down, the movement is stopped. Both buttons must be released before any movement is allowed.

2.12.1.2 Malfunctioning Node

If any node stops functioning, all movements are stopped and the power to the motors in the System is removed.

2.12.1.3 Dead man's grip

All movements require constant activation of the chosen button.

If the operator releases one of the buttons/controls, the system will immediately stop or engage the brakes (manual movements). The exposure operator console has the same functionality.

2.12.1.4 Watchdog

One important issue for the safety in the system is the node error handling e.g. transmission error, software error or irregular behaviour of a node. The system is built to prevent an un-controlled movement.

The design relies on two different constructions to have a safe communication and safe error handling.

The first is the CAN bus itself. The CAN bus is a highly reliable bus, which take care of transmission errors and retransmissions on corrupted messages. If a message is sent and no errors are reported it is presumed to be guaranteed that the message is transferred and received correctly in all receiving nodes.

The other design is the watchdog handling between nodes. As soon as two nodes start to communicate with each other, each node must send a watchdog message to the other node within a defined time. If the message is not received within the time frame, the state for the node is then considered as disconnected.

With help of the above described constructions it is guaranteed, with a reasonable safety, that every message is transferred and received by the receiving node. If a message is not received or a node is removed it will be detected and measures will be taken.

A transmission error on the CAN bus will put the system in an ERROR state.

A missing watchdog message from a node on the internal bus will put the system in an ERROR state.

A missing watchdog from a node will stop all motors.

The watchdog mechanism is also used for inhibiting uncommanded movements in case of software failure in the master node. The master node continuously sends a watchdog command (signal) to a trig relay (time relay). If the relay does not receive the signal within a defined time, the power (36 V) to the drivers will be cut.

Note!

It is only the 36 V that is blocked, i.e. the logic (24 V) is still live, hence the system as such is still active.

2.12.1.5 PID controller

The control loop is implemented as a PID-controller with both acceleration and velocity feed forward. The function of the anti-windup is to prevent any increase of the integration part when the driver board limits the output voltage to a value less than the desired output voltage.

2.12.1.6 Two column table

Table top guard (option)

The table has a collision detection system that protects the table. It activates if a collision is detected and all movement is stopped.

Sensors are placed in each corner of the table frame. The sensors register vertical pressure on the frame, for instance a vertical impact. When the pressure exceeds the trig level in any direction all movements are stopped and the motors are short circuited (the short circuiting of the motors provides a quick and solid stop). To be able to release the pressure, a movement in the opposite direction is allowed. When the pressure has returned to normal, see Fig. 2-21 *Collision detection*, the movement is allowed again. The guard is active during downward and upward movement. A command is sent from the master node when the movement is activated and deactivated. During this period the response on changes of the pressure is received from the sensors. The reason for this design is that by only allowing the guard to be active during movements the temperature deviation is inhibited.




Fig. 2-21 Collision detection

A Zero force level

B Hysteresis

C Upper trig level

D Lower trig level

Table top crash guard

The table top crash guard shall only be primarily used as a safety precaution for the system, but will as well limit the risk of personal injury, although the crash guard does not guarantee patient protection.

To be able to detect a collision, four micro switches are placed between the table and the table top. If the table crashes into an object, the micro switches will stop the movement in the on-going direction, but it will allow the movement in the opposite direction. When the object is removed, the table can move in both directions again.

At power-up, the table will detect if a button is activated, and then disable all movements. If that is the case, switch off the power and remove the obstacle/replace the broken switch.

Ramp generation

The set point speed of the ramp is generated as an integration of the ramp acceleration (deceleration); the set point position of the ramp is generated as an integration of the ramp speed. The acceleration, deceleration and the maximum speed of the ramp are set as parameters.

The speed of the ramp is increased until the maximum speed is reached. For this increase in speed, the acceleration parameter is used. This is independent of the direction of the acceleration. This maximum speed is maintained until it is time to start the deceleration. This deceleration point is given by the current speed, the rate of the deceleration and the desired final position of the ramp.

The dynamic calculation of the ramp makes it possible to change direction of an active ramp generation. In this case the ramp will first decelerate, using the deceleration value until zero speed is reached, then the acceleration in the other direction will commence.




Fig. 2-22 Speed profile of a motorized movement

2.12.1.7 Wall stand

The product is balanced with counterweights and whenever any item is removed from the wall stand it will become unbalanced. If the brake is released when the wall stand is unbalanced, the detector holder moves and can cause injury.




Fig. 2-23 Wall stand

4011-02

2.13 Safety zone, definition

2.13.1 Table Safety zone

There is a safety zone over and around the table.

The safety zone reaches from the table top surface and vertical up 500 mm and from the table top edge and horizontal out 120 mm. Inside the zone, the table moves downwards with reduced speed.



WARNING!

When the stand has passed the table top level, on its way downwards, the speed increases to normal speed again.

2.13.2 Two column table

There is a squeezing risk when driving the table to a low position.

Within the safety zone the table moves at a low speed, to increase the possibility for the user to react in case of a collision (squeezing). The safety zone appear 120 mm above the floor, according to IEC 60601-1. The safety zone automatically stops the two column table, 120 mm above the floor. The user must then activate the foot control again to make the table move further down.

Safety

Electromagnetic compatibility (EMC)

2.14 Electromagnetic compatibility (EMC)

The system complies with the requirements of IEC 60601-1-2:2014 regarding electromagnetic compatibility. Surrounding equipment shall follow the standard IEC 60601-1-2:2014.



WARNING!

Do not use this equipment adjacent to or stacked with other equipment.

Such use could lead to improper operation.

Verify that the equipment is operating normally, if such use is necessary.



WARNING!

Do not use other accessories, transducers and cables than those specified or provided by the manufacturer.

Such use could lead to increased electromagnetic emissions or decreased electromagnetic immunity of this equipment and result in improper operation.



WARNING!

Do not use portable RF communications equipment (including peripherals such as antenna cables and external antennas) closer than 30 cm (12 inches) to any part of the system, including cables specified by the manufacturer.

Such use could lead to degradation of the performance of this equipment.

CAUTION!

Do not place the system near MRI equipment or other equipment that generates a strong magnetic field.

CAUTION!

Mobile telephones and other radiating equipment can interfere with the function of the system and can therefore cause safety hazards.

The system is intended for use in the electromagnetic environment specified below. The customer or the user of the system should assure that it is used in such an environment.

| Guidance and manufacturer's declaration - electromagnetic emissions | | |
|---|----------------|--|
| Emissions test | Compliance | Electromagnetic environment - guidance |
| RF emissions CISPR 11 | Group 1 | The system uses RF energy only for its internal function. Therefore, its RF emissions are very low and are not likely to cause any interference in nearby electronic equipment. |
| RF emissions CISPR 11 | Class B | The system is suitable for use in all establishments, other than domestic and those directly connected to the public low-voltage power supply network that supplies buildings used for domestic purpose. For information purpose the system complies with IEC61000-3-11 and is suitable for connection to public mains network if the impedance is 0.32 Ohm or lower |
| Harmonic emissions IEC 61000-3-2 | Not applicable | |
| Voltage fluctuations/ Flicker emissions IEC 61000-3-3 | Not applicable | |

Safety

Electromagnetic compatibility (EMC)

The system is intended for use in the electromagnetic environment specified below. The customer or the user of the system should assure that it is used in such an environment.


| Guidance and manufacturer's declaration - electromagnetic emissions | | | |
|--|--|--|--|
| Emissions test | IEC 60601 test level | Compliance level | Electromagnetic environment - guidance |
| Radiated emissions CISPR 16-2-3 | 30 MHz to 230 MHz: QP 40 230 MHz to 1 GHz: QP 47 | 30 MHz to 230 MHz: QP 40 230 MHz to 1 GHz: QP 47 | |
| Conducted emissions CISPR 16-2-1 | 150 kHz to 500 kHz: QP 100+20, average 90 500 kHz to 5 MHz: QP 86+20, average 76 5 MHz to 30 MHz: QP 90+20 (at 5 MHz) decreasing linearly to 73+20 (at 30 MHz) average 80 (at 5 MHz) decreasing linearly to 60 (at 30 MHz) | 150 kHz to 500 kHz: QP 100+20, average 90 500 kHz to 5 MHz: QP 86+20, average 76 5 MHz to 30 MHz: QP 90+20 (at 5 MHz) decreasing linearly to 73+20 (at 30 MHz) average 80 (at 5 MHz) decreasing linearly to 60 (at 30 MHz) | |
| Note: These limits apply to equipment with a rated power > 20 kVA and intended to be connected to a dedicated power transformer or generator, and which is not connected to low voltage (LV) overhead power lines. 20 dB relaxation for Quasi-Peak (QP) is allowed for Radiography and pulsed Radiography (Intermittent Mode). | | | |

The system is intended for use in the electromagnetic environment specified below. The customer or the user of the system should assure that it is used in such an environment.

| Guidance and manufacturer's declaration - electromagnetic immunity | | | |
|---|--|--|---|
| Immunity test | IEC 60601 test level | Compliance level | Electromagnetic environment - guidance |
| Electrostatic discharger (ESD) IEC 61000-4-2 | ± 8 kV contact ±15 kV air | ± 8 kV contact ± 15 kV air | Floors should be wood, concrete or ceramic tile. If floors are covered with synthetic material, the relative humidity should be at least 30%. |
| Electrical fast transient/burst IEC 61000-4-4 | ± 2 kV for power supply lines + 1 kV for input/output lines 100 kHz repetitive frequency | ± 2 kV for power supply lines + 1 kV for input/output lines 100 kHz repetitive frequency | Mains power quality should be that of a typical commercial or hospital environment. |
| Surge IEC 61000-4-5 | 1.0 kV 1.2 kV 2.0 kV 0,90, 180, 270 degree phase angle | 1.0 kV 1.2 kV 2.0 kV 0,90, 180, 270 degree phase angle | Mains power quality should be that of a typical commercial or hospital environment. |
| Voltage dips, short interruptions and voltage variations on power supply input lines. IEC 61000-4-11 | <5 % U_T (>95 % dip in U_T) for 0.5 cycle (0, 45, 90, 135, 180, 255, 270, and 315 degrees phase angle) <5% U_T (>95% dip in U_T for 1 cycle) 70% (30 % dip in U_T for 25/30 cycles) <5 % U_T (>95 % voltage dip in U_T for 250/300 cycles) | <5 % U_T (>95 % dip in U_T) for 0.5 cycle (0, 45, 90, 135, 180, 255, 270, and 315 degrees phase angle) <5% U_T (>95% dip in U_T for 1 cycle) 70% (30 % dip in U_T for 25/30 cycles) <5 % U_T (>95 % voltage dip in U_T for 250/300 cycles) | Mains power quality should be that of a typical commercial or hospital environment. If the user of the system requires continued operation during power mains interruptions, it is recommended that the system should be powered from an uninterruptible power supply or battery. |
| Power frequency (50/60 Hz) magnetic field IEC 61000-4-8 | 30 A/m | 30 A/m | Power frequency magnetic fields should be at levels characteristic of a typical location in a typical commercial or hospital environment. |

Safety

Electromagnetic compatibility (EMC)

| Guidance and manufacturer's declaration - electromagnetic immunity | | | |
|--|---|---|--|
| Immunity test | IEC 60601 test level | Compliance level | Electromagnetic environment - guidance |
| Note! ————— <i>U_T is the AC mains voltage prior to application of the test level.</i> | | | |
| | | | Portable and mobile RF communications equipment should be used no closer to any part of the system, including cables, than the recommended separation distance, calculated from the equation applicable to the frequency of the transmitter. Recommended separation distance; |
| Conducted RF IEC 61000-4-6 | 3 Vrms 150 kHz to 80 MHz 6 Vrms (ISM and amateur radio bands) | 3 Vrms 150 kHz to 80 MHz 6 Vrms (ISM and amateur radio bands) | $d = 1.2 \sqrt{p}$ |
| Radiated RF IEC 61000-4-3 | 3 V/m 10 V/m 80 MHz to 2.7 GHz | 3 V/m 10 V/m 80 MHz to 2.7 GHz | $d = 1.2 \sqrt{p}$ 80 MHz to 800 MHz $d = 2.3 \sqrt{p}$ 800 MHz to 2.7 GHz where p is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer and d is the recommended separation distance in metres (m). |
| Proximity field from wireless transmitters 61000-4-3 | 9 V/m to 28 V/m 15 specific frequencies | 9 V/m to 28 V/m 15 specific frequencies | |
| | | | Interference may occur in the vicinity of equipment marked with the following symbol:  |
| NOTE 1: These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people. | | | |

Recommended separation distances between portable and mobile RF communications equipment and system

The system is intended for use in an electromagnetic environment in which radiated RF disturbances are controlled. The customer or the user of the system can help prevent electromagnetic interference by maintaining a minimum distance between portable and mobile RF communications equipment (transmitters) and the system as recommended below, according to the maximum output power of the communications equipment.

| Rated maximum output power of transmitter <i>W</i> | Separation distance according to frequency of transmitter | | |
|--|---|--|--|
| | 150 kHz to 80 MHz $d = 1.17 \sqrt{p}$ | 80 MHz to 800 MHz $d = 0.35 \sqrt{p}$ | 800 MHz to 2.7 GHz $d = 0.7 \sqrt{p}$ |
| 0.01 | 0.12 | 0.04 | 0.07 |
| 0.1 | 0.37 | 0.11 | 0.22 |
| 1 | 1.17 | 0.35 | 0.7 |
| 10 | 3.69 | 1.11 | 2.21 |
| 100 | 11.67 | 3.5 | 7 |

For transmitters rated at a maximum output power not listed above, the recommended separation distance *d* in metres (m) can be estimated using the equation applicable to the frequency of the transmitter, where *p* is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer.

NOTE 1: These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption as reflection from structures, objects and people.

Safety

Electromagnetic compatibility (EMC)

3 Theory of operation

3.1 User interface description

The system is operated from the user interface controls, inside the examination room and from the operating room.

The exposure controls are placed in the operating room whereas the positioning controls are placed in the examination room (lab). The basic idea is that the functions shall be operated from the position where they are needed, which will enhance the workflow and increase the efficiency.

All position controls use a continuous activation technique which basically means that the operator must press and hold the key to activate the function. On release, the function will be deactivated. An extra external servo button can be ordered for the operation room.

3.2 Basic concepts

Subsystem 0072 is built with a number of separate subsystems, acting as individual units in the System.

The different subsystems are:

- High voltage generator
Responsible for the emission of X-rays.
- Cabinet
The interface between the image system and the generator
- OTC
Responsible for handling of the X-ray tube ceiling support. Important functions for this subsystem are, moving Z up/down, X, Y, Alpha and Beta, tracking of table and wall stand, and as a last function to inform the user about system status.
- Wall stand
Responsible for holding the detector for chest examinations. Also possible to move the detector in Z and tilt direction.
- The table
Holding the detector, support patient. Moving the table up/down, detector and handling of a brake for the table top.
- The image system.

3.3 Overhead tube crane

3.3.1 General user interface


The controls of the OTC are placed at the handlebar in front of the X-ray tube. The controls are used for enabling and disabling functions concerning the OTC.

The following information is always displayed on the system display.

- Alpha angle
- Beta angle
- Distance, or the distance to the floor (depending on modes)
- Mode
- Position

See Operation manual for user description of the controls.

3.3.2 System Display Overview



- | | |
|---------------------------------------|--|
| 1. Up | 7. Automatic collimator, see 3.3.3.1 <i>Automatic collimator</i> |
| 2. Down | 8. Light indication, see 3.3.3.14 <i>Light indication</i> |
| 3. Y direction | 9. Display user interface, see 3.3.3.2 <i>Display user interface</i> |
| 4. X direction | |
| 5. Emergency brake (rear side) | |
| 6. Release all directions (rear side) | |

Theory of operation

Overhead tube crane

3.3.3 Automatic Collimator Control

The collimator is used to adjust the size of the x-ray field to cover the area of interest of the patient by adjusting the collimator light field size. The collimator light field size / x-ray field size and the collimator filtration can be predefined in the anatomical protocols and is then set automatically when the protocol is selected. The size of the light / x-ray field and the filtration can then be adjusted when needed to adapt to the patient.

The collimator can be operated from the collimator interface at the Overhead tube crane, from the hand control at the wall stand or from the control handle at the table (option).

The following figure shows the functions of the automatic collimator.





Fig. 3-1 Display, automatic collimator

1. Knob for adjusting collimator light/x-ray field height
2. Collimator light and laser light on/off.
Automatic off after predefined time.
3. Knob for adjusting collimator light/x-ray field width
4. Measuring tape grip for SID measurement, graduation in cm/inch -
Take reading at bottom edge of multi-leaf collimator.
5. Accessory rail

The collimator can rotate around the central beam axis $\pm 90^\circ$.

3.3.3.1 Automatic collimator



1. Select *Automatic* or *Manual* mode of the collimator.

Note!

If there is no new examination and the System is in a Manual mode, the collimator ignores the instructions of sent collimator area from the Imaging system. This can be useful if the collimator area is intended to be kept for the next examination.

2. Collimator light/x-ray field height x width
3. Collimator filter selection

Collimator mode



In automatic mode, the collimator light height and width is set from the anatomical program. The collimator light size can still be changed manually. In manual mode the collimator light height and width is not set from the anatomical program.

1. Automatic mode
2. Manual mode

Fig. 3-2 Collimator mode

When Automatic mode is selected the predefined values of the collimator light / x-ray field size and the filter selection will be set automatically when the anatomical protocol is selected. Both the light / x-ray field size and the filter can be changed when needed. In automatic mode the maximum light / x-ray field size is restricted to the maximum active area of the imaging unit.

When manual mode is selected the size of the collimator light / x-ray field size can be adjusted outside of the maximum active area of the imaging unit. When a new anatomical protocol is selected (for the same patient) the collimator light / x-ray field size or the filtration is not changed even if size and filtration is defined different in the protocol.

Theory of operation

Overhead tube crane

When changing from Manual mode to Automatic mode the collimator light / x-ray field size and filtration is restored to the values that were selected when changing from automatic to manual mode. Example:

- Automatic mode: Size: 30 cm x 10 cm; filter 1.
- Changes to Manual mode. Changes: Size: 30 cm x 20 cm, filter 2.
- Changes back to Automatic mode: Size 30 cm x 10 cm, filter 1.

When a new patient is selected Automatic mode is automatically activated.

Collimator filtration selection



The user can change the selected value from the display.

1. Collimator filtration selection icon
2. Collimator filtration selection values

Collimator filters

The collimator filter options are:

- No added filtration
- Filter 1 = 1 mm Al + 0.1 mm Cu
- Filter 2 = 1 mm Al + 0.2 mm Cu
- Combined: 2 mm Al + 0.3 mm Cu

The filters can be predefined in the anatomical protocol and also be changed if needed

Laser

The laser can be switched off by applying a mechanical cover over the laser. The cover is available underneath the collimator.

Collimator functionality - system

When the OTC moves in a direction that changes the SID, the collimator starts to compensate the field size. The collimator light field size on the imaging unit is held constant with changing SID.

When the OTC is tracking against the Wall stand or when the table top is released, the collimator light automatically will be turned on. This will make it easier to directly find the correct stand and patient position.

In *Free mode*/*Auto position* mode the position of the detector is unknown for the System. The indicated size of the light field is correct at the shown SID.

Collimator Control Handle, Table (option)





Fig. 3-3 Table collimator control handle

- A. Button for switching the light and the laser line on/off. The light and laser line is automatically switched off via a time switch.
- B. Button for changing between *Automatic mode* and *Manual mode*. A long activation of the *M button* set the light field to max image size, based on the pre-programmed SID value and the selected receptor.
- C. Button for closing the format height collimation.
- D. Button for opening the format height collimation.
- E. Button for opening the format width collimation.
- F. Button for closing the format width collimation.

Hand control, Wall stand – collimator adjustment




- A. Collimator light on/off
- B. Adjustment height collimation
- C. Adjustment width collimation

Fig. 3-4 Hand control

Theory of operation

Overhead tube crane

3.3.3.2 Display user interface



1. Patient information
2. Active protocol
3. Position information
4. Adjustment of generator parameters: kV, mA, ms, mAs
5. Select the settings menu
6. Hospital manual
7. Active System mode
8. Selection of Technique mode
9. Selection of active AEC field (AEC mode only)
10. Patient size
11. Collimator centering
12. Manual or Servo mode
13. Density

See the following pages for detailed description of the functions.


3.3.3.3 Patient Information

In this field the *Patient Name*, *Patient ID*, *Date of Birth*, *Age*, *Sex* and *Accession number* can be shown.

The information shown is defined in the *Setting menu*. In the *Setting menu* it is also possible to decide if the *Patient information* shall be shown always (picture 1), or on demand (picture 2).

When the button is shown on demand, the *Patient information* can be obtained by pushing the "i" on the black bar.

The *Patient information* closes automatically, or when the bar is pushed once again.



Picture 1



Picture 2

Fig. 3-5 Patient information display

3.3.3.4 Position Information




Fig. 3-6 Position information

- A. Alpha angle (°)
- B. Beta angle (°)
- C. Source Image Distance (SID), or Height to floor (H) in Free or Auto Position Mode (cm/inch)

The height to floor (H) is shown in *Free mode* and *Auto position mode*. In all other modes the source image distance (SID) is shown. The unit for the distance can be either cm or inch, and is set in the *Setting menu* (Fig. 3-6 Position information).

Theory of operation

Overhead tube crane

3.3.3.5 Adjustment of Generator Parameters (kV, mA, ms, mAs, Density)

In order to change the exposure values, the button with the parameter that shall be changed, is pushed. Then the user may select to increase or decrease the value.



Fig. 3-7 Adjustment of generator parameters

Note!

The Operator/User is always responsible for checking and validating the exposure parameters in the Image system before performing exposure.

Exposure Index

The exposure index, EXI, is a measure of the amount of exposure received by the detector and depends on mAs, the total detector area irradiated respective the beam attenuation. It is indicative of the image quality.

3.3.3.6 Settings

The *Setting menu* is reached by activating the *Setting* button for 1 second.



Fig. 3-8 Setting button

The *Setting menu* has the following tabs; *User Settings* and *Service*.

User settings has the following tabs: *Display*, *Settings* and *Themes*.

Service has the following tabs: *Log*, *Settings* and *Display*.

User settings

User settings – Display





Fig. 3-9 User settings – Display

Patient Info

CAUTION!

The user shall always assure that the Patient info and the type of examination is corresponding to the one in HIS and RIS.



When the *Always on* is marked, the *Patient information* is shown as soon as the information is selected in the imaging display.

Fig. 3-10 “Always On” selected



When the *Always on* is **not** marked, the *Patient information* is shown when pushing the black field where the “i” is.

Fig. 3-11 “Always On” not selected.

The *Patient information* closes automatically.

It is also possible to select what patient information to show on the display. The following parameters can be selected:

- *Date of Birth (DoB)*, different formats selectable
 - YYYY-MM-DD
 - DD-MM-YYYY
 - MM-DD-YYYY

Theory of operation

Overhead tube crane

- ID
- Age
- Sex
- Accession number
- Examination/Active Protocol

User settings – Settings




Fig. 3-12 User settings – Settings

In the *Settings* tab, it is possible to adjust the following:

- Preview Image (not applicable for CR systems)
- Localization unit selection
- Audio key click, On/Off
- System sound, On/Off
- LCD brightness, Plus/Minus
- Arcoma logotype in display, On/Off

– Image preview on

By selecting this, a small preview image will be shown next to the Active Protocol name (see figure on page57).

– Localization

Changes between cm and inch, for collimator light width and height values and SID/H.

– Audio Key Click

By selecting this, a key click will be heard when touching the System display.

– Sound on

By selecting this, a beep will be heard when OTC is aligned with the detector, at tracking.

LCD

The display brightness can be adjusted. There is also a setting if the logo shall be shown or not.

Theory of operation

Overhead tube crane


Preview Image



WARNING!

The preview image must not be used for diagnostics or positioning

It is possible to select if a *Preview image* shall be shown on the touchscreen display or not.



Preview image

If preview is selected, a small preview image, see Fig. 3-13 *Preview image displayed*, is shown on the touchscreen display when an exposure is performed.

Touch the small image on the display, and the image is shown as a large image.

Fig. 3-13 Preview image displayed



By touching the zoom button +/-, it is possible to zoom in and out, in the image.

Fig. 3-14 Preview image enlarged



The arrows appearing in the image are used to pan in the image.

Fig. 3-15 Zooming In/Out

Themes




Fig. 3-16 Themes

Select a pre-set theme.

Service

The Service tag is meant to be used by the service technician.

Log




Fig. 3-17 Log

The log file shows warnings, errors and events that have occurred in the system. The log file can be filtered to show all information, or just warnings and errors. By selecting *Information*, *Warning* or *Error*, more information concerning the current issue will be shown.

Theory of operation

Overhead tube crane

The log file may be used for troubleshooting.

It is possible for service personnel to delete the log file which can be helpful when fault tracing. The refresh button retrieves the latest events.

Delete log file

Note!

This procedure shall only be performed by service personnel.

When selecting *Delete Log* a four digit access code is required before the log is deleted.




Fig. 3-18 Delete log file

Service – Settings

The Service menu shows system set up and system software versions. A more detailed description can be found in the Service and installation manual.




Fig. 3-19 Service – Settings

Service – Display

| USER SETTINGS | | SERVICE |
|---------------|----------|----------------------------|
| LOG | SETTINGS | DISPLAY |
| Versions | GUI | 1.1 (Oct 7 2013 08:56:26) |
| | ROOTFS | ME Merisc (Poky 8.0 base) |
| | KERNEL | 2.6.37-14321-g1fb710c |
| | U-BOOT | 2010.12-rc2-00004-g71led39 |
| | MLO | X-Loader 1.44 (ME) |
| | Protocol | 01.01 |
| | System | 1.123.1234.1245 |

Fig. 3-20 Service – Display

Information of the display software versions.

3.3.3.7 System Mode

The System has a number of different modes. All modes are described below with their special functionalities and features.

Note that depending on the particular System, different modes and actual configurations are available.

- *Free mode*
- *Auto position mode*
- *Wall flexible mode*
- *Table flexible mode*
- *Film tracking mode*
- *Pendulum mode*, Table
- *Stitching mode* (toward the Table and Wall stand)

Free Mode

General Description

The *Free mode* is the most basic mode in the System.

The mode holds no special features or functionality. It is intended as a manual mode with a lot of freedom in positioning and exposure, e.g. for emergency examinations or examinations with the patient in a wheel chair or lying in a bed. This mode is available in all Systems.

The distance shown in display for *Free mode* is the distance to the floor.

Exposure Validation

Exposure is allowed if the stand is not moving and operating properly (not in an error state).

Theory of operation

Overhead tube crane

Auto Positioning Mode

General Description

The *Auto position mode* functions as the *Free mode* with the added functionality of automatic positioning in the room.

Automatic positions are a number of positions that can be programmed and saved into the System. The stand will upon activation of the servo button, move to the programmed position chosen from the imaging unit.

The mode is intended as a flexible, easy to use mode. The mode can also be used as a parking mode.

The distance (H) shown in display for *Auto position mode* is the distance to the floor.

Exposure Validation

Exposure is allowed if the stand is not moving and operating properly (not in an error state). The chosen position must have been reached successfully.

Wall Flexible Mode

General Description

The *Wall Flexible mode* is intended for examinations toward a wall stand.

The wall stand detector angle is controlled from the APR.

The OTC will upon activation of the servo button move to the programmed position associated with *Wall mode*. The stand will stop at the transport height and wait for a change in position of the wall stand (detector height). When a change in position is detected (the user moves/drives the wall stand up or down) the OTC will move downward and start tracking the position of the detector.

The value is constantly updated as soon as the wall stand/OTC is moved. It is possible for an operator to change the position so the value cannot be calculated or would be incorrect; in those situations the display will clear the field for the value.

No Wait

At the installation of the System it is possible to select, that the OTC shall not wait for the user to move the Wallstand before tracking starts. The OTC will then start the tracking as soon as it reaches its final position.

Exposure Validation

Exposure is allowed if the stand is not moving, operating properly (not in an error state) and the servo button is activated.

Table Flexible Mode

General Description

The *Table flexible mode* is equal to *Auto positioning mode* with functionality added for tracking the height of the Table (compare with Wall flexible mode). The mode is intended for Table examinations.

The stand will upon activation of the servo button, move to the programmed *Table mode* position and start tracking the Table height, thereby keeping the film focus distance constant. The *Film focus distance* shown in the display is the actual distance to the detector. The Table position in the room is set during the installation of the System.

Exposure Validation

Exposure is allowed if the stand is not moving, operating properly (not in an error state) and the servo button is activated. Movement is allowed in X and alpha direction.

Film Tracking Mode

General Description

The *Film Tracking mode* functions as the *Table mode* with added functionality for controlling the position of the detector in one direction. The mode is intended for fast and easy positioning with the X-ray tube always aimed at the center of the detector.

The motorized detector holder will move the detector to the right position. The stand will upon activation of the servo button move to the pre-programmed *Film-tracking position* and start tracking the Table height, thereby keeping the film focus distance constant. The film focus distance shown in the display is the actual distance to the detector. When *Film Tracking mode* is chosen all buttons except X and alpha-brake buttons will be deactivated. The tube stand is operated manually by releasing one or both of the brakes. The position of the detector is changed according to the change in X and or alpha position of the tube. That is the X and alpha positions can be changed independently.

Exposure Validation

Exposure is allowed if the stand is not moving, operating properly (not in an error state), the X-ray tube is aimed to the center of the detector and the servo button is activated.

Theory of operation

Overhead tube crane

Pendulum Mode, Table

General Description

The *Pendulum mode* can be seen as a variation of film tracking.

The X-ray tube is always aimed at the center of the detector. The alpha angle of the tube and the position of the detector changes according to the change in X-position of the tube stand. Also *Pendulum mode* incorporates all the functionality of the more simple Table mode. The mode is intended for fast and easy positioning with the X-ray tube always aimed at the center of the detector.

For moving and controlling the position of the detector, a motorized detector holder is required. The stand will upon activation of the servo button move to the programmed position associated with the *Pendulum mode* and start tracking the Table height, thereby keeping the film focus distance constant.

All table handle bar buttons, except (move left) and (move right) buttons, will be deactivated when the *Pendulum mode* is activated. The X-position of the stand is controlled by these two buttons and thereby also the detector and the alpha angle of the tube.

Exposure Validation

Exposure is allowed if the stand is not moving, operating properly (not in an error state), the X-ray tube is aimed to the center of the detector and the servo button is activated.

Stitching Mode

General Description

Stitching is the process of combining multiple images with overlapping fields of view to produce a larger image.

When imaging long parts of the human body, there is need for an image with extended length. In digital radiography the image size is limited due to the sensitive area of flat-panel detectors. In order to produce a large image, images are assembled from multiple exposures with a small, spatial overlap.

Stitching is possible at both Table and Wallstand.




Fig. 3-21 Stitching, schematic description

Theory of operation

Overhead tube crane

Wallstand/Table Stitching

The user must define the area that shall be captured in the stitching sequence.

When choosing *Stitching mode*, new information will be present on the manoeuver handle; high (left) position, low (right) position, total length and number of exposures. The tube support moves to the pre-defined position for X, Y, Alpha, Beta and Wallstand (detector holder for TableStitching). Z moves to the position received from the Image system (*SID value for TableStitching*).

To start the stitching procedure, press *Start exam*.

The movement for stitching is:

- From head to foot, for booth Wallstand and Table.

The operator sets the size of the stitching area (the composite image) by positioning the light field.

Note!

A patient protection shall always be used at Wallstand examinations when performing stitching examinations.

For detailed information about the stitching operation, see the Operator's Manual.

Exposure Validation

It is only possible to perform an exposure when the System is ready;

- indication light is fixed
- generator is enabled.

The exposure will be blocked and the user needs to activate the start button once more if; a new parameter setting is received, the System is moved out from the start position, a collision when moving, patient position removed, or collimator size is changed.

3.3.3.8 Hospital manual

The hospital manual is reached by activating the *Hospital manual* button for 1 second.

The hospital manual is selectable when a method book has been loaded to the display (performed by a service technician)




Fig. 3-22 Hospital manual button

3.3.3.9 Selection of Technique Mode

There are three different technique modes available that are selected by pushing the *Technique mode selection* button. The selected mode is highlighted and the pop-up window closes automatically.




Fig. 3-23 Technique mode selection

1. AEC mode
2. mAs mode
3. mA/ms mode

Depending on what mode is active, different parameters will be available. Parameters not available for selection will be grayed out, see the *mAs selection* button in Fig. 3-24 *mAs selection button grayed out*, below.

In *AEC mode* the value that will be used as back-up value (ms, mAs or fixed), is indicated with the text *AEC Backup*.

CAUTION!

For avoiding unnecessary radiation, make sure that the AEC back-up values are properly defined.




Fig. 3-24 mAs selection button grayed out

For more detailed information about the different technique modes, please see Operator's Manual for Canon single console CXDI NE.

Theory of operation

Overhead tube crane

Selection of Active AEC Field (AEC Mode Only)

The *AEC field selection* button is available in *AEC mode*.

When selecting the *AEC field* button, a pop-up-window with the different AEC fields according to Fig. 3-25 *AEC field selection*, will appear. The *AEC fields* are activated by a selection in the pop-up window to the right (2). All activated *AEC fields* will be shown in the left picture (1). *AEC fields* are deactivated by selecting them again in the pop-up window (2).




Fig. 3-25 AEC field selection

3.3.3.10 Patient Size

The *Patient size setting* is used for a quick setting of the generator parameters to suit the physique of the patient.

Patient size is adjusted by pressing the *Patient size selection* button. A pop-up window, according to Fig. 3-26 *Patient size selection*, will open and show available patient sizes.




Fig. 3-26 Patient size selection

- | | |
|---------------|-----------|
| 1. Paediatric | 3. Medium |
| 2. Small | 4. Large |

Select the desired *Patient size*. The pop-up window will automatically close shortly after the selection.

Note!

The generator parameters and the collimator settings (field size and filter) will change to the defined values for the new Patient size.

If no generator parameters or collimator settings are defined for the new Patient size (defined in APR), the current values will be kept.

Note!

At the stitching procedure, a change of the Patient size for the first included image in the sequence, will not be kept for the following included images.

Theory of operation

Overhead tube crane

3.3.3.11 Collimator Centering

The collimator light field size can be top or bottom centered against the maximum image area.

This means that the upper border of the collimator light field is aligned with the top of the maximum image area, or that the lower border of the collimator light field is aligned with the bottom of the maximum image area. The stand will automatically move to keep the alignment of the top or bottom of the maximum image area when the collimator light field is increased or decreased.

The functionality of top and bottom centring is only available in *Wall mode* or *Wall Flexible mode*




Fig. 3-27 Top and bottom centering of the collimator light field

The collimator centering is adjusted by pressing the *Collimator centering* button.

A pop-up window according to Fig. 3-28 *Collimator centering selection*, will appear with the alternatives *Top centering*, and *Bottom centering*. Select the desired collimator centering.

The pop-up window will automatically close shortly after the selection, and the light field will adjust accordingly.




Fig. 3-28 Collimator centering selection

3.3.3.12 Servo State Mode




Fig. 3-29 Servo state mode

1. Automatic mode
2. Manual mode

The Servo state can be either *Automatic mode* (1) or *Manual mode* (2).

A pop-up window according to Fig. 3-29 *Servo state mode*, will appear with two alternatives. When the System is in *Manual mode* all movements are allowed and exposure can be performed in any position, also outside the detector.

For further information about *Manual mode*, see corresponding section.

Theory of operation

Overhead tube crane

3.3.3.13 Grid Status

The grid status is indicated in the OTC display and in the Canon NE user interface for guidance. There is also a pop-up window appearing in the Canon NE user interface if grid status needs to be adjusted.

It is possible to perform exposure without adjusting the grid status according to the information in the pop up window. Please note that performing exposure with incorrect grid status might affect the image quality negative.

The grid status is shown in the upper right corner of the Canon NE user interface.

When the correct grid is attached the grid name is written with black letters, see Fig. 3-31.

When a grid is not needed for the examination "Removed" is shown with black letters in the same location, see Fig. 3-31.

When a correction of grid status is needed this is indicated with red text in the Canon interface, see detailed description in Table 3-1 *Grid status*






Fig. 3-30 Canon NE user interface. Grid data displayed.



Fig. 3-31 Canon NE user interface. Grid removed.


Table 3-1 Grid status

| OTC display | Message Canon NE user interface | Description | User Action |
|--|---------------------------------------|---|---|
|  4081 | Removed | INSERT GRID Pop up window in Canon will guide to insert the correct grid defined for the selected protocol. | Insert grid. Grid shall be used for this examination. |
|  4080 | Example: 180cm_10:1_52 lp/cm | REMOVE THE GRID Pop up window in Canon will guide to remove the grid. | Remove the grid. No grid shall be used for this examination. |
|  4082 | Example: 115cm_10:1_52 lp/cm | CHANGE GRID Pop up window in Canon will guide to exchange the grid inserted to the requested grid according to the protocol. | Wrong grid inserted (name of the attached grid shown in Canon). Change to the correct grid. |

Theory of operation

Overhead tube crane

3.3.3.14 Light indication



There is a light indication available around the overhead tube display.

- No light — Between examinations
- Yellow flashing — Action needed by the user or system is moving
- Green flashing — System is ready for exposure
- Green fixed — Preparation (before exposure)
- Yellow fixed — Exposure

3.3.4 Information field

3.3.4.1 Detector information, table

Detector tray out of position



Fig. 3-32 Detector tray out of position

Detector not present



Fig. 3-33 Detector not present in the detector tray/holder

Detector position needs correction



Fig. 3-34 The position of the detector in the detector holder needs to be corrected

3.3.4.2 Detector information, wall stand

Detector tray out of position




Fig. 3-35 Detector tray out of position

Detector not present



Fig. 3-36 Detector not present in the detector tray/holder

Detector position needs correction



Fig. 3-37 The position of the detector in the detector holder needs to be corrected

3.3.4.3 Grid status information

Table

No symbol

The defined grid status (present/not present) in the *Anatomic Protocol* is fulfilled.

Grid not present, table

The user has defined in the *Anatomic Protocol*, that a grid shall be present for the selected examination, but no grid is attached. The user is requested to attach the grid but exposure is still possible.




Fig. 3-38 Grid not present, Table

Grid present, table

The user has defined, in the *Anatomic Protocol*, that a grid shall not be used for the selected examination, but a grid is attached. The user is requested to remove the grid but exposure is still possible.




Fig. 3-39 Grid present, Table

Theory of operation

Overhead tube crane

Wall stand

No symbol

The defined grid status (present/not present) in the *Anatomic Protocol* is fulfilled.

Grid not present, wall stand

The user has defined in the *Anatomic Protocol*, that a grid shall be present for the selected examination, but no grid is attached.




Fig. 3-40 Grid not present, wall stand

Grid present, wall stand

The user has defined, in the *Anatomic Protocol*, that a grid shall not be used for the selected examination, but a grid is attached.




Fig. 3-41 Grid present, wall stand

3.4 Motorized movements

Motorized motions are performed with a PID-controller, using position feedback. An absolute encoder may be used as position transducer. The speed of the movement follows a trapezoid-shaped curve.

The movement is stopped when a collision or a faulty position transducer is detected. A collision is detected if the control error is too large. The control error is defined as the difference between the set point and the actual position. The set point is given by the ramp generation, and the actual position is given from the position transducer. The maximum allowed difference is set by a parameter.

Ramp generation

The set point speed of the ramp is generated as an integration of the ramp acceleration (deceleration); the set point position of the ramp is generated as an integration of the ramp speed. The acceleration, deceleration and the maximum speed of the ramp are set as parameters.

The speed of the ramp is increased until the maximum speed is reached. For this increase in speed, the acceleration parameter used, independent of the direction of the acceleration. This maximum speed is maintained until it is time to start the deceleration. The deceleration point is given by the current speed, the rate of the deceleration and the desired final position of the ramp.

The dynamic calculation of the ramp gives that it is possible to change direction of an active ramp generation. In this case, the ramp will first decelerate, using the deceleration value until zero speed is reached. Then will the acceleration in the other direction, commence.




Fig. 3-42 Speed profile of a motorized movement

PID controller

The control loop is implemented as a PID controller with both acceleration and velocity feed forward. The function of the anti-wind up is to prevent any increase of the integration part, when the driver board limits the output voltage to a value less than the desired output voltage.

Theory of operation

Perform examination

3.5 Perform examination

3.5.1 Select patient

1. Select [Exam] and [Worklist].



Fig. 3-43

2. Sort the list in [Search For Study List] and select patient.

3.5.2 Start examination

1. Select [Start Exam].

Predefined protocols are activated automatically.

Patient data can also be added manually, see Canon Operation Manual.





Fig. 3-44

2. The indication light will be lit on the selected workstation.



Theory of operation

Perform examination

3.5.3 Position the system

1. Activate the servo button to position the system.
The servo button is activated on the console, the remote control, or wall stand hand control.
2. The indication light around the OTC display indicates with a green flashing light that the system reached correct position.




Fig. 3-45 Indication light

3.5.4 Adjust position and collimator for chosen examination and patient

Adjust the position of the OTC, table top or wall stand according to:

- 3.3 Overhead tube crane, Page 57
-
-

The light field should be reduced to the examination area. Adjust the collimator according to:

- 3.3.3 Automatic Collimator Control, Page 58

3.5.5 Exposure



WARNING!

Check that the settings of the SID (Source Image Distance) are accurate before the exposure.



WARNING!

Check that the selected workstation (wall stand, table) is connected and linked properly at the Examination Check screen of the image system before the exposure.



WARNING!

Check that the X-ray tube is set at correct position before the exposure.

CAUTION!

It is the responsibility of the user to ensure that the X-ray field is within the active detector area when exposing.

Note!

The operator is responsible for verifying the exposure parameters before exposure.

Check that the examination conditions are displayed on the image system without failure.

Exposures are done using either the hand control or the prep. and X-ray buttons on the operator console.

Exposure operator console in

- A. normal position
- B. preparation position
- C. exposure position




Fig. 3-46 Exposure operator console

Theory of operation

Perform examination

Exposure operator console:

- A. preparation exposure
- B. exposure position
- C. light indicating exposure




Fig. 3-47 Operator console

3.5.6 Review image

1. If the image is correct, select [End Exam] or continue examination if more images are planned.
2. If the image is not correct, select [Retake].
3. Type reject reason and retake image.

3.5.7 Change work space

1. Select [Protocol].




Fig. 3-48

2. Select detector or workspace.

3624

Theory of operation

Perform examination




Fig. 3-49

3625

3.5.8 Basic exposure error handling

| Exposure not possible | Check | Measure |
|--|--|---|
| The small detector is selected (Green) | Is the small detector in the docking station? | Remove the small detector from the docking station. |
| Table examination | If the table is equipped with a wireless detector and charging the detector in the holder - check if the connector is correctly connected to the detector. | Connect the connector correctly to the wireless detector. |
| Table or wall stand | Is the indication light lit (yellow LED in the control room or green light on the OTC)? | Position the system correct by pressing the servo button on the remote control, the operators console or on the OTC. or Change from Auto to Manual on the OTC display if the patient/light field is in position (and you don't want to reposition the OTC). |
| Table examination | Is the detector in the table detector holder? | Place the detector in the table detector holder, make sure to connect the connector correctly. |
| Wall stand examination | Is the detector in the wall stand detector holder? | Place the detector in the wall stand detector holder, make sure to connect the connector correctly. |

3.6 Mechanical design

3.6.1 Table

The table is designed to cover all kind of examinations and patient types.

It is operational with a load up to 300 kg. The table Z-movement is motorized whereas the floating table top is manually manoeuvrable. The table top brakes are electrical, allowing the operator to control them with a simple press of a button.

Note that the table is customized for the 0072 system.

3.6.2 Wall stand

The up and down movement of the wall stand is both manually and motorized controlled.

The movement is counter-weighted, allowing a manual movement with a very limited applied force. For motorized movement the motor is connected to the shaft with a clutch, this is also to reduce the force for manual movement.

The tilting function is motor driven. With a tilting function the imaging unit can be set in any angles within a range of -20° to 90° .

3.7 Table

3.7.1 Controls

The controls concerning the table are situated at the handlebar, mounted on the table top and/or at the floor, in form of a foot control (option) or a strip-tape switch (option). The control for the detector brake is placed on the right side of the detector holder. The controls are used for enabling and disabling functions concerning the table. These functions are:

- A. Move down
- B. Release/engage brakes of the table top (X- and Y-direction)
- C. Move up
- D. Release/Engage button for bucky movement brake and table indication light
- E. Emergency stop




Fig. 3-50

The table top release key (B) automatically switches on the collimator lamp on activation. The collimator lamp is automatically switched off after a pre-defined time, when the table top release key has been deactivated (released).

Note!

The collimator light is not switched on during vertical movement. The idea is that light is only needed for the positioning of the patient and/or the radiation beam.

3.7.2 Motorized Imaging Unit Movement

The imaging unit can be moved in X direction motorized. The motorized movement is manoeuvred from the table hand control, see Fig. 1-4 *Table overview*. The function can synchronize the imaging unit and follow the movement of the ceiling unit.

3.7.2.1 Synchronization Function

In Auto position mode and in Table flexible mode, the detector holder may be moved in X-direction using the motor (via the table handle or manually by activating the green button at the detector holder). There is no synchronization between the tube and the table detector.

In Film tracking and Pendulum mode the detector holder may be moved manually in X-direction. If this is done, the servo button will be deactivated and exposure is no longer possible. To return to an activated servo button, the detector holder shall be moved to the correct position. The correct position will be indicated by the lightning of the green detector holder button.

Note! —————

It is the user's responsibility to verify that the detector is in position at exposure.

3.7.3 Motorized imaging unit movement

The table imaging unit can be moved in X-direction motorized. The motorized movement is manoeuvred from the table hand control. The function can synchronize the imaging unit and follow the movement of the OTC.

3.7.3.1 Synchronization function

A mechanical solution enables the detector holder to be moved manually. The synchronization function finds the detector holder, moves to end position and lights up the green indicator. The imaging unit will now follow the movement of the OTC during the synchronization.

If the user moves the imaging unit (motorized) from the hand control, the synchronization will be performed as described above, also when auto position is activated in following modes:

- *Pendel* (pendulum)
- *Film tracking*

For the modes *Table flexible* and *Auto position* the system will not synchronize the imaging unit, if the detector holder is not in its cradle. The user can select if the imaging unit should synchronize and follow the movement of the OTC or not, by moving the imaging unit manually into, or from the cradle.

Note! —————

It is the user's responsibility to verify that the imaging unit is in position when exposing.

3.7.3.2 Synchronization function

In Auto position mode and in Table flexible mode, the detector holder may be moved in X-direction using the motor (via the table handle or manually by activating the green button at the detector holder). There is no synchronization between the tube and the table detector.

In Film tracking and Pendulum mode the detector holder may be moved manually in X-direction. If this is done, the servo button will be deactivated and exposure is no longer possible. To return to an activated servo button, the detector holder shall be moved to the correct position. The correct position will be indicated by the lightning of the green detector holder button.

Note!

It is the user's responsibility to verify that the detector is in position at exposure.

3.8 Wall stand

3.8.1 Motorized movement




Fig. 3-51

The wall stand is controlled by the wall stand hand control unit and foot pedal.

A Emergency stop

B Hand control:

For adjustment of the automatic collimator, vertical movement of the detector, rotation of the detector and activation of pendulum mode.

The collimator lamp on the hand control (B) is activated when motorized or manual movement is performed, if *Wall flexible mode* is selected, see Fig. 3-4 *Hand control*.

The Break release button (E), see fig Fig. 3-4 *Hand control*, automatically lights the collimator lamp on activation, if *Wall flexible mode* is selected and the detector is moved. The collimator is automatically switched off after a pre-defined time when the Break release button (E) has been deactivated (released).

The Detector up/down button (G), see fig Fig. 3-4 *Hand control*, is also used for enabling movement of the OTC (Z-direction). On activation of the Break release button (E), an automatic movement of the OTC is allowed. The automatic movement is used for tracking the movement of the detector and to synchronize (align) the X-ray tube and the imaging unit.

At auto-positioning the wall stand, the wall stand detector unit will move into a basic position.

Hand control





Fig. 3-52 Hand control




Up/down

- Button G, Motorized
OTC tracking wall stand detector when auto-position active
- Button E, Manual

Theory of operation


Wall stand



Pendulum mode wall stand

- Button F

The OTC performs a pendulum movement in order to find correct angulation of the central X-ray



Tilting -20° to 90°

- Button H, Motorized Tilt

OTC tracking wall stand detector when auto-position active

- Button E, Manual

Note!

Armrest has to be removed to allow tilt movement.

3.9 Remote control (option)



WARNING!

The System must always be supervised when activated.

Note!

The remote control shall only be used inside the examination room.

Note!

Always mark up the remote controls with, for example, the room number or the system number. Use the enclosed labels to distinguish different system remotes, from each other.




Fig. 3-53 Remote control, front and back

Front

- 1 Servo button – (yellow)
- 2 Indication diode (green)
- 3 Tube up
- 4 Switch On/Off Collimator light

Back

- 5 Fastening clip
- 6 On/Off switch
- 7 Battery changing slot

Servo button

The servo button is yellow with a little peg, making it easy to recognize the button. When activating the yellow servo button, the OTC moves to auto-position.

Theory of operation

Remote control (option)

Indication diode

The diode shows a green light, when the remote control button is activated. When the diode turns red, the batteries shall be exchanged.

Tube up

When the *Tube up* button is activated, the OTC will move upward. The movement will stop at button is release or when the highest possible position is reached.

Switch On/Off collimator light

The button turns the X-ray field illumination and linear light localizer on/off.

Automatic switch-off via a time switch.

On/Off switch

There is an On/Off switch for the remote control, at the back of the remote control. When the control is switched off, all buttons are disabled.

Battery changing slot

When the indication diode lights red, changing of battery is needed.

The remote control uses 2 pcs of LR03, 1.5V, AAA batteries. To change batteries, loosen the 3 screws and open the slot at the back of the remote control.

Note!

The batteries shall be recycled.

4 Installation

Before starting to install the Image system, install the 0072 Subsystem.

4.1 Installation of Subsystem 0072

4.1.1 Software installation

The software is installed at manufacture.

4.1.2 Unloading

CAUTION! —————
*Always be at least two persons cooperating when unloading the equipment.
Before unloading the System, secure a proper equipment transfer route.*

4.1.3 General

This chapter describes how to unpack and install the product.

After completing the installation, fill in the Installation Report and send it back to Arcoma. If not, the time of guarantee will be considerably reduced.

Note! —————
Surrounding equipment, not supplied by the manufacturer, shall comply to the standard IEC 60601-1-2 regarding electromagnetic compatibility.

Note! —————
It is the responsibility of the one who combines the Product with other equipment, to secure that the use of the combination is in compliance with MDD or other directives that may be mandatory on the market in question.

Note! —————
Refer to the Product Planning Guide for information about installation location, space and transfer.

4.1.4 Precautions



WARNING! —————
Do not switch on the power, before the cabling is checked for damage and the System completely installed and connected according to the Installation Chapter.

Installation

Installation of Subsystem 0072



WARNING!

Electrical shock. Covers removed, exposure to electrical shock.



WARNING!

Remaining energy may exist when the equipment is switched off. Always wait at least 15 seconds before working on the System.

Note!

For a safe and reliable function of the System, it is crucial to follow the installation instructions regarding the insulation.

Note!

The insulation kit is designed to isolate System components, e.g. System cabinet, table, wall stand and ceiling suspended unit, from the hospital building.

The insulation kit will prevent stray currents from reaching the System e.g. via screw attachments. Stray currents can be present e.g. in reinforcement bars or in water pipes in a building. These currents can be of several hundred amperes and can affect the leakage current from the System to the patient and thereby the safety for patient and user. Stray currents in the building shall be regarded as a failure in the building but the insulation kit provides an extra safety barrier.

The insulation kit will also prevent unwanted ground loops due to e.g. electrical contact through the wall or floor lead X-ray shielding via screw attachments of the System components.

4.1.5 Installation Preparations

4.1.5.1 Tools Required

Standard Tools

- Standard hand tools and service tools
- Tools for unpacking
- Dynamometer (400N)
- Torque wrench (47Nm)
- Multimeter
- Dose probe
- Digital spirit level
- Rotation laser
- Allen keys (metric)
- Steel straight
- Hammer drill
- Lift
- Leakage current tester for measurements according to IEC 60601-1
- Assorted cable ties
- Protective ground wire tester for measurements according to IEC 60601-1
- Loctite 243
- Tape
- Service PC
- Service cable (See chapter)
- Standard serial cable
- Working gloves

4.1.6 Cable marking

All cables and electronics are marked in accordance with the following;

- 1.xx — OTC
- 2.xx — Table
- 3.xx — Wall stand
- 4.xx — Cabinet
- 5. xx Control Room

Installation

Installation of Subsystem 0072

4.1.7 Shipping/receiving

4.1.7.1 Receiving

Verify that the site is ready for installation.

Remove the crate's top and sides. Inspect the equipment for transport damage immediately upon arrival at its destination. If there is any damage, save the packing material and notify the transport company at once.

To determine whether the complete shipment has arrived, compare items received to those listed on the shippers packing list and the Manufacturer's order.

Any discrepancies should be reported to:

ARCOMA AB
Annavägen 1
SE-352 46 Växjö
Sweden
Phone +46 (0)470 70 69 70

4.1.7.2 Storage precautions

CAUTION!

Store the machine in a place where the machine will not be exposed to water.

CAUTION!

Store the machine in a place where atmospheric pressure, temperature, humidity, ventilation, sunlight, dust, salt, or air containing sulphur will not adversely affect the machine.

CAUTION!

Avoid placing on angled surfaces, and subjecting it to vibration, shock (including during transportation) and other factors that may impair stability.

4.1.7.3 Return authorizations

Goods returned for credit, exchange or repair will not be accepted by the Manufacturer, unless written authorization has been issued.

Contact Manufacturer at the above address for return authorizations.

4.1.8 Mechanical installation of OTC

4.1.8.1 Installation Rails (Unistrut)

The described installation is performed with Unistruts, but naturally there are other methods.

Check that necessary fixation points are present on the ceiling.

Use Unistrut rails or similar, installed with a distance of 800 mm and 2900-3100 mm above the floor. The Unistrut rails should be parallel with the long side of the patient Table. Vertical alignment shall be within +/- 1 mm. For more information, see Planning guide.


Every single attachment point must be able to carry a load of at least 400 kg. The OTC with 4x4 m rails must have at least 10 brackets in the ceiling. All attachment points together, must be able to carry at least 2000 kg. +/- 1 mm deformation is allowed.

To be able to install the cable carriage, see *Installing the Cable Carriages*, Page 120. The distance between the wall and the ceiling rail Y must be minimum 120 mm.

To install the ceiling wagon, see section 4.1.8.7 *Ceiling Wagon*, Page 128, the distance between the wall and the ceiling rail X must be at least 650 mm

Installation

Installation of Subsystem 0072



*625mm + lid and screwhead

Fig. 4-1 Example for 4 m traverse

The length of the traverse rails X, outside the ceiling rails Y must not exceed 600 mm, see Fig. 4-1 *Example for 4 m traverse*. If the traverse rails are more than 4000 mm, a third rail must be used in the middle, for increased stability.

| X-rail (mm) | Y-rail (mm) | Unistrut rails | Number of brackets | Number of Y-rails |
|-------------|-------------|----------------|--------------------|-------------------|
| 3000 | 3000 | 4 | 8 | 2 |
| 3000 | 4000 | 5 | 10 | 2 |
| 3000 | 5000 | 7 | 14 | 2 |
| 3000 | 6000 | 8 | 16 | 2 |
| | | | | |
| 4000 | 3000 | 4 | 8 | 2 |
| 4000 | 4000 | 5 | 10 | 2 |
| 4000 | 5000 | 7 | 14 | 2 |
| 4000 | 6000 | 8 | 16 | 2 |
| | | | | |
| 5000 | 3000 | 4 | 12 | 3 |
| 5000 | 4000 | 5 | 15 | 3 |
| 5000 | 5000 | 7 | 21 | 3 |
| 5000 | 6000 | 8 | 24 | 3 |

Insulation

For a safe and reliable function of the System it is crucial to follow the Installation instructions regarding insulation.

Note!

The insulation kit is designed to isolate System components, e.g. System cabinet, table, wall stand and ceiling suspended unit, from the hospital building.

The insulation kit will prevent stray currents from reaching the System e.g. via screw attachments. Stray currents can be present e.g. in reinforcement bars or in water pipes in a building. These currents can be of several hundred amperes and can affect the leakage current from the System to the patient and thereby the safety for patient and user. Stray currents in the building shall be regarded as a failure in the building but the insulation kit provides an extra safety barrier.

The insulation kit will also prevent unwanted ground loops due to e.g. electrical contact through the wall, or floor lead X-ray shielding via screw attachments of the System components.

Installation

Installation of Subsystem 0072

4.1.8.2 Traverse




Fig. 4-2 Traverse 4x4 m

- | | |
|------------------------------------|--------------------------------------|
| 1. Beam | 4. Tooth belt profile |
| 2. End cover, large (0070-001-021) | 5. Cover, electronics (0070-063-247) |
| 3. Cable carriage (0070-099-001) | 6. Tooth belt |

4.1.8.3 Tooth Belt

- Install the tooth belt profile on the ceiling rail (Y) and traverse rail (X), see figures below. The screws and nuts are pre-assembled at the tooth belt profile.




Fig. 4-3 Tooth belt profile

- | | |
|---|--------------------------------------|
| 1. Tooth belt, included in rail package | 3. Ceiling rail Y or Traverse rail X |
| 2. Installation nut M4 | |

- Loosen the screws.
 - Slide the rail into ceiling rail Y and traverse rail X.
 - Tighten the screws again.
- Use Loctite 243 when fastening the screws on the tooth belt profile.
- For distances, see Fig. 4-4 *Mounting distance*




Fig. 4-4 Mounting distance

Installation

Installation of Subsystem 0072

4.1.8.4 Ceiling Rails Y




Fig. 4-5 Approximate position cable channel assembly

Start by opening the pack box CS Box 1.

Take the ceiling rails Y, 1 with tooth belt and the other(s) without tooth belt (standard 4000 mm), and install the fixation blocks at the same distance as the Unistrut rails. Use the M12x30B and the installation nut M12.

For the position of the ceiling rail with tooth belt, see Fig. 4-5 *Approximate position cable channel assembly*

Install the insulation plates and cases on the fixation blocks.




Fig. 4-6

- | | |
|----------------------|-------------------------|
| 1. Unistrut rail | 4. Installation nut M12 |
| 2. MF6S 10.9 M12X30B | 5. Ceiling rail (Y) |
| 3. Fixation blocks | |




Fig. 4-7

- | | |
|-------------------|---------------------|
| 1. Fixation block | 2. Ceiling rail (Y) |
|-------------------|---------------------|

Note!

For location of the tooth belts, see Fig. 4-2 Traverse 4x4 m.

Installation

Installation of Subsystem 0072

Lift up the ceiling rails Y and bolt them into the ceiling attachment points.




Fig. 4-8

- | | |
|------------------------------|-----------------------------|
| 1. Unistrut rail | 5. Isolation case, traverse |
| 2. Spring channel nut | 6. BRB FZB |
| 3. Isolation plate, traverse | 7. MC6LS M10x30A |
| 4. Fixation block | |

To bolt the ceiling rails Y into the Unistrut or similar, use M10 low-head bolts and a suitable (M10) washer, between the bolts and the insulation housing.

Note!

It is important to use low-head bolts for this installation.

Loctite 243 on the bolts is required. The torque on the bolts, is 47 Nm. The ceiling rails Y have to be parallel ± 2 mm.

Alignment of Ceiling Rails Y

The ceiling rails Y must be horizontal, measure with a spirit level. If necessary, adjust with the shims kit 1 mm or 2 mm.




Fig. 4-9

Installation

Installation of Subsystem 0072

Installing the Cable Carriages

- Open the pack boxes CS Box 4, and CS Box 2.
- Decide from what side to slide the distance plates.
- Mount the end stop and cover at the opposite side.




Fig. 4-10

- | | |
|--|-------------------------------------|
| 1. Ceiling rail (Y) | 5. Contact washer KB 5.1x10.2 |
| 2. M6M M10 | 6. K6S M10x40 A |
| 3. End cover, small, ceiling rail (0070–001–020) | 7. End stop, rubber (0070–001–022) |
| 4. K6S 4.6 M5X10 A | 8. Anchoring nut M12 (0070–001–016) |

Install as many cable carriages as needed in the ceiling rail Y.




Fig. 4-11 Cable carriage




Fig. 4-12 Installations at Ceiling Rails Y

1. End stops
2. Cable carriages
3. Distance plates

Installation

Installation of Subsystem 0072

Distance Plates

Note!

Install the M10x75 bolts, before rolling in the distance plates all the way.

The tooth belt obstructs installation of the bolts afterward.

Roll in the distance plates into each ceiling rail Y, see Fig. 4-13 *Distance plates*.




Fig. 4-13 Distance plates

End Stops and Covers, Ceiling Rails Y

Mount the resting end stops and covers.




Fig. 4-14 Overview rubber/adjustable end stop

- | | |
|---|---------------------------------|
| 1. Rubber end stop + K6S bolt and nut, (4 pcs) | 3. Adjustable end stop, (2 pcs) |
| 2. K6 bolt and nut, (4 pcs) | |

Protective Earth

Connect the protective earth from the generator to each ceiling rail Y.

Installation of Subsystem 0072

4.1.8.5 Traverse Rail X

Lift up the traverse rails X and bolt them into the distance plate, see figure below. See also Fig. 4-1 *Example for 4 m traverse* for measurements.

Select the tooth-belt rail and position it in accordance with Fig. 4-2 *Traverse 4x4 m*.




Fig. 4-15

Pack box CS Box 2 and 4.

- | | |
|---|--------------------|
| 1. Installation nut M10, 0070-001-034 | 4. 0070-001-044 |
| 2. Traverse rails X | 5. 0070-001-242 |
| 3. Distance plate, 0070-001-223, CS Box 4 | 6. MF6S M5x25 (2x) |

Put 3 installation nuts M10 into each rail. Attach by 2 pcs of M10x75 and 1 pc of M10x25.

Side Position Bearings

- Install the side position bearings on the distance plates. See Fig. 4-15 .
- Run the traverse rails X all the way and make sure it runs smoothly.
- Check that the rails are parallel and that the wheels are centered in the ceiling rails Y. Adjust if necessary.

4.1.8.6 Electrical Plate Y and Drive Unit Y

Unpack the electrical plate.

Install the electrical plate Y and drive unit Y, by using the 3 pcs of M5x8A screws and contact washers.

Note!

The drive unit, (pos. 1) must be mounted at the right side of the traverse, see Fig. 4-16 Mounting position of drive unit (1).




Fig. 4-16 Mounting position of drive unit (1)

Installation

Installation of Subsystem 0072

- Assemble the electrical plate Y.
- Unscrew the assembling screws from the support wheel bracket.

MC6S m5x8 + KB 5.1x10.2




Fig. 4-17 Assembling the electrical plate

- Disassemble the support wheel bracket from the braking unit.
- Assemble the drive unit with 2 screws — do not tighten the screws.

Drive unit MC6S M6x60 + BRB 6.4x12.5x1.6




Fig. 4-18

- Reassemble the support wheel bracket at the braking unit.
- Adjust by loosening the nuts at the eccentric wheel axles. Turn the eccentric wheel axles, with a screw driver, until there is no play and the bearings are not possible to turn.

MC6S M6x20

Adjusting eccentric wheel axle




Fig. 4-19

- Connect the drive unit to the electrical plate Y, see Fig. 4-22 .

Note!

As soon as the drive unit is installed, the traverse rail (X) is locked in its position. The traverse cannot be moved until the power is supplied and the brake is released.

Installation

Installation of Subsystem 0072

4.1.8.7 Ceiling Wagon

Check room layout for the correct orientation of the ceiling wagon. There should be enough space in accordance with Fig. 4-1 *Example for 4 m traverse*.

Decide from which side the ceiling wagon shall be inserted. Mount end stops at the opposite side of the X traverses.

End stops and Covers, Traverse Rails X

Install the end stops and the cover plate onto the traverse rails X.




Fig. 4-20

1. Mount the adjustable end stops.
2. Mount the non-adjustable end stops.
3. Mount the end plates.

Install the Ceiling Wagon

Lift up the ceiling wagon and roll it into the traverse rails X, see Fig. 4-21 .




Fig. 4-21

*630 mm with bracket removed

If this distance cannot be obtained;

1. Remove the 4 wheels and roll them into the traverse rails X.
2. Lift the ceiling wagon into position.
3. Remount the wheels.

Installation

Installation of Subsystem 0072

Side Position Bearings

Install the side position bearings on the ceiling wagon.

Run the traverse rails X all the way and make sure it runs smoothly.

Check that the rails are parallel and that the wheels are centered in the ceiling rails Y. Adjust if necessary.

Cable Hose

Install the loose end of the cable hose, referring to the room planning. Preferred position is close to the parking position.

Move the ceiling wagon around and check that the cables are not caught into something in the room. The cable hose may be shortened to avoid from hanging down too much.

Drive Unit

Lower the electronic plate.

Install the drive unit X and connect the cables.

As soon as the drive unit is installed, the traverse rail (X) is locked in its position. The traverse cannot be moved until the power is supplied and the brake is released.

4.1.8.8 Cable support

1.YJ01. 1.YCan and 1.YPE

Connect to electrical plate 1.Y.




Fig. 4-22

Connect the cables on the drive unit Y.

1. Cable 1.YJ01 1.YJ01
2. Cable 1.YPE 1.YPE
3. Cable 1.YJ01 1.YCB01-J6

Place redundant cabling under the cover.

Installation

Installation of Subsystem 0072

4.1.8.9 Cable channel

Measurements




Fig. 4-23 Measurements for rails, 4x4 m

The outer cable attachment shall be close to the Y-beam.

Note!

The measurement 2113 mm, is used to get the same cable length at both sides.

For a 5 m rail, this measurement will be 2613 mm.

Mounting the cable channel

Start by deciding at which side the cable hose shall leave the cable channel.




Fig. 4-24

Installation

Installation of Subsystem 0072

Mount the channel brackets, the end plates and the supporting angles at the cable channel ends, in accordance with the numbers in Fig. 4-25 *Cable channel bracket, left*.




Fig. 4-25 Cable channel bracket, left

Mounting order:

1. End cover, cable channel (0073-600-034)
2. Cable channel bracket, intermediate (0170-600-009)
3. Angle, cable channel (0170-002-148)




Fig. 4-26 Cable channel bracket, right




Fig. 4-27 Right hanging

Installation

Installation of Subsystem 0072




Fig. 4-28 Left hanging

- | | |
|--|--|
| 1. Cable holder, part A(0070–600–045A) | 10. Cable channel, intermediate (0170–600–009) |
| 2. Cable holder, part B (0070–600–045B) | 11. Cable ties |
| 3. Wagon, cable suspension (0073–003–018) | 12. Rubber rope (52–101_300mm) |
| 4. Cable channel (0073–600–028) | 13. Rollco SXTE30–2320 (53–237) |
| 5. Cable channel, for 4 m (0073–600–029) | 14. Rollco LSWL30_wagon (53–238) |
| 6. End cover, cable channel (0073–600–034) | 15. Plastic screw KT-PT 5x25mm (54–430) |
| 7. Support, cable channel (0073–600–042) | 16. BRB FZB (BRB 1.5x21x2) |
| 8. Cable channel, angle (0170–002–148) | 17. BRB FZB 5.3x15x2 (BRB 5.5x19NB) |
| 9. Cable channel bracket hose (0170–600–007) | 18. SRKB FZB 5.5x19 (BRB 5.5x19NB) |
| | 19. K6S 10.9 FZB 4x10 (K6S M4x10 A) |
| | 20. K6S 10.9 FZB 4x6 (K6S M4x6 A) |
| | 21. K6S 10.9 FZB 4x8 (K6S M4x8 A) |
| | 22. K6S 10.9 FZB 4x10 (K6S M4x10 A) |
| | 23. M6M-8 FZB 4 (M6M M4) |
| | 24. MC6S 8.8 FZB 5x12 (MC6S M5x12 A) |
| | 25. MC6S 8.8 FZB 5x20 (MC6S M5x20 A) |

The length of the cable channel is adjusted according to Fig. 4-23 *Measurements for rails, 4x4 m*. This is done by pushing one part of the channel into the other. It shall be locked in a later step of the mounting.

Cable Into channel

Put the cable into the channel, and haul it through the holes in the cable channel brackets. Assemble the hose plate to the cable channel bracket, see Fig. 4-29 . Join the hose to the hose plate.




Fig. 4-29

Stabilizing plates

Mount the stabilizing plates at the outside of the cable channel brackets.

Note!

The cable must be put inside the channel, before the stabilizing plates are mounted.

Installation

Installation of Subsystem 0072




Fig. 4-30 Intermediate cable channel bracket

Note!

The channel bracket at the channel extension, shall have 2 angles mounted.




Fig. 4-31

CAUTION!

Remember to assemble the nut and washer at the upper side of the stabilizing plate, in accordance with the picture above.

Sliding rail, cable wagon and cable suspension

Fasten the sliding rail for the cable holder, at the middle of the cable channel, lower side.

Mount the cable wagon and the cable suspension.

See Fig. 4-27 *Right hanging*, view G.

Note!

Item number 17 and 24 are used as end stops for the carriage. See Fig. 4-28 Left hanging.

4.1.8.10 Wall attachment for cable (option)

Move the traverse rail X to its end position so the cable channel, mounted on the traverse rail X, will point toward the middle of the ceiling rail Y.

If the OTC is not moved to its end position, the hose may not be long enough when the OTC is positioning after installation.

Measure the distance and mount the wall attachment on half this distance, and at the same height as the ceiling rails Y.

Shorten the hose if necessary, after mounting the wall attachment.

4.1.8.11 X-ray Tube

The X-ray tube is pre-installed from the Manufacturer. For more information on mechanical installation and adjustment refer to X-ray tube Manufacturing documentation.

Installation

Installation of Subsystem 0072

4.1.9 Mechanical installation of system cabinet

Place the system cabinet in a corner of the room, see Planning guide and room layout for further information. The cabinet corner (1), see figure, must be placed in a corner of the room.

Depending on the installation of the cables from the OTC, table and wall stand, one of the cable outlets (2) is used, see Fig. 4-32 .




Fig. 4-32

- Remove one of the cable outlet covers(2). If the upper outlet is used, assure that the outlet is covered by the cable run. Otherwise objects may fall into the cabinet and down to the generator.
- The borders of the outlet have to be covered with the edge protection.




Fig. 4-33 Alternative 1

- The cables must be covered with a cable channel. The cable outlet shall be completely covered by the cable channel.
- The cable channel must not be possible to open without a tool.
- The cables have to be secured with a cable clamp or a suitable strain relief.




Fig. 4-34 Alternative 2

Installation

Installation of Subsystem 0072

4.1.9.1 Remove covers, cabinet

Remove the covers:




Fig. 4-35 Remove cabinet covers

4.1.10 Electrical installation

4.1.10.1 General



WARNING!

To avoid risk of electric shock, this equipment must only be connected to a supply mains with protective earth.



WARNING!

All components shall be connected to the same earth connector on the System.

Note!

A disconnecting device from the mains shall be incorporated external to the equipment according to the national wiring rules.

Interfacing

to the following standards and local regulations.

- IEC 60601-1
- IEC 60601-1-2
- IEC 60601-2-54
- MDD 93/42/EEC


4.1.10.2 Cable path

1. Remove screw (A) according to Table 4-1 *Cable paths*.
2. Lift up the electrical plate 4.4 and secure it with screw (A) in position (B).

CAUTION!

Tie the cables carefully to the frame. Otherwise there is a cable squeezing hazard.

Table 4-1 Cable paths



- Cable path number 1 — to the generator.
- Cable path number 2 — to the electrical plate 4.2.
- Cable path number 3 — to the electrical plate 4.4.
- Cable path number 4 — to the electrical plate 4.5.

Installation

Installation of Subsystem 0072


4.1.10.3 Electrical Installation of OTC

Note!

The installation cables from the OTC must be installed covered. They shall not be placed on the floor.

Lubricate the HSP connectors generously with silicone oil. Use the silicone gaskets.

Wiring to generator, is made according to path 1, Table 4-1 *Cable paths*.



Wiring to electrical plate 4.2 is made in accordance with cable path 2, Table 4-1 *Cable paths*.

Installation

Installation of Subsystem 0072




Fig. 4-36 Electrical plate 4.2

1. 1XPE

2. 1.1MAINS – 17, 18




Fig. 4-37 Connecting the OTC

1. 1.EMRE01 & 1.EMSTOP – J18

4. 1.Collsig – J2/J4

2. 1.1CAN – P1

5. 1.3DSP01 – 4.4CB800_01 – J0

3. 1.1Service – J30

Installation

Installation of Subsystem 0072

4.1.11 Mechanical Installation of wall stand



WARNING!

Whenever any item is removed from the wall stand, e.g. the detector holder, the wall stand will become highly unbalanced.

Whenever the brake is released, part of the wall stand will move upward and can cause injury.

Make sure that the operation will be performed by personnel who are trained in the use of the equipment.

4.1.11.1 Orientation of wall stand

Before placing the wall stand on the floor, check for enough free space around the device to allow free movement. See Planning Guide for further information of required space around the wall stand and the position in the room.




Fig. 4-38

The wall stand center must be aligned with the tube center.

4.1.11.2 Unload wall stand

Transport Protection of the wall stand



WARNING!

Whenever any item is removed from the wall stand, e.g. detector holder, it will become highly unbalanced. Whenever the brake is released it will move upward and can cause injury. Make sure that the operation will be done by personnel who are trained in the use of the equipment.

Unloading



WARNING!

When the wall stand is not bolted to the floor, the wall stand is unstable and front-heavy and may fall down. When you get the wall stand upright, make sure to bolt the wall stand to the floor.

Note!

Packages has "Up" and "Down" marks on the top and bottom sides of the wall stand respectively.

1. Remove the package band from the package.
2. Remove all the mounting screws on the top and bottom of the crate sides.
3. Remove the top crate, then the crate sides as a set.
4. Remove the screws from two cross-ties, securing the wall stand.




Fig. 4-39 Removing cross-ties

CAUTION!

Do not hold the wall stand by the base when lifting it up.

Note!

*Do **not** lift the wall stand from the bottom.*

Installation

Installation of Subsystem 0072




Fig. 4-40 Remove packaging




Fig. 4-41 Lift the wall stand

9. Remove the mounting band (4) (see Fig. 4-40 *Remove packaging*), at the foot end (5).
10. Remove the mounting beam (2).
11. Position the wall stand in its dedicated position.




Fig. 4-42 Transport lock

5. Remove the packaging.
6. Loosen the screws (3) fastening the mounting beam (2) to the wooden packaging.

Note!

Do NOT remove the mounting band (4) at the foot end.

Note!

The weight of the wall stand is approximately 80 kg. It has to be lifted by at least 2 persons. Use gloves.

7. Lift the wall stand (1) slightly at the head end and push it so that the foot end (5) is positioned outside the packaging.
Use a floor protection/plate (6), if necessary.
8. Continue to raise the wall stand (1) using the mounting beam (2) off the pallet to an upright position.

12. Remove transport locks, see Fig. 4-42 *Transport lock*.

13. Mount the top crate, front plate, and lower and back protections plates.




Fig. 4-43 Temporarily attachment

- | | |
|----------------------|-------------------------|
| 1. Bolt | 4. Bottom plate |
| 2. Insulation washer | 5. Insulation plate |
| 3. Insulation case | 6. Expanders (enclosed) |
14. Mount the insulation plate (5) between the plate and the floor.
15. Temporarily attach the stand to the floor, with 1 bolt (comprising parts 1, 2, 3, 6) at the floor. Making it possible to readjust the parallelism to the Ceiling stand.
16. Drill 1 hole (C) in accordance with Fig. 4-43 *Temporarily attachment*.
The 3 remaining holes shall be drilled after the adjustment.

Installation

Installation of Subsystem 0072

4.1.12 Electrical Installation of wall stand

4.1.12.1 Connect wall stand

Note!

The installation cables from the wall stand must be installed covered. They shall not be placed on the floor.

Wiring shall be done according to cable path 2, see Table 4-1 *Cable paths*.




Fig. 4-44 Connecting the wall stand

1. 3.0PE01
2. 3.0MAINS – 19, 20

Wiring shall be done according to cable path 3, see Table 4-1 *Cable paths*.




Fig. 4-45 Connecting the wall stand

1. 3.0SIG01 — J9–J20
2. 3.0COLL01 — J26
3. 3.0CAN01 — 4.4BCM01–4

Installation

Installation of Subsystem 0072

Connecting the wall stand AEC

Wiring shall be done according to cable path 3, see Table 4-1 *Cable paths*.




Fig. 4-46 Connecting wall stand AEC

1. 3.DAID01 – ION chamber
2. 3.DB3C01 (option) (channel 1) – Solid state chamber
3. 3.DI/F01 Connect to Generator AUX-PWD
 - A1 J2–7
 - A2 J2–8
 - B1 J2–5
 - B2 J2–6

Option, the cable is only present if a fix detector or a detector with charging is installed at the wall stand.

4.1.13 Mechanical installation of table

4.1.13.1 Orientation of the table

Before placing the table on the floor, check for enough free space around the table to allow free movement. See Planning Guide for further information of required space around the table. Place the table on the floor according to the room layout.

It is possible that a cable duct is already made in the floor where the table shall be placed.



WARNING!

Squeezing hazard! When the Table is lifted, the columns will bend toward the middle of the Table. Two persons must keep the columns vertical.




Fig. 4-47

Installation

Installation of Subsystem 0072

4.1.13.2 Unload table

Slide/lift off the table from the pallet by grabbing underneath the table frame.




Fig. 4-48

Note! _____

Do not tilt the table when unloading.

Note! _____

Make sure there is enough free space to slide on and off the table top, see Planning guide.

Note! _____

Do not place anything at the table when it is not attached.

Place the table where intended in the room.

Continue the mechanical installation of the table after the alignment of the table is ready. See 4.6.5 *Horizontal alignment of table*, Page 199.

Transport protection of the detector

Remove the transport protection of the detector according to Fig. 4-49 *Transportation holder*. There is one on each side of the detector.




Fig. 4-49 Transportation holder

1373-01

Installation

Installation of Subsystem 0072

4.1.14 Electrical Installation of table

4.1.14.1 Connect table

Note!

The cables from the table to the system cabinet, must be installed covered.

They shall not be placed on the floor.

Connect the table according to figures.

Wiring shall be done according to cable path 2, see Table 4-1 *Cable paths*.




Fig. 4-50 Connecting the table

1. 2.0PE
2. 2.0MAINS – 19, 20

Wiring shall be done according to cable path 3, see Table 4-1 *Cable paths*.




Fig. 4-51 Connecting the table

1. 2.0IND01 — J8
2. 2.0I/O01 — J17
3. 2.0RE01 / 2.0EM01 — J19
4. 2.0COLL01 — J27
5. 2.0CAN01 — J28P4

Installation

Installation of Subsystem 0072

Connecting the table AEC

Wiring shall be done according to cable path 3, see Table 4-1 *Cable paths*.

Wiring to the generator is made according to cable path 1.




Fig. 4-52

1. 2.0SIG03 (channel 2) (standard) – ION chamber
2. 2.DB3C01 (option) – Solid state chamber
3. 2.DI/F01 Connect to Generator AUX-PWD
A1 J2–7

A2 J2–8

B1 J4–5

B2 J4–6

Option, the cable is only present if a fix detector or a detector with charging is installed at the table.

Foot Control X/Y/Z or Foot Control X/Y Separate (option)- Cable 2.4J01 or 2.4J02

Install the foot control and connect the cable 2.4J01 or 2.4J02 according to Fig. 4-53 . Also see System Block Diagram for the Table, 8.1.6.1 *Table 2 columns*.




Fig. 4-53

1. Cable 2.4J01

2. Cable 2.4J02

4.1.15 Connect options

4.1.15.1 Foot control, wireless (option)

CAUTION!

Make sure that the correct control is activated, as there is one foot control for the table and one for the wall stand.

The table and the wall stand with motorized vertical movement, can be manoeuvred from the foot control.

The wireless foot control is an optional control unit for table and wall stand.

Consider the working area when manoeuvred.

Installation

Installation of Subsystem 0072








Fig. 4-54 Wireless foot control

1. Z movement down 
2. Z movement up 
3. Release pedal:
 Unlocks wall stand detector brake. Manual movement is possible.
 Unlocks table top. Manual movement is possible, table top is floating.

How to manoeuver

1. Press pedal to move downward.
2. Press pedal to move upward.
3. Press the pedal to release the brakes. On activation, the table top or the wall stand detector holder, can be moved manually.

When the release pedal is activated, the collimator light will be lit.

Note!


The foot control must not be used outside the examination room.

The device has no applied parts and should not be accessible to patients.

Battery

The yellow battery indication LED will begin to flash once every two seconds, when the remaining battery capacity is approximately 1 week of constant use, or 168 hours. It will then change to 2 flashes per second when the capacity has been reduced to approximately 2 days, or 48 hours.

4.1.15.2 Room lights



The generator supplies a dry contact closure when the room light is to be activated. Relay K7 is energized during X-ray exposure

Installation

Installation of Subsystem 0072

4.1.15.3 Installation of wireless access point (option)



WARNING!

The cable must be installed covered. It must not be placed on the floor.



WARNING!

The wireless access point must be installed out of reach from patient and user.

Note!

The wireless access point is only used with the wireless detector.

1. Install the wireless access point at the wall in the x-ray room out of reach from patient and user.
2. Connect cable 5.0WLAN01 to connection 1.




Fig. 4-55

3. Connect cable 5.0WLAN01 to 4.5HUB01-4 in the system cabinet.




Fig. 4-56

4.1.15.4 Electrical installation image system

Electrical installation of image system computer

CAUTION!

**The image system PC should only have the image system software installed.
Other software installations could interfere with system operation.**

Note!

*The cables must be installed covered.
They shall not be placed on the floor.*

Position the image system PC in the operation room.

Connect the cable Image PC 0073–750–038 between the image system PC and the system cabinet.




Fig. 4-57 Connections image system PC

- | | |
|-------------------------------------|--|
| 1. Cable 5.0ETHCB800 – 5.0PC01-ETH1 | 3. Cable 5.0ETHHospital – 5.0PC01-ETH3 |
| 2. Cable 5.0ETHIS – 5.0PC01-ETH2 | 4. Cable 5.0RS232IS – 5.0PC01-I/O |

Hospital network


Connect cable 5.0ETHHospital to the Hospital ETH network.

Installation

Installation of Subsystem 0072

Connections to system cabinet

Wiring shall be made according to path 3 in Table 4-1 *Cable paths*.



3344

Fig. 4-58 Electrical plate 4.4 with CB800

1. Cable 5.0ETHCB800 – 4.4CB800_01–J1

Wiring shall be made according to path 1 in Table 4-1 *Cable paths*.




Fig. 4-59

1. Cable 5.0RS232IS – 4.GEN–J3

Wiring shall be made according to path 4 in Table 4-1 *Cable paths*.

| | | |
|----------------|------------|--|
| Cable 5.0ETHIS | 4.5HUB01–1 | |
|----------------|------------|--|

Installation

Installation of Subsystem 0072

Wall stand detector installation





| | | |
|--|--------------|---|
| Wiring shall be done according to cable path 2, see Table 4-1 <i>Cable paths</i> . | | |
| 3.DPOW01 | 4.2J01 21–22 |  |
| Wiring shall be done according to cable path 4, see Table 4-1 <i>Cable paths</i> . | | |
| 3.DETH01 | 4.5HUB01–3 |  |

Table detector installation

| | | |
|--|--------------|--|
| Wiring shall be done according to cable path 2, see Table 4-1 <i>Cable paths</i> . | | |
| 2.DPOW01 or 2. DPOW02 | 4.2J01 21–22 |  |
| Wiring shall be done according to cable path 4, see Table 4-1 <i>Cable paths</i> . | | |
| 2.DLAN01 or 2. DETH01 | 4.5HUB01–2 |  2 |

Installation

Installation of Subsystem 0072

4.1.15.5 Electrical installation of mini console

Position the Mini console in the operation room and connect cable Gen Console between the mini console and the cabinet.



Connecting mini console



Gen. Console cable is hanging, rolled together, inside the cabinet.

Connect to ESI card, cable path 3

4.1.15.6 External Servo Button

Mechanical Installation of External Servo Button

Install the external servo button in the operation room, using M4 bolts.




Fig. 4-60 Installation plate external servo button

Electrical Installation of External Servo Button

Position the external servo button in the operation room and connect the cable to the system cabinet.

Wiring shall be done according to cable path 3, see Table 4-1 *Cable paths*.




Fig. 4-61 Connecting to FIB

1. J15
2. J21

Installation

Measure protective earth

4.2 Measure protective earth



DANGER!

Make sure the mains power is switched off before the mains protective earth cables are disconnected.

4.2.1 Measure insulation between hospital protective earth and system

Measure the resistance between hospital protective earth and system protective earth.

The resistance value must be $\infty \Omega$.




Fig. 4-62 Measure insulation

4.2.2 Protective earth subsystem

Protective earth is measured to ensure that all cables are correctly connected.

A visual or audible device (Ohmmeter, buzzer, etc.) may be used to indicate grounding continuity.

The measured value must be $< 0,1 \Omega$.

1. Make sure the protective earth cables from table, wall stand and OTC are connected and the bolts are tightened, see Fig. 4-63 *Protective earth 4.2*.




Fig. 4-63 *Protective earth 4.2*




Fig. 4-64 *Measuring point 4,1PE01*

2. Measure the protective earth OTC between the measuring point 1.CS and the ground terminal 4,1PE01.

Installation

Measure protective earth




Fig. 4-65 Measuring point 1.CS

1. Alpha/Beta arm (1A PE)
3. Measure the protective earth OTC between the measuring point 2.CS and the ground terminal 4,1PE01.




Fig. 4-66 Measuring point 2.CS

1. Traverse wagon Y
4. Measure the protective earth table between the measuring points 1.TS, 2.TS and the ground terminal 4,1PE01.




Fig. 4-67 Measuring points 1.TS and 2.TS

1. 1.TS
2. 2.TS

5. Measure the protective earth wall stand between the measuring point 1.WS and the ground terminal 4,1PE01.




Fig. 4-68 Measuring point 1.WS

1. Measuring point 1.WS

Installation

Electrical building installation

4.3 Electrical building installation

The Machinery directive 2006/42/EC requires the system to be fitted with means to isolate it from all energy sources.



WARNING!

To avoid risk of electrical shock, this equipment must only be connected to a supply mains with protective earth.

Note!

When service or maintenance will be performed, the technician shall lock the equipment from all energy sources.

Note!

A disconnecting device from the mains shall be incorporated external to the equipment according to the national wiring rules.

4.3.1 Power ratings and line requirements

The product requires a three-phase electrical line with a protective earth ground (4 or 5 wires).

The transformers in the system cabinet, requires a tap configuration.

The generator has an automatic main line selection (no transformer tap configuration required).

The voltage has to be manually set to:

- 3 Phase VAC $\pm 10\%$
- 380 VAC 50/60 Hz
- 400 VAC 50/60 Hz
- 480 VAC 50/60 Hz
- 400 VAC with neutral 50/60 Hz
- maximum wire gauge 4 AWG (25 mm²)
- required fuse 63 A B curve thermal breaker

Having selected the voltage, make a mark at the system serial number label, at the related check box for the power rating.


| | |
|---|--|
| Model: | 0180 |
| SN | XXXX |
|  | MM/YYYY |
| Power rating: | <input type="checkbox"/> 380 3~VAC <input type="checkbox"/> 400 3~VAC <input type="checkbox"/> 400 3~N VAC <input type="checkbox"/> 480 3~VAC |
| Long-time (positioning) 2A, 50/60Hz Momentary (exposure) 150A, 50/60 Hz | |
| Intermittent operation: 20% 1min ON / 4min OFF | |

Fig. 4-69

Recommended service disconnect (as per the above table):

- All wiring and grounding should comply with the national electrical code or equivalent.
- All wiring must be copper.
- The disconnecting switch shall be located within reach of the operator.

Installation

Electrical building installation

4.3.2 Tap configuration 380 VAC / 400 VAC

Having selected the voltage, make a mark at the system serial number label, at the related check box for the power rating.




Fig. 4-70 400VAC

1. Position of generator transformer.

Check that the red wire is connected to 400V, at the generator transformer. See Fig. 4-71 *Connection 400V*.




Fig. 4-71 Connection 400V

Check that the eeprom positioned at the generator, is marked with 400V. See Fig. 4-72 400V eeprom positioned.




Fig. 4-72 400V eeprom positioned

Installation

Electrical building installation

Make sure the wire (A) is connected according to Fig. 4-73 .




Fig. 4-73




Fig. 4-74 380V




Fig. 4-75 390V




Fig. 4-76 400V




Fig. 4-77 410V

Installation

Electrical building installation




Fig. 4-78 420V

4.3.3 Tap configuration 480 VAC

Having selected the voltage, make a mark at the system serial number label, at the related check box for the power rating.




Fig. 4-79 480VAC

1. Position of generator transformer.

Check that the red wire is connected to 480 V, at the generator transformer, see Fig. 4-80 480V connection.




Fig. 4-80 480V connection

Check that the eeprom positioned at the generator is marked with 480V, see Fig. 4-81 480V eeprom positioned.

Installation

Electrical building installation




Fig. 4-81 480V eeprom positioned

Make sure the wire (A) is connected according to figure.




Fig. 4-82

3229




Fig. 4-83 460V




Fig. 4-84 470V




Fig. 4-85 480V

Installation

Electrical building installation




Fig. 4-86 490V




Fig. 4-87 500V

4.4 Electrical installation mains

Connect mains power and mains protective earth according to Fig. 4-88 *Electrical installation mains*.




Fig. 4-88 *Electrical installation mains*

Installation

Collimator

4.5 Collimator

The collimator is pre-installed by the Manufacturer. For more information on mechanical installation and adjustment refer to collimator Manufacture documentation.

4.6 Start-up procedure

4.6.1 Start-up procedure

4.6.1.1 Check voltage to the subsystem

Switch off (press down) the fuses according to picture 1 and switch on the mains power to system with the mains switch.

Measure at the fuse 4.2F02 and 4.2F05 according to picture 2.





Fig. 4-89 Check voltage to the subsystem

- $U1 = 230V \pm 10\%$
- $U4 = 230V \pm 10\%$

If the measured value fails to correspond with the levels listed above, check the tap configuration.

If the measured values correspond with the levels listed above, switch on (press up) 4.2F02.

Switch on the system from the mini console "ON" button according to picture 3.



Measure at the 4.2F03 and 4.2F04 according to picture 2.

- $U2 = 230V \pm 10\%$
- $U3 = 230V \pm 10\%$

If the measured values correspond with the levels listed above, switch off the power at mini console "OFF" button (picture 3) and switch on (press up) 4.2F03, 4.2F04 and 4.2F05.

Installation

Start-up procedure

4.6.2 Check alignment, OTC



WARNING!

The Z movements are factory default, and may not conform to the current conditions.

1.
 - Place a spirit level (1) on the OTC column (2).
 - Check that column is vertical ($\pm 1^\circ$) in two directions.
 - If necessary, check the wheels of the ceiling wagon.
2.
 - Place a spirit level (1) on the OTC tube (3).
 - Check that the tube is horizontal ($\pm 1^\circ$) in both directions.
 - If not horizontal, see 4.6.2.1 *Adjust Alpha Index*, Page 192.




Fig. 4-90

1. Spirit level
2. Column
3. OTC tube

Installation

Start-up procedure

6. Check that the collimator is placed in its index position.
7. Turn on the collimator light and mark a cross in the center of the collimator light field on a piece of paper placed on the floor.
Drive the column upward/downward and the center of the collimator light field must stay on the same mark on the paper.




Fig. 4-91




Fig. 4-92

If the collimator light field moves in x or y direction, or rotate/tilt the tube angle, check the 4.1.8.4 *Ceiling Rails Y*, Page 116 and 4.1.8.5 *Traverse Rail X*, Page 124. These must be level. If necessary adjust the Alpha index or rotate/tilt the tube angle.

Note!

Adjusting the alpha index and/or rotating/tilting the tube angle must be done before using the OTC as a reference to other devices.

Check that the tube (3) and tube tilt angle is horizontal by using a spirit level (1).




Fig. 4-93

- 1. Spirit level
- 2. Column
- 3. OTC tube

Installation

Start-up procedure

4.6.2.1 Adjust Alpha Index

Adjust the alpha index if necessary:

- Loosen the nut (A).
- Adjust the tube to horizontal level, use a spirit level.
- Tighten the nut (A).





Fig. 4-94

4.6.2.2 Adjust Beta Index



1. Loosen the two nuts.
2. Align by the method described in Fig. 4-92 .
3. Fasten the nuts.

4.6.2.3 Adjust Index Magnet

The index magnet shall be adjusted if the movement of the OTC is irregular in the middle of the sweep (alpha 0°), during Tomo-movement.

1. Remove the covers.
2. Loosen the bolt (A) that is behind the hole.
3. Turn the handle (D) until the arm (C) is against the magnet (B).
Rail (B) has to be installed on the front.
4. Activate the magnet from the node A view in the service software, see Fig. 6-9 *Measure point, protective earth traverse wagon Y.*
5. When the arm (C) is against the magnet (B) tighten the bolt (A).




Fig. 4-95

Installation

Start-up procedure

4.6.2.4 Adjust the Mechanical End Stop, Beta

Depending on how the OTC is installed, you might need to adjust the mechanical end stop beta.

1. Disconnect power.
2. Remove cover and cables connected to beta drive unit.
3. Release screws (1), holding potentiometer and release tension of belt.
4. Hold beta drive unit (2) to prevent it from falling.
5. Remove screw (3), pulley (4) and belt (5).
6. Remove beta drive unit (2) by sliding it downward.




Fig. 4-96

7. Release the two screws at no. 7, Fig. 4-97 . Remove the beta magnet.

Note! _____

There may be shims or washers needing to be reassembled in the same way afterward.




Fig. 4-97

8. Unscrew the bolts (A), see Fig. 4-98 .
9. Turn the detent plate into desired position.
10. Fasten the bolts (A) in desired position for the end stop (4 different positions are possible).
11. Reassemble any removed shims or washers.




Fig. 4-98

12. Reassemble drive unit.
13. Install pulley (4) with screw (3). Torque 9.8 Nm, Loctite 243.
14. Install belt (5).
15. Adjust tension by pushing potentiometer and tighten screws. Tension = ± 2 mm when pushing on the belt between the c/c of the pulleys.

Installation

Start-up procedure

4.6.2.5 Alignment of OTC, X- and Y-direction

1. Turn on the collimator light and mark a cross in the center of the collimator light field on a piece of paper placed on the wall.




Fig. 4-99

2. Move the OTC backward/forward and the center of the collimator light field must stay on the same mark on the paper.




Fig. 4-100

If the collimator light field moves in z direction, check the 4.1.8.4 *Ceiling Rails Y*, Page 116 and 4.1.8.5 *Traverse Rail X*, Page 124. These must be level.

4.6.3 Alignment of wall stand

1. Place a spirit level on the column and check that the wall stand is in level.
2. Move the OTC and place the collimator 10 mm from the detector of the wall stand according to Fig. 4-101 .
3. Move the OTC sideways. Measure the distance. The distance should be 10 mm.
4. If the two measured values fail to correspond, adjust the wall stand column by moving it sideways.




Fig. 4-101

4.6.4 Wall stand attachment

4.6.4.1 Wall stand Insulation and Attachment to Floor

Bolt the wall stand into the floor with the enclosed M10 bolt, also install the enclosed insulation plate and washer according to Fig. 4-102 . Apply Loctite 243, and tighten the bolts with 15 Nm.

Note!

The insulation kit is designed to insulate the wall stand from the hospital building, and will prevent stray currents from reaching the System e.g. via bolt attachments. Stray currents can be present e.g. in reinforcement bars or in water pipes in a building. These currents can be of several hundred amperes and can affect the leakage current from the System to the patient and thereby the safety for patient and user. Stray currents in the building shall be regarded as a failure in the building but the insulation kit provides an extra safety barrier. The insulation kit will also prevent unwanted ground loops due to e.g. electrical contact through the wall or floor lead X-ray shielding via bolt attachments of the Systems components.

Installation

Start-up procedure




Fig. 4-102

- 1. Bolt
- 2. Insulation washer
- 3. Insulation case
- 4. Bottom plate
- 5. Insulation plate
- 6. Enclosed expanders

4.6.5 Horizontal alignment of table

1. Move the table and place the collimator above the table frame.
2. Light up the collimator and place the light field on the detector.
3. Move OTC and detector and observe the alignment.
4. Move the OTC forward/backward along the table frame. The border of the light field must not move from the border of the table frame, see Fig. 4-103 .

If needed, adjust the table position.




Fig. 4-103

1. Light field

2. Table frame

Note!

Make sure there is enough space to slide on and off the table top, see Planning Guide.

4.6.6 Table attachment

1. Drill the holes using the drill template see Fig. 4-47 , 12 mm diameter, for the expanders. The hole depth for the enclosed expanders shall be 45 mm.




Fig. 4-104

For an alternative attachment to the floor, see the requirements in the Planning guide.

4.6.6.1 Insulation

2. Put the enclosed expanders in the holes. Place a mandrel in the expander and drive in 5-10 mm to attach the expander.
3. Place the Table over the drilled holes and install the insulation plate and washers according to Fig. 4-104 and Fig. 4-105 .

Note!

The insulation kit is designed to insulate the Table from the hospital building, and will prevent stray currents from reaching the System e.g. via bolt attachments.

Stray currents can be present e.g. in reinforcement bars or in water pipes in a building. These currents can be of several hundred amperes and can affect the leakage current from the System to the patient and thereby the safety for patient and user. Stray currents in the building shall be regarded as a failure in the building but the insulation kit provides an extra safety barrier. The insulation kit will also prevent unwanted ground loops due to e.g. electrical contact through the wall or floor lead X-ray shielding via bolt attachments of the Systems components.




Fig. 4-105

- | | |
|----------------------|----------------------|
| 1. Spirit level | 5. Insulation washer |
| 2. Installation tool | 6. Insulation plate |
| 3. Insulation washer | 7. Shims |
| 4. Adjusting bolt | |

Installation

Start-up procedure

4. Place a spirit level on the table top and check if the table top is horizontal (± 1 mm), see Fig. 4-106 . Shim each column if necessary.




Fig. 4-106

5. Place a spirit level (1) on two adjacent sides of each column. The column shall be 90° with a tolerance of $\pm 0.5^\circ$.
6. To adjust the column use the adjusting bolts (4) and the installation tool (2), see Fig. 4-105 The adjusting bolts are only for alignment.
Shims shall be used to align table top.
7. Bolt the table into the floor. Use the M10 screws included in the shipment. Apply Loctite 243 and tighten with 15 Nm.
8. Every attachment point shall be able to carry a load of at least 4.2 kN.

4.6.7 Measure insulation between hospital protective earth and system



DANGER!

Make sure the mains power is switched off before the mains protective earth cables are disconnected.

See 4.2 *Measure protective earth*, Page 170.

4.6.8 Calibration OTC

4.6.8.1 Definitions




Fig. 4-107

Installation

Start-up procedure





Fig. 4-108 Calibration X, Y

Note!

The OTC must be calibrated according to Fig. 4-108 Calibration X, Y, irrespective of how the OTC is going to be used after the installation, (i.e. normal installation or reverse installation) and the placement of the Table in relation to X and Y.

Table definitions



1. Tabletop surface to Image receptor surface
 - 1+2 FS to Image receptor holder offset.
 3. Not applicable
 4. Rotation point (pendulum parameters)
 5. Calculated movement range (Image receptor holder)
- 1 - 4 = parameters

Fig. 4-109 Important measures

4.6.9 Password

There are two access levels:

- Basic level for the Operator. Only used for reading purposes.
- Advanced level for the Service technician. Used for setting up the System and perform basic error detection.

To change the access level:

1. Chose the *File menu* and *Change user*.
2. Enter the password for the selected type of access level.
3. Press the *OK button*.
4. If no change shall be done, chose *Cancel button*.




Fig. 4-110

4.6.10 System setup

Before setting up the OTC, check the following:

1. Connect a standard serial cable (maximum length 2 m), between the System cabinet (J31 at the FIB) and the serial interface port (COM), on the service lap top (PC).
2. Start the service program.
3. Select COM-port.
4. Start the OTC service software from the enclosed USB and enter password.

Installation

Start-up procedure




Fig. 4-111

Note!

Note that the software in all nodes, including service software and the parameters are tested and verified as a software package.

The version on all nodes, service software and parameters must belong to the same software package in order to guarantee the function.

Further check can be made against the SwRLN_document.




Fig. 4-112

A System software version

B Status field

5. Check that the system software version is shown in the service program **A**. The box must not be blank.

Installation

Start-up procedure

If problems occur with the service software configuration, they are displayed in the status field **B**.

6. Check the state of all the nodes. All nodes shall be in enable state.

4.6.10.1 Hardware key

To identify the current configuration in the system, the dialogue box `Hardware Key Mask` is used.

The hardware key is made based on the ordered options for the System. The information describes the setting unique for each System.

It is possible to disable functionality in the system by unmarking a check box. This could be helpful if a node is broken. Then it is still possible to use the system if the node is removed.




Fig. 4-113

1. From the ceiling system service software, select `Edit` and `HW-Key Mask`.




Fig. 4-114 Hardware key

2. Make your choices in the dialogue box.
3. Press `Close` to return without saving changes.
4. Press `Save` to save parameters.

Descriptions of dialogue box options;

Installation

Start-up procedure

| | |
|-----------------------|---|
| System Configuration: | Current configuration for the system; - Wall stand - Table or - Table and wall stand |
| Motor Nodes: | Nodes with motorized movement. |
| Control Nodes: | Nodes with specific control functionality, for example to control the collimator. |

4.6.10.2 Motorized movements

Calibration of X-axis

1. Enter the *Node X* view.
2. Move the stand (X-axis) to its calibration point. See Fig. 4-108 *Calibration X, Y*.
3. Make sure that the stand is placed against the mechanical end stop.
4. Press the *Calibrate* button in the Node X view.
5. Check that the position of the X-node has been set to zero.
6. Move the stand (X-axis) in the positive direction and check that the position changes concurrently.
7. Place the stand 1-2 cm from the mechanical end stop (if no external object is in the way), at the same side where the calibration point (position 0) is located.
8. Press the *Set Low* button to set the low end stop.
9. Place the stand 1-2 cm from the opposite mechanical end stop (if no external object is in the way).
10. Press the *Set high* button to set the high end stop.
11. Move the X-axis, from the service software with the blue arrows, and check that the System stops at the defined positions (the end stop positions that has been set).

Note!

The end stops shall be set at a minimum distance of 500 mm, between the stand and the surrounding walls (consider the Beta rotation).




Fig. 4-115

Installation

Start-up procedure

Adjust the drive unit X and Y

Move the OTC in both X and Y direction.

Adjust the drive units if:

- the drive units run too stiff (e.g. object protection error during automatic movement).
- the drive units lose contact with the tooth belt when the brake is activated (the OTC shall not be able to move when the brake is activated).

1. To adjust the drive units loosen the nut (A).
2. Turn the eccentric bolts (B), see Fig. 4-116 .

It shall be possible to rotate the wheels (C) by finger pressure. Repeat until the drive units runs smoothly.

When the calibration of the OTC is done, a fine adjustment of the drive units may be needed.

Check that the tooth belt wheels does not lose contact with tooth belt, during the entire stroke of X/Y-direction.




Fig. 4-116

The tooth belt should not give any vibrations down to the manoeuvre handle, when the OTC is moved manually.

Calibration of Y-axis

1. Enter the *Node Y* view.
2. Move the stand (Y-axis) to its calibration point. See Fig. 4-108 *Calibration X, Y*
3. Make sure that the stand is placed against the mechanical end stop.
4. Press the *Calibrate* button in the *Node Y* view.
5. Check that the position of the Y-node has been set to zero.
6. Move the stand (Y-axis) in the positive direction and check that the position changes concurrently.
7. Place the stand 1-2 cm from the mechanical end stop (if no external object is in the way), at the same side where the calibration point (position 0) is located.
8. Press the *Set Low* button, to set the low end stop.
9. Place the stand 1-2 cm from the opposite mechanical end stop (if no external object is in the way).
10. Press the *Set high*, button to set the high end stop.
11. Move the Y-axis, from the service software with the blue arrows, and check that the System stops at the defined positions (the end stop positions that has been set). The OTC shall run smoothly, if not adjust the drive unit Y. See *Adjust the drive unit X and Y*, Page 212.

Note!

The end stops shall be set at a minimum distance of 500 mm, between the stand and the surrounding walls (consider the Beta rotation).




Fig. 4-117

Installation

Start-up procedure

Calibration of Z-axis

1. Enter the *Node Z* view.
2. Move the stand (Z-axis) to its calibration point (1500 mm between the focal spot and the floor).
3. Press the *Calibrate* button in the Node Z view.
4. Check that the position of the Z-node has been set to 1500.
5. Restart the system.
6. Press the *Connect* button (File => Connect) and check in the service software that the position (Node Z) has been set to 1500.
7. Move the stand (Z-axis) in the positive direction and check that the position changes concurrently.
8. Measure the distance between the floor and the focal spot on at least five different positions and check that the distance is concurrent (± 3 mm) with the displayed position in the service software.

If the distance differs more than the specified value (± 3 mm) helix compensation must be performed. See *Helix adjustment*.

Note!

After the helix compensation has been performed the Calibration of the Z-axis must be re-done from step one.

9. Place the stand (Z) at the position for the high end stop, see Fig. 4-119 *High and low end stops*.
10. Press the *Set high* button to set the high end stop.
11. Place the stand (Z) at the position for the low end stop (maximum range of 1750 mm, between the end stops, see Fig. 4-119 *High and low end stops*).
Observe that the end stop must be set so that there is a space between the lowest part of the stand and the floor of at least 120 mm, due to squeeze hazard.
12. Press the *Set low* button to set the low end stop.
13. Move the Z-axis and check that the System stops at the defined positions (the end stop positions that have been set).

Note!

*If the present end stops inhibits the movement, press the **Remove** button.*

If this button has been pressed the end stops must be set again.

CAUTION!

Observe that the end stop must be set so that there is a space between the lowest part of the stand and the floor of at least 120 mm, due to squeeze hazard.




Fig. 4-118 Z node




Fig. 4-119 High and low end stops

Installation

Start-up procedure

Helix adjustment

Only perform if necessary. Check if helix is correct according to step 8 at *Calibration of the Z-axis*.

1. Enter the *Node Z* view.
2. Press the *Helix* button.
3. Move the Z-axis upward until the inner segment of the column is 7 cm from the outer segment, see a) in Fig. 4-119 *High and low end stops*.
4. Measure the actual height between the floor and the focal spot.
5. Enter the value in the *Height 1* edit box.
6. Press the coherent *Enc. value* button.
7. Move the Z-axis downward until the focal spot is approximately 1200 mm above the floor.
8. Measure the actual height between the floor and the focal spot.
9. Enter the value in the *Height 2* edit box.
10. Press the coherent *Enc. value* button.
11. Place the stand (Z) at the position for the low end stop (maximum range of 1750 mm, between the end stops), see b) in Fig. 4-119 *High and low end stops*.
12. Measure the actual height between the floor and the focal spot.
13. Enter the value in the *Height 3* edit box.
14. Press the coherent *Enc. value* button.
15. Press the *Write* button to calculate and set the helix compensation value.
16. Redo the calibration of the Z-axis.

Note!

After the helix compensation has been performed, the calibration of the Z-axis must be redone from step one.




Fig. 4-120

Calibration of Alpha-axis

Only perform if necessary. Start with a check.

1. Turn the alpha-axis in $\pm 90^\circ$.
2. Check that the display shows the correct value.

If correct value is shown the alpha-axis is correct and no calibration is needed.

Before calibration of alpha-axis make sure that the alpha-axis is in the 0 position.

If not, see 4.6.2.1 *Adjust Alpha Index*, Page 192.

1. Enter the *Node A* view.
2. Move the stand (alpha-axis) to its calibration point, see Fig. 4-108 *Calibration X, Y*. Set the A-axis in the 0° index.
3. Press the *Calibrate* button.
4. Move the alpha-axis until the display shows an angle of max 135° .
5. Press the *Set High* button to set the high end stop.
6. Move the alpha-axis until the display shows an angle of max -135° .
7. Press the *Set low* button to set the low end stop.
8. Verify that the value for that Alpha angle in the display is correct in all the indexes (-90° , 0° and 90°).

Installation

Start-up procedure

Calibration of Alpha compensation

Only perform if necessary.

1. Turn the alpha-axis in $\pm 90^\circ$.

2. Check that the display shows the correct value.

If correct value is shown the alpha-axis is correct and no calibration is needed.

Before calibration of alpha-axis make sure that the alpha-axis is in the 0 position. If not, see 4.6.2.1 *Adjust Alpha Index*, Page 192.

1. Press the *Reset Alpha comp. param.* button to reset the Alpha compensation parameters.

2. Press the *Calibrate* button.

3. Set the A-axis in the -90° index.

4. Press the *-90 deg.* button to get the compensation values in -90° .

5. Set the A-axis in the 90° index.

6. Press the *90 deg.* button to get the compensation values in 90° .

7. Press the *System reset* button.




Fig. 4-121

Calibration of Beta-axis




Fig. 4-122

Only perform if necessary:

1. Turn the beta-axis in $\pm 90^\circ$.
2. Check that the display shows the correct value.
If correct value is shown, the beta-axis is correct and no calibration is needed.

Note!

If the mechanical end stop is kept in the factory preset position; paragraph 2 through 6 shall be disregarded.

1. Enter the *Node B* view.
2. Adjust the mechanical end stop (if necessary), so that the Beta rotation suits the particular installation.
3. Move the beta-axis to the mechanical end stop (positive direction).
4. Remove the potentiometer for the Beta-movement.
5. Rotate the potentiometer until the encoder value reaches 3050 (± 20).
6. Install the potentiometer and check the value again.
7. Turn the beta-axis toward the mechanical end stops (in both directions) and check that the displayed value is correct (the displayed value does not flicker or changes uncontrolled).
8. Move the stand (beta-axis) to its calibration point (see Fig. 4-108 *Calibration X, Y*).
9. Make sure that the beta-axis is in the 0° index.
10. Press the *Calibrate* button in the Node B view.
11. Check that the position of the B-node has been set to zero.
12. Move the stand (beta-axis) in the positive direction (turn counter clockwise). Check that the position changes concurrently.
13. Move the stand (beta-axis) in the positive direction (turn counter clockwise). Place the stand approximately 1° from the mechanical end stop (mechanical end stop of the b-axis).
14. Press the *Set high* button, to set the high end stop.

Installation

Start-up procedure

15. Move the stand (beta-axis) in the negative direction (turn counter-clockwise). Place the stand approximately 1° from the opposite mechanical end stop (mechanical end stop of the beta-axis).
16. Press the *Set Low* button to set the low end stop.
17. Move the beta-axis, from the service software with the blue arrow. Check that the System stops at the defined positions (the end stop positions that has been set).

4.6.10.3 Beta resolution

Before altering the resolution of the Beta node check the following:

1. Check that all nodes are alive (a green LED is toggling on the control board).
2. Check that the service cable is connected to the serial interface port on the service application host (PC).
3. Start the service application.




Fig. 4-123

4. Enter the view of the node, which resolution is to be altered (node A or node B).
5. Check that all the potentiometer value is changing (the potentiometer value can be read in the SSW) when moving the axis.
6. Check that all the encoder value is changing (the encoder value can be read in the SSW) when moving the axis.
7. Set the axis in the -90° mechanical index. Read out the potentiometer and the encoder value.
8. Set the axis in the 90° mechanical index. Read out the potentiometer and the encoder value.
9. Calculate the resolution, using the following formula:
$$(180 / (\text{Pot.value 1} - \text{Pot.value 2})) * 10\,000 = \text{Potentiometer resolution}$$
$$(180 / (\text{Enc.value 1} - \text{Enc.value 2}) / 180) * 100\,000 = \text{Encoder resolution}$$

Installation

Start-up procedure




Fig. 4-124

10. Press the *Set Resolution* button.
11. Enter the *Potentiometer Resolution* and the *Encoder resolution* in the coherent edit boxes.
12. Enter the fraction of the encoder resolution in the coherent edit box (see example below).
If the Encoder resolution value is 1009,416564..., the "Enc. res frac." shall be set to 4.
13. Press *Write button* to store the values.
14. Close the dialogue box.
15. Move the axis, with the blue arrows, and check that the movement works correctly.
16. Place the axis (manually) in the mechanical indexes. Verify that the position is coherent with the position of the indexes.

4.6.11 Calibration of bucky-axis on table




Fig. 4-125

Note!

The value on the position must increase when moving in positive X or Y direction.
If it does not increase then activate the inverted direction.

Note!

If the present end stops inhibit the movement, press the Remove-button.
If this button has been pressed, the end stops must be set again.

Note!

To be able to calibrate, the bucky-axis must be placed in the cradle. The drive cradle box is marked green, when the detector holder is correctly positioned.

1. Enter the *Bucky* view.
2. Move the OTC (X- and Y-axis) until the light field of the collimator is aligned with the center of the detector holder.
3. Press the *Calibrate* button in the *Bucky* view.
4. Check the position.
If the table is installed in the X-direction the detector holder shall have the same position as the X-node.
If the table is installed in the Y-direction the detector holder shall have the same position as the Y-node.
5. Move the bucky-axis, from the service application, in the positive direction. Place the detector approximately 1 cm from the mechanical end stop.
6. Press the *Set high* button to set the positive end stop.
7. Move the bucky-axis, from the service application, in the negative direction. Place the detector approximately 1 cm from the mechanical end stop.
8. Press the *Set Low* button to set the negative end stop.
9. Move the bucky-axis, from the service software with the blue arrows. Check that the system stops at the defined positions (the end stop positions that have been set).

Installation

Start-up procedure

10. Check that the value in the `Position` box increases when moving in positive X or Y direction.

If it does not increase, activate the inverted direction.

The table can be installed in four directions in the room and the value in the `Position` box must increase when moving in positive X or Y direction for correct setting.

11. Define grid to be used.

4.6.12 Calibration of wall stand




Fig. 4-126 WS node

1. Enter the *WS node* view.
2. Make sure the collimator is directed against the detector.




Fig. 4-127

3. Make sure that the focal spot of the tube is aligned with the center of the detector.
4. Press *Calibrate*.
5. Check that the position of the wall stand has changed to the position of the Z-node.

Calibration of end stops:

6. High end stop.
Move the wall stand to its highest position and then down approximately 2 cm. Press Set high.
7. Low end stop.
Move the wall stand to 12 cm up of the floor and then up approximately 2 cm.
Press set low.

Note!

The lowest position must be set so that there is a space between the lowest part of the stand and the floor of at least 12 cm, due to squeeze hazard.


Installation

Start-up procedure

4.6.12.1 Patient protection end stop

- Move the wall stand to a position where the distance between the lowest moving part and the floor is 2.5 cm.
- Press the *Patient Protection* button.
- Check that the *Patient Protection value* changed to the same value as the wall stand position.

4.6.12.2 Calibration of wall stand tilt



Note!

If the present end stops inhibits the movement, press the Remove-button.

If this button has been pressed, the end stops must be set again.

1. Enter WS Tilt node view.
2. Make sure the detector is in a vertical position.
3. Press Calibrate.
4. Check that the position of the wall stand tilt has changed to 0.

Calibration of End stops

5. High end stop.
Move the wall stand tilt to 91°. Press Set high.
Move carefully, so as to not collide with the plastic cover.
6. Check that the High end stop value changed to the same as the Position value.
7. Low end stop.
Move the wall stand tilt to -20°. Press Set low.
8. Check that the High end stop value changed to the same as the Position value.
9. Move the WS Tilt axis and check that the movement stops at the defined end positions.

GRID settings

10. Define grids that shall be used
 - a Select the table grid, or short SID WS grid, as Set Grid 1.
 - b Select the medium SID WS grid, as Set Grid 2.
 - c Select the long SID WS grid, as Set Grid 3.

Note!

Set Grid 1 should be the same as defined under the table bucky node.

Installation

Start-up procedure

4.6.13 Calibration of table

Note!

Observe that the room coordinates are critical to get the correct table position.

The Z-node, X-node, Y-node, A-node and B-node must have been calibrated before the Table position can be set.

To get the correct Table area, observe the Beta-rotation for each position.

The table calibration is performed by the manufacturer is made by the manufacturer. Any further calibration is not needed if the function is good.




Fig. 4-128 Table stand

1. Enter the Z Table view.
2. Move the table to its highest position, and then down 2 cm.
3. Measure the height between the active image area and the floor.

4. Move the Z to the height corresponding to the measured height. Use the collimator measuring tape.




Fig. 4-129

5. Press the *Get pos.1* button.
6. Move the table to its lowest position, and then up 2 cm.
7. Measure the new height between the active image area and the floor.

Note!

It is important to measure the height at exactly the same spot at the detector.

8. Move the Z to the height corresponding to the measured height. Use the collimator measuring tape.




Fig. 4-130 Pos 1 and Pos 2

9. Press the *Get pos.2* button.
10. Check that the position of the Table has changed to the position of the Z-node.
11. Measure the speed of the table (mm/s) and multiply the value with 2.
12. Enter the value in the *Max Speed* edit box.
13. Press the *Set speed* button to store the value.

Installation

Start-up procedure

Note!

The height of the table stand is measured from the floor, to the active detector surface.

4.6.13.1 Table safety zone




Fig. 4-131

Note!

The table safety zone is for low speed area.

1. Enter the *Master node* view. (*Stand/Control nodes/Master node*)
2. Move the stand to position 1 (see figure). Press the *Set pos. 1* button.
3. Move the stand to position 2 (see figure). Press the *Set pos. 2* button.
4. Move the stand to position 3 (see figure). Press the *Set pos. 3* button.
5. Move the stand to position 4 (see figure). Press the *Set pos. 4* button.




Fig. 4-132 Table position

There shall be a distance of 120 mm between the stand (front of the display) and the table top. If the table top is “floating”, consider the maximum and minimum position of the table top when setting the Table safety zone.

4.6.13.2 Transport interval zone

Movements between auto-positions is performed in a defined transport interval zone. The upper and lower limits are pre-defined from factory, but shall at installation be adjusted to the actual circumstances in the operating room.

- The upper transport height shall be set as high as possible, considering the cable hoses etc. See note below.
- The lower transport height, shall be set with consideration taken to the table.
- None of the values shall be 0.

Setting of the transport interval zone, must be done after the calibration of all axis.

To set the transport interval zone;

1. Enter the *Master node* view (Stand/Control nodes/Master node).
2. Move the Z-axis node upward to the desired position.

Note!

*We recommend the upper limit, **not** to be higher than when the inner segment of the column is 10 cm from the outer segment. See Fig. 4-133 Recommended highest limit.*

See also Fig. 4-131 Master node view.




Fig. 4-133 Recommended highest limit

3. Press the *Set upper* button, for transport height.
4. Check that the upper value has changed to the position value of the Z-node.
5. Move the table upward until the table top has reached the maximum height of approximately 1 m. Move the Z-axis downward to the desired position for the lower transport height.

Note!

When the OTC is within the area above the table, the lower transport height shall be at least 30 cm over the highest point of the table.

6. Press the *Set lower* button.
7. Check that the lower value has changed to the position value of the Z-node.




Fig. 4-134 The high voltage cable running freely

Take special care to confirm that the high voltage cable runs freely in all auto positions and does not obstruct or inhibit movements in any of the selected positions.

The cable can be adjusted in the cable holder to prevent the cable from being squeezed during positioning.

4.6.13.3 Focal spot to detector holder offset




Fig. 4-135

See Fig. 4-131 Master node view:

1. Enter the *Master node view*.
2. Move the stand over the table.
3. Place the tube directly over the table top (the lowest point of the stand shall almost touch the table top).
4. Measure the distance between the focal spot and the active detector surface of the detector.
5. Enter the measured value in the *FS to BU offset* edit box in millimetres.
6. Press the *Set distance* button.
7. Move the stand (Z-axis) up at least 800 mm above the table top and down again.
8. Check that the system stops 500 mm above the table top (lowest point of the stand).
9. Press down again and check that the speed is reduced to half speed.

Note!

This distance must be set to secure that the safety distance (500 mm) is accurate.

4.6.13.4 Table top offset

See Fig. 4-131 Master node view:

1. Enter the *Master node view*.
2. Measure the distance between the active detector surface of the detector, and the surface of the table top.
3. Enter the value (in mm) in the *Table top offset* edit box.
4. Press the *Set distance* button.

4.6.13.5 Movement short-cut zones

At installation a movement short-cut zones shall be set up for the wall stand resp. the Table. The zones are defined as rectangular cubes. Inside these zones, short-cuts are allowed and there is no need for the OTC to attain the transport interval zone before moving.

Outside these short-cut zones, the OTC will first move in Z direction, to the transport interval zone, before moving to position.

The recommended transport height is set as; The first Table stop + SID.

Installation

Start-up procedure

Table movement short-cut zone

When defining the Table movement zone, it will be activated toward the direction of the light field.

1. Start the zone definition by setting the OTC alpha to 0.
2. Position the light field with the reticle at the middle of the Table head end, exactly where the cover ending and the middle seam, cross each other. See Fig. 4-136 . The OTC handle shall be positioned at the same direction as the front of the detector tray.





Fig. 4-136

Also see Fig. 4-131 .

Table service program

3. Move to the *Master view*. See Fig. 4-131 Master node view.
4. Mark the *Enable* box. Marking this box enables short-cuts.
5. Enter *Set*. The X-position and the Y-position for the area, will be saved as to the OTC position.




Fig. 4-137

As long as at least one of the OTC corners stays inside the Table movement zone, the OTC will perform a short-cut at positioning.

Installation

Start-up procedure

4.6.13.6 Wall stand movement short-cut zone

When defining the wall stand movement short-cut zone, it will be activated toward the direction of the light field.

1. Angle the OTC light field against the floor.
2. Move the OTC light field to the point where the area is to begin.
3. Angle the OTC light field against the center of the wall stand detector.




Fig. 4-138 Wall stand movement short-cut zone



WARNING!

The wall stand movement short-cut zone must not be set too wide. Consider the Table safety zone.

Setting wall stand safety zone

See Fig. 4-131 Master node view.

1. Tube short-cut wall stand: Mark the *Enable* box. Marking this box enables shortcuts.
2. When the OTC is positioned where the zone is intended to start, press *Set*.

The position of the short-cut zone can be seen by selecting *View Areas*.

If the settings shall be changed, define the width and length of the short-cut zone by setting the values *Width* and *Length* in mm. Press *Save*.




Fig. 4-139 Wall stand short-cut zone

Installation

Start-up procedure

4.6.13.7 Beta offset

See Fig. 4-131 Master node view:

1. Enter the *Master view*.
2. Move the B-axis to a typical working position.
3. Enter the current B-position value (deg.) in the Beta offset edit box.
4. Press the *Set to zero* button.
5. Check that the value, shown on the display, has changed to 0.

Note! —————

The Beta offset only manipulates the value shown in the display.

The actual position of the Beta-rotation will not be changed and the position in the service software will not be changed.

4.6.13.8 WallFlexible parameters

Movements




Fig. 4-140 Adjust WallFlexible parameters

There are 3 different Wall Flexible Modes, all accessible from the Arcoma Service program; *Adjust WallFlexible parameters*.

The active mode for the installation is selected in the Service program and applies for all autositions with Wall Flexible Mode.

Installation

Start-up procedure




Fig. 4-141 Not Blocked

1. *Not Blocked* — All OTC movements are allowed.




Fig. 4-142 Beta blocked and Sideways supervised

2. *Beta blocked and Sideways Supervised* — Beta movements are blocked. A beta rotation will turn the servo off and prevent exposure. The OTC can be moved sideways, for a distance of half the detector width (landscape position). When the OTC is outside this area, the servo turns off and exposures will not be possible. It is also possible to move the OTC in FFD-direction.




Fig. 4-143 Beta and Sideways blocked

3. *Beta and Sideways Blocked* — Beta movements and sideways movements of the OTC are blocked. It is only possible to move the OTC upward, downward and in FFD-direction. A movement will turn the servo off and block any exposure.

Autopositioning — WS

To enable the wall stand autopositioning, check the box *Autoposition wall stand*. Enabling this feature, means that the wall stand detector holder will move to the programmed position, at the autopositioning.

Installation

Start-up procedure

4.6.13.9 Detector parameters

Define Table and Wall stand detector sizes.

Entered settings are mainly used for autocollimation.

See Fig. 4-131 *Master node view*:

1. Enter the *Master node view*.
2. Press the button Detector parameters.
3. When the parameters are updated, press Save and you will return to the *Master node view*.




Fig. 4-144 Detectors

Note!

Refer to detector data sheets to set the correct size in mm. Incorrect detector size settings can affect automatic collimation and positioning.

4.6.13.10 Calibration of guard function (Z-axis)

Check the impact force.

The force must not exceed 170 ± 30 N (use a force gauge).

If the force does not exceed 170 ± 30 N (upward or downward), the following section may be skipped.




Fig. 4-145 Guard node

1. Enter the *Guard* view.
2. Place the stand in the specified position.




Fig. 4-146 Stand position

3. Press the *Set balance* button.
4. Reset the system.

Installation

Start-up procedure

5. Move the Z-axis downward.
6. Measure the force required to trig the collision guard (movement stops and an error message is displayed), when moving downward (use a dynamometer).
7. Adjust the value for Pos.1.
8. Press the *Set pos.1*—button to store the value to the stand.
9. Measure the force needed to trig the collision guard (use a dynamometer).
10. Move the Z-axis upward.
11. Measure the force required to trig the collision guard (movement stops and an error message is displayed) when moving upward.
12. Adjust the value for Pos.2.
13. Press the *Set pos.2* button to store the value to the stand.
14. Measure the force needed to trig the crash guard (use a dynamometer).

Note!

The required force for activation of the guard function must not exceed 170+/-30 N. The values displayed in the edit boxes are not directly compatible with the force. 2-3 points are approximately 10 N.

4.6.13.11 Calibration service software for table

Note!

The table is calibrated on Manufacturers site and only has to be recalibrated if a problem occurs.



WARNING!

Standard RS232 cable shall not be used. Service cable shall be ordered from Manufacturer.

Note!

The electrical plate is heavy. Be careful when the plate opens.




Fig. 4-147

Installation

Start-up procedure

System setup

Before setting up the table:

1. Check that the table can go the entire stroke, up and down.
2. Check that the table stops at the correct end stops.
3. Check that the guard works. (Option)
 - If the table works correctly, go to 4.6.8 *Calibration OTC*, Page 203.
 - If the table needs further calibration:

Note!

Note that all the software nodes including service software and the parameters are tested and verified as a software package. The version on all nodes, service software and parameters must belong to the same software package for Manufacturer to guarantee the function of the table.

Note!

Parameters shall always be saved before any adjustments are made. The parameter settings shall always be physically stored nearby the System.

4. Verify that all nodes are alive (a green LED is toggling on the control board).
5. Connect the service cable from the lap top (PC) to the serial interface port (COM). (The service cable can be ordered as a spare part).
6. Start the service software (enclosed). Check that the version of the service software and the version on the System software belong to the same software package. Check against the enclosed accompanying documents.
7. Select COM-port and enter password. See Fig. 4-148 *Login*.
8. Verify that the User Level in Fig. 4-148 *Login*, changes from 0 to 1, when entering the correct password.
9. Verify that all nodes are in enable state, see Fig. 4-149 *SSW 0055*.

Note!

The state also depends on the System configuration, thus the system might be fully functional even if an optional node is in another state.

If a node is not present, the text "NO CONNECTION" is displayed.

Installation

Start-up procedure




Fig. 4-148 Login




Fig. 4-149 SSW 0055

Installation

Start-up procedure

Calibration of the tilt sensor

1. Enter the *Calibrate Z* view.
2. Place a spirit level on the table top.
3. On condition that the floor is horizontal (± 1 mm), level the table top by moving one of the columns. See also 4.6.5 *Horizontal alignment of table*, Page 199.
4. Press the *Tilt Calibrate*—button (lower left corner of the view).

Note!

Be careful when moving the columns separately. If the angle of the table top exceeds 7° the Table might be damaged.

5. Adjust the tilt sensor mechanically.
 - a. Measure the voltage between J4:4 and J4:6 on the control board. If the voltage is $3\text{ V} \pm 0.2\text{ V}$ re-install the cover and go the paragraph 6.
 - b. Remove the left back cover by removing the bolts (A) shown in Fig. 4-150 *Removing left back cover*. Observe the placement of the cable chain before removing the cover.




Fig. 4-150 *Removing left back cover*

- c. Loosen the bolts (B), see Fig. 4-151, and angle the bracket (C) until the output of the tilt sensor (D) is $3\text{ V} \pm 0.2\text{ V}$.




Fig. 4-151

- d. Tighten the bolts (B), use Loctite 243, see Fig. 4-150 *Removing left back cover*.
- e. Install the cover.

Note!

Beware of the cable chain when installing the cover.

- 6. Press the *Tilt Calibrate* button (lower left corner of the view), see Fig. 4-152 *Reset button*. The displayed angle shall now be set to 0.0°.
- 7. Press the reset button (R), see Fig. 4-152 *Reset button*.




Fig. 4-152 *Reset button*

Installation

Start-up procedure

Calibration of table height

1. Enter the *Calibrate Z* view.
2. Place a spirit level on the table top.
3. Level the table top by moving one of the columns.

Note!

Be careful when moving the columns separately. If the angle of the table top exceeds 7° the Table might be damaged.

4. If the displayed angle of the tilt sensor exceeds 0.4° the tilt sensor has to be re-calibrated, see *Calibration of the tilt sensor*, Page 250.
5. Measure the distance between the floor and the surface of the table top.
6. Enter the distance (in mm) in Edit box beside the Calibrate button of the table top (Z), see Fig. 4-153 *Calibration Table height*.
7. Press the Calibrate button.
8. Press the reset (R) button.
9. Verify that the position of the Head End column and the Foot End column is changed to the entered value.




Fig. 4-153 Calibration Table height

Calibration of software end stops

Note!

Calibrate the software end stops, to prevent collision whit external objects.

1. Enter the *Calibrate Z* view.
2. Enter the value "20" in the *Edit* box beside the *Set Max Speed* button.
3. Press the *Set Max Speed* button.
4. Press the *Clear Limits* button, see Fig. 4-154 *Setting the Table top limits*.

Note!

Be aware that the end stops now are removed. Be careful when moving the Table.




Fig. 4-154 Setting the Table top limits

5. Enter the *Z* view.
6. Press the *Arrow Down* button and keep it pressed until the movement stops. The text "DOWN" shall now be visible in the *Blocking edit* box for both the *Head End* and the *Foot End*.
7. Press the *Arrow UP* button and keep it pressed until the text "NO" is visible in the *Blocking edit* box for both the *Head End* and the *Foot End*.
8. Enter the *Calibrate Z* view.
9. Press the *Set Lo Limit* button.
10. Enter the *Z* view.
11. Press the *Arrow Up* button and keep it pressed until the movement stops. The text 'UP' shall now be visible in the *Blocking edit* box for both the *Head End* and the *Foot End*.

Installation

Start-up procedure

12. Press the *Arrow Down* button and keep it pressed until the text “NO” is visible in the *Blocking edit box* for both the *Head End* and the *Foot End*, see Fig. 4-155 .




Fig. 4-155

13. Enter the *Calibrate Z* view.
14. Press the *Set Hi Limit* button.
15. Enter the value “40” in the *Edit box* besides the *Set Max Speed* button.
16. Enter the *Z* view and move the Table up and down, to verify the functionality. The text in the *Blocking Edit box* shall say “NO” at all times.

Note!

The software end stops shall be set at minimum 4 mm +/-1 mm from the mechanical end stops.

Calibration of max speed

1. Enter the *Calibrate Z* view.
2. Enter the new speed value (mm/sec) in the *Edit box* beside the *Set Max Speed* button, see Fig. 4-156 *Calibration Table Max Speed*. Observe that 40 mm/sec is the maximum speed.
3. Press the *Set Max Speed* button.




Fig. 4-156 Calibration Table Max Speed

Installation

Start-up procedure

Calibration of safety zone

The safety zone is the distance (120 mm) from the lowest moving point of the Table to the floor.

1. Enter the *Calibrate Z* view.
2. Move the Table until the height for the safety zone is reached.

Note!

It shall always be at least 120 mm between the lowest moving point of the Table and the floor.

3. Press the *Current* button beside the *Set Safety Height* button, see Fig. 4-157 .
4. Press the *Set Safety Height* button.
5. Verify the functionality by moving the Table up and down. The movement shall stop when entering the safety zone and when the downward button is pressed again it shall proceed at half speed.




Fig. 4-157

Calibration of crash guard detection

1. Enter the *Guard* view.
2. Press the *Calibrate* button.
3. Check the value displayed in the *AD value Edit* box. The value shall be 2500 +/-500, see Fig. 4-158 *Guard Setting*.
4. Use a dynamometer to check the impact force by moving the table top upward and downward. The needed force of impact shall not exceed 200N +/-70N before movements is stopped.
5. If necessary adjust the trig levels by entering a new value Guard settings Edit boxes and pressing the coherent button (Set Trig level 1 and/or Set Trig level 2) see Fig. 4-158 *Guard Setting*. 2-3 points are approximately 10N.
6. Check the guard function in each corner of the table top.




Fig. 4-158 Guard Setting

Installation

Start-up procedure

4.6.13.12 Save parameters (settings) table

If there are problems with the Table functionality, calibrate and save back up described below.

In case of failure, the Table may be restored to the same state as it was initially.

1. Open the *Table service software* program.
2. Press *Operations* in menu and select *Save Parameters*, see Fig. 4-159 .
3. Select folder to where the parameters shall be saved.
4. Press the *Save* button.

Note!

Parameters shall always be saved before any adjustments are made. The parameter settings shall always be stored near by the System.




Fig. 4-159

4.6.14 Calibration of collimator

The collimator is preset from factory.

4.6.14.1 Detector X/Y orientation

The X/Y orientation of the table and wall stand detectors are defined in figure.




Fig. 4-160

Installation

Start-up procedure

4.6.15 Calibration of tube

The tube calibration is done at manufacture and shall be done once again at the installation.

For tube calibration, see *Generator documentation*.

4.6.16 Installation of AEC

For Systems with a detector holder for a portable detector, the AEC is pre-mounted at factory.

If applicable, install and calibrate the AEC according to manufacturers instructions. A chamber of ionic type, has to be flatly mounted. If it should be mounted in any tension, the result cannot be guaranteed. Adjust the chamber brackets until a flat position is reached.

CAUTION!

Make sure the AEC back-up values are properly defined.

4.6.17 Gain adjustment of AID (ICX-3922) AEC

Note!

For adjusting the exposure settings, see the Image System User Manual, Section C, "Adjusting Technique Settings".

When adjusting AEC, remember to check against the dose value.

4.6.17.1 Wall stand

The description below, relates to a left-loaded detector holder. When using a right-loaded detector holder, the adjustments screws shall be in the opposite order.



Fig. 4-161

1. Remove the 4 screws from the cover at the back of the detector holder, and remove the small cover.
2. Adjust AEC gain from the adjustment hole to the AEC amplifier using a precision standard screwdriver.
3. Adjust from the MASTER adjustment hole.
4. Adjusting in the clockwise direction increases sensitivity = reduces time = reduces dose = reduces exposure index.
5. Adjusting in the counterclockwise direction reduces sensitivity = increases time = increases dose = increases exposure index.

Installation

Start-up procedure



Fig. 4-162

Note!

In case of a right-loaded detector holder, adjustment holes are Field A, Field B, Field C, and MASTER in order from the top.

4.6.17.2 Table

Adjust AEC gain from the adjustment hole to the AEC amplifier on the side of the reader part (detector holder) using a precision standard screwdriver.

- Adjust from the MASTER adjustment hole.
- Adjusting in the clockwise direction increases sensitivity = reduces time = reduces dose = reduces exposure index.
- Adjusting in counterclockwise direction reduces sensitivity = increases time = increases dose = increases exposure index.




Fig. 4-163 Adjustment holes




Fig. 4-164 Adjustment holes

4.6.18 Calibration of auto positions

1. Enter the *Positions* view (Operations => Positions).
2. Move the ceiling tube support (A, B, X, Y, Z, detector holder/wall stand) to the position.

3. Press a position, in the *Pos. column*, with the cursor.
4. Select mode (check which modes that are valid for the System).
5. Enter the offset Z value.
The offset Z value is only available in *Table Flexible mode*.
6. Enter the SID value (in *Free mode* and the *Auto position* mode the SID value is only used for the automatic collimator).
7. Check or uncheck *NoWait*, depending on desired function.
See the *System Operation Manual, Chapter 4, Operating the System and Wall Flexible mode* for description of *NoWait configuration*.
8. Press the *Write* button to save the position.





Fig. 4-165

9. After saving the “*Auto positions*”, check the X-ray field alignment with the detector and adjust if necessary.



Note!

Wall stand detector angle and tube angle can also be controlled from the Protocol Editor.

4.6.19 Tomo/pendulum parameters

1. Enter the *Master* view.
2. Press the *Tomo/Pend. parameters* button.
3. The *Tomo/pend. parameters* view will appear.

Installation

Start-up procedure

4. Enter the *Sweep length* for the tomo-movement.
5. Enter the *Trig time* for the tomo-movement (the value shall be entered in milliseconds).
6. Enter the wanted *Speed* for the pendulum-movement (the value shall be entered in millimetres per second).
7. Enter the wanted Rotation offset (cut line height) for the pendulum-movement (the value shall be entered in millimetres, measured from the tabletop).
8. Press the *Write* button to save the values.

Note!

The Sweep length is the movement range, calculated from the point where the position was stored (if the Sweep length is set to 500 mm, the total sweep length will be 1000 mm). The Trig time is the preparation time that the detector needs before imaging.




Fig. 4-166

4.6.20 Tests

4.6.20.1 System test

Perform a number of X-ray examinations.

Exposure parameters

Check the Exposure parameters.

Auto positioning

Check the auto positioning.

Installation

Start-up procedure

4.6.20.2 Balancing the wall stand detector movement

The wall stand is designed with a counterweight wagon inside the base column. Depending on system use and user preferences (detector type, grid and armrest) a rebalancing might be needed. Consult with end users and responsible person at customer site in order to decide if rebalancing is necessary.

To adjust the weight balance, perform the following steps:




Fig. 4-167 Remove cover

1. Move the detector wagon to a low position.
2. Release the 4 screws (A) and remove the top plastic cover.




Fig. 4-168 Remove upper screws

3. Remove the 2 upper screws (B) holding the front aluminium plate.




Fig. 4-169 Remove lower screws


4. Remove the 2 lower screws (C) holding the front aluminium plate.
5. Remove the front aluminium plate by lifting it upwards.

Note!

Be careful not to scratch the aluminium plate in the narrow gap between base column and detector wagon.

Note!

It is important to perform step 3. before step 4. in order to release mechanical tension on aluminium plate and avoiding any damage on screws.



6. Move the counterweight wagon up/down to a convenient position to work with. *Note! Mind the squeezing hazard.*
7. Remove the 4 screws (D) with nuts (E) attaching the counterweights.
8. Add/remove one weight at a time.
9. Release the brake to allow manual Z movement and check the balance.
10. Repeat step 8. and 9. until balance between counterweight wagon and detector wagon is satisfactory.

Fig. 4-170 Counterweight wagon

Note!

The guard plate (F, marked red) must always remain mounted, see Fig. 4-170 Counterweight wagon

11. When balance is satisfactory, reattach the 4 screws (D) previously removed in step 7.

If weights have been added: Release the nut (E) on each screw (D) before tightening. Then tighten the screws (D) and finally tighten the nuts (E) to lock the position of the weights.

If weights have been removed: Tighten the screws (D) and then tighten the nuts (E) to lock the position of the weights.

12. Move the detector wagon to a low position.

Installation

Start-up procedure

13. Remount the front aluminium plate by sliding it downwards behind detector wagon.
14. Insert and tighten the 2 lower screws (C) holding the front aluminium plate, see Fig. 4-169 *Remove lower screws*
15. Insert and tighten the 2 upper screws (B) holding the front aluminium plate, see Fig. 4-168 *Remove upper screws*.

Note! _____

Be careful not to damage the aluminium threads.

16. Attach the plastic top cover and tighten the 4 screws (A) see Fig. 4-167 *Remove cover*.

4.6.20.3 Emergency button test

The emergency buttons should be tested in order to see that they work properly.

See *Chapter 2 Safety*, for description on how the emergency stop should react on command.

4.6.20.4 Indication light test

Check that the indication lights on the table and the wall stand are lit when the respective receptor is selected.

4.6.20.5 Generator software file

Check that the permanent license file is loaded into the generator.

4.6.21 Back-up parameters

4.6.21.1 Save OTC parameters

1. Connect service laptop to the service cable of Arco Ceil (1.1 Service).
2. Launch Service software from Arcoma system USB.
3. Connect the service program to the system using the appropriate COM port. Make sure that the connection state in the lower part of the screen changes from "Disconnected" to "connected".
4. Check that all nodes are in enable state.




Fig. 4-171 Check enable state

5. Select **File** and **Save parameters As**.
The file is saved as a .txt-file.




Fig. 4-172 Save parameters as

Installation

Start-up procedure

4.6.22 Collimator light and X-ray field alignment

The collimator light field and the X-ray field are normally adjusted at delivery.

However, check the following when installing.

1. Align the tube with the detector.
2. Attach some suitable objects on the detector holder cover (within the active detector area).
3. Perform an exposure and evaluate the alignment (images vs. the collimator light field) using the references applied in the previous step.

Rail (B) has to be installed on the front.

4. The maximum deviation between light field and X-ray field is $\pm 1\%$ of SID, see figure.
5. Adjust the collimator light field according to the Collimator Manual.

Note!

Be aware of the difference between the two rails (A) and (B).




Fig. 4-173 Alignment

4.6.23 Collimator Adjustments

4.6.23.1 Accuracy of the Light field indication to X-ray field

The Collimator X-ray field and the light field are factory calibrated. Ensure the calibration meets local legislation.

Calibration setting:

- The total discrepancies between the edges of the X-ray field and the corresponding edges of the Light Field do not exceed 2% of the distance of the measured plane of the Light Field from the Focal Spot.

4.6.23.2 Verification of the Light field indication to X-ray field

The X-ray images taken are used to verify the light field to X-ray field accuracy.

In case the light field does not match the X-ray field, perform the following:

- Check the if distance (spacing) from the focal spot of the X-ray tube to the collimator mounting plane is 80 ± 1 [mm] ($3.15'' \pm .039''$):
 1. Light field larger than X-ray field:
Remount the collimator to the X-ray system using less spacer(s) and repeat the test image procedure and verify the sizes.
 2. Light field smaller than X-ray field:
Remount the collimator to the X-ray system using additional spacer(s) and repeat the test image procedure and verify the sizes.

4.6.23.3 Field light size fine adjustment




Fig. 4-174 Field light adjustments

Fine adjustment of the field light size can be done after removal of the rear panel. The field light size can be adjusted by loosening the positioning screws of the field light bracket as indicated Fig. 4-174 *Field light adjustments*. Adjusting is done by means of 2 screws, socket head wrench (size 2).

After the field light size is adjusted, carefully tighten the positioning screws without moving the field.

Installation

Start-up procedure

4.6.24 Calibration of tube

The tube calibration is done at manufacture and shall be done once again at the installation.

For tube calibration, see *Generator documentation*.

4.6.25 AEC calibration

4.6.25.1 Measurement of system attenuation factor

General

On delivery of the system, the AEC is pre-calibrated and should only need minor corrections. In case a new AEC chamber is to be installed, proceed as following:

Installation of new AEC chamber

1. Turn all four gain potentiometers on the amplifier (not the AEC board in the generator) completely to minimum.
Turn clockwise until you can hear a click on every turn, max 15 turns.
2. Turn all four gain potentiometers approx. 3.5 turns positive (3.5 turns anti clockwise).
3. All master gain adjustments need to be performed on the generator AEC board.
4. Make sure the central beam is perpendicular and centered relative to the image receptor.
5. Ensure the X-ray field completely covers all three AEC fields.
6. Ensure the size of the used phantom is larger than the X-ray field.
7. All AEC post exposure times should be between 30 and 100 ms.
Adjust tube current if necessary.
8. Only one film speed is activated on delivery (medium).

4.6.25.2 Check of AEC chamber field versus image system AEC fields


Check that all three AEC fields on both table and wall stand correspond to the selected fields in the image system.

1. Activate AEC on the image system.
2. Make sure that only the left field is activated.
3. Completely cover the left field on the table or wall stand with a suitable object with high attenuation, e.g. a lead apron.
Make sure the other two fields are not covered, here center and right field.
4. Make an exposure with suitable exposure parameters, e.g. 50 KV, 10 mAs, no phantom, SID according to grid focal distance, X-ray beam covering all three AEC fields.
The exposure should be finished by the backup timer.
5. Remove the object mounted in front of the relevant field and repeat the exposure. Now a very short exposure time should be the result.
6. Repeat on all fields of the table and wall stand.

Installation


Start-up procedure

4.6.25.3 Adjustment of balance between the three fields



3597


Fig. 4-175



3598

Fig. 4-176

Balance calibrations in GenwareMP



3786

Fig. 4-177

Field balance check

Exposure parameters:

- SID 100 cm
- 80 KV
- 25 mAs backup mAs
- 25 mm aluminum Phantom in front of collimator
- AEC ON
- Collimator filter off = 0 mm AL and CU
- X-ray field set to cover all three fields
- Grid mounted. If more than one grid is available, mount the one with the highest ratio.

1. On the image system, activate only the left field (C).
2. Expose and note the mAs (or measure the radiation dose).
3. Repeat 1–2 for both the center (B) and right field (A).
4. Compare the three mAs (or μGy) results and if necessary adjust the corresponding gain potentiometer (field A-C potentiometer) until all three mAs values are the same. As accurate as possible, max deviation is $\pm 10\%$.

During this procedure, do not change the master gain potentiometer.

4.6.25.4 Fine tuning of KV compensation

Determination of AEC cut off EI

The required EI (Exposure Index) value is depending on detector type. The detector entrance dose is depending on the detector type/manufacture and can be regulated by national requirements, if unknown, a suitable value is 180 (corresponds to ca 1,8 μGy detector entrance dose).

The CXDI software has AEC protocols used for calibration installed, which are used to calibrate the cut off EI level. The below exposure parameters might need to be adjusted for your own needs.

Exposure parameters:

- SID according to grid focal distance
- 75 KV
- Set the value in the 75 KV dialog box to 4,50, see Fig. 4-178 *AEC setup and calibration*(see figure 5 below) for the relevant AEC channel and filmscreen
- 25 mAs backup mAs
- 15 cm PMMA in front of the collimator, alternatively a suitable thickness of aluminium or a water phantom can be used.
- AEC ON
- Collimator filter off = 0 mm AL and CU
- X-ray field covering all AEC fields but smaller than the Phantom.
- Grid mounted (If more than one Grid is available, mount the one with the highest Ratio).
- Center field

Installation

Start-up procedure

1. Make an exposure.
2. Note the resulting EI value.
Make sure the post exposure time is between 30–100 ms, adjust tube mA if necessary
3. Adjust the master gain on the generator AEC board and repeat the procedure until the right EI value is reached.
A suitable value is 180.




Fig. 4-178 AEC setup and calibration

KV compensation calibration

1. Repeat the *Determination of AEC cut off EI* procedure, with the KV levels (except 75 KV) shown in Fig. 4-178 AEC setup and calibration, using the phantom sizes in the table:

| KV | Acrylic Phantom (cm) |
|-----|----------------------|
| 50 | 10 |
| 55 | 10 |
| 65 | 10 |
| 75 | 15 |
| 85 | 15 |
| 95 | 15 |
| 110 | 20 |
| 130 | 20 |

2. For every KV level (except 75 KV), adjust the corresponding dialog box value until the correct EI is reached.
3. Make sure the post exposure time is between 30–100 ms, adjust tube mA if necessary.

4. Repeat for both the table and wall stand.
Remember to adjust the SID according to the grid focal distance when changing between table and wall stand.


4.7 Image system

For further information, see the *Image system manual*.

4.8 Configuring the protocol settings in Protocol Editor

For Configuring the protocol settings in Protocol Editor, see the *Image System Service Manual*, Chapter “Configuration”.

4.9 DAP test



$$k = \frac{D \cdot c \cdot d \cdot ((a-b)/a)^2}{\text{DAP}}$$

Fig. 4-179 DAP test

- a Focus distance (cm)
 - b Distance to active detector area of air kerma meter (cm)
 - c Height of xray (cm)
 - d Width of xray (cm)
 - e Active detector area air kerma meter
 - f focus
- k= DAP correction factor, where DAP = DAP value (mGycm²)
- D = Measured dose with air kerma instrument (mGy)

A DAP value test is performed at manufacture and needs to be checked again after the installation. The DAP shall be tested in accordance with the hospital-preferred settings.

If adjustment is needed:


1. Open Genware MP (CPI generator software, typically installed on image PC) and connect to generator, using the same wired connection as during normal communication between image PC and generator. No extra cable or tools required.

Note! _____

Canon NE must be turned OFF



2. Select the DAP-menu (A) to open the DAP Setup window:



3. Set the Calibration Value (B) to the measured reference value.
4. Press Apply (C) to activate the change.

Installation

Install table top

4.10 Install table top

Note!

When sliding the table top in place, make sure the friction pads of table top brakes aren't damaged.

1. Remove one of the table top end stops.
2. Switch on the power to the table and release the X/Y brake.
3. Press the brake pad against the magnets. Keep the brakes released (button pressed) when carefully sliding the table top in place.
Rail (B) has to be installed on the front.
4. Install the mechanical stop (A), use Loctite 243. Tighten the bolts with 24 Nm.
5. Check that the table top runs smoothly.
6. Check that the brakes are working in a correct way.
7. Check that the table top runs smoothly. If not, see .

Note!

Be aware of the difference between the two rails (A) and (B).




Fig. 4-180

4.11 Automatic collimator test

1. Check collimator handlebar functions.
2. Check collimator function for top/bottom alignment.
3. Check collimator light on/off signal (typical from table top release).

Installation

Display test

4.12 Display test




Fig. 4-181

1. Enter the Display node view, see Fig. 4-181 .
2. The system is automatically set to disable to inhibit any movements during tests.
3. Press a button on the system handlebar.
4. The corresponding "LED" turns green and stay green as long as the button is pressed.
5. Press the Beep button and the display beeper sounds for short time.
6. Press the Laser button and the handlebar laser is activated for approximately three seconds.
7. Press the Back light button and the display back light is turned off or on.

Note! —

The laser and the back light is set to a normal state when the view is closed.

4.13 System communication

System communication is configured at the manufacture. See Chapter 5 *Setup* for details.

4.14 Image quality test

The image quality shall be tested when the system is finally installed.

For further information, see the *Image System Manual*.

4.15 Send installation report to Arcoma service

Fill in the Installation Report and send it to Arcoma Service; service@arcoma.se

Installation

Send installation report to Arcoma service

5 Setup

5.1 Computer network settings

Make sure that the 0072 system is connected to the Canon NE PC (Ethernet cable). See *SBD_1000_C* for reference.




Fig. 5-1

1. Open the “Network and Sharing Center” from the “Control Panel”.
2. Click the Connection name, can be other than “Local Area Connection 2” as in Fig. 5-1 .

Setup

Computer network settings




Fig. 5-2

3. Press Properties.




Fig. 5-3

4. Select Internet Protocol Version 4 (TCP/IP) and press Properties.

Setup

Computer network settings




Fig. 5-4

5. Enter settings for the IP address as in Fig. 5-4 . Press OK.

5.1.1 Canon software IP settings




Fig. 5-5

1. Start Canon Service tool
2. Select X-Ray Generator.




Fig. 5-6

3. In Operation setting :
 - **Select** Synchronize the detector with the generator to perform exposure
 - **Select** Communicate with the generator
4. In Connection setting:
 - **Set Local IP addresses and ports** according to Fig. 5-6 .
 - **Set Response timeout (ms) to 15000.**
5. In Option setting :
 - **Select** Enable overwrap
Press **Browse** at line Overwrap module path and **select: C : \CXDI_NE_Overwrap \ExposureCondition.exe.**
 - **Select** Enable image information notification after the radiography”
6. Press OK.

5.1.2 Generator settings




Fig. 5-7

1. Select tab `General`
2. Check `Version information` to confirm that the version corresponds with the 0072 software. See Release Note *SwRLN_0072-C_System_x.x* for further reference.
3. Start the generator control software: `GenConfig.exe` (folder `C:\CXDI_NE_Overwrap\`)




Fig. 5-8

4. Select tab Receptors.
5. Check all receptors active in the system, and select an icon.
Grid detection via CMP200 Hardware inputs is not used.

Setup

Computer network settings




Fig. 5-9

6. Select tab `Network`.
7. The network settings shall be configured according to Fig. 5-9 .




Fig. 5-10

8. Select tab `Licensed Features`.
9. The licensed features settings shall be configured according to Fig. 5-10 .
Depending on the license installed in the system, some features may not be available.

Setup

Static protocol setup

5.2 Static protocol setup




Fig. 5-11

1. Enter Canon ServiceTool.
2. Select Utility Setting/Protocol Editor.





Fig. 5-12

3. Define a protocol. Press Add.



New protocol - (1/4)

Property

Protocol name: Chest AP

Comment:

Mark Placement

☐ L Preset position: Middle center

☐ R Preset position: Middle center

☐ Use this marks as DICOM Laterality attribute(0020,0062).
It sets Unpaired when none or both of the laterality marks are placed.

DICOM Attribute

Modality: DX

Body part:

Patient orientation: L/F

Laterality: L


View Position:

Series description:

Next >> Cancel

Fig. 5-13

- Assign a Protocol name to the new protocol. Press Next.



New protocol - (2/4)

Default workspace: Det 50G WS

Workspace information

Position type: Stand

Detector group: 50G

Detector:

| Model Name | Serial number | Detector group |
|------------|---------------|----------------|
| CXD150G | 1040023c | 50G |

Source image receptor distance (SID): mm

Source object distance (SOD): mm

Exposure type: Static

Grid detectability type: Existence or nonexistence

Grid ID: None

<< Back Next >> Cancel

Fig. 5-14

- Select an appropriate Default Workspace.
- Select Static as Exposure Type.
Press Next.

Setup

Static protocol setup

Fig. 5-15 Intuition system parameters

7. Define Exposure parameters for the new protocol.

For Auto positioning functionality, the following settings are important:

- Define the appropriate `Receptor` number.
 - 1- Table, 2- Free, 3- Wall stand, 4- Free
- Set `AutoPosition` On to YES.
- Define the appropriate `Auto Position` number.
- Define an `Auto Pos Offset`, if applicable
- Define a `Detector` angle value, if applicable.

For Automatic collimator functionality, the following settings are important:

- Set `Filter` On to YES.
- Define the appropriate `Filter` number.
- Set `Collimator` On to YES.
- Define `CollimatorWidth` and `CollimatorHeight` (mm). Values are limited by actual detector size.
- Set `CollimatorCentering`, if required.

Note!—

Settings for `SID` on and `GridInfo` are not used.

5.3 Stitching protocol setup (option)




Fig. 5-16

1. Enter Canon Service Tool.
2. Select System Setting/Application Setting.




Fig. 5-17

3. Select **Stitch image** and confirm that settings are according to Fig. 5-17 .

Setup

Stitching protocol setup (option)




Fig. 5-18

4. Define a stitching protocol, press Add.




Fig. 5-19

5. Assign a Protocol name to the new protocol.
Press Next.

New protocol - (2/4)

Default workspace: Det: 50G WS

Workspace information

Position type: Stand

Detector group: 50G

Detector:

| Model Name | Serial number | Detector group |
|------------|---------------|----------------|
| CXDI50G | 1040023c | 50G |

Source image receptor distance (SID): mm

Source object distance (SOD): mm

Exposure type: Static

Grid detectability type: Existence or nonexistence

Grid ID: None

<< Back Next >> Cancel

Fig. 5-20

6. Select an appropriate Default Workspace for the protocol.
7. Select **Static** as Exposure Type.
Press **Next**.

Setup

Stitching protocol setup (option)




Fig. 5-21

8. Define Number of images included in the stitching sequence.

It is better to define one image more than expected than too few images. Based on the size of the region of interest the system will calculate the number of images needed and remove protocols for images that are not exposed.

Press Next.

A stitching protocol is now defined containing the number of protocols (Radiography) corresponding to the selected number of images.

Exposure values shall be defined for all included protocols/images.

Setup

Stitching protocol setup (option)




Fig. 5-22 Intuition system parameters

9. Define exposure parameters for the first protocol/image.
10. First protocol (Radiography 1):
 - Define exposure parameters using the same method as for static protocols.
 - For stitching functionality, the following settings are important:
 - Set AutoPosition On to YES
 - Define the appropriate Auto Position number
 - Set Collimator On to YES.
 - Define Collimatorwidth and Collimatorheight (limited by actual detector size).
 - Leave SID On set to NO

Setup

Stitching protocol setup (option)

| NAME | Very Small | Small | Medium | Large |
|---------------------|----------------|----------------|----------------|----------------|
| Rad mA | 50.0 | 200.0 | 200.0 | 200.0 |
| ms | 10.0 | 80.0 | 80.0 | 80.0 |
| Technique | MA/MS | MA/MS | MA/MS | MA/MS |
| Film | Film Screen 1 | Film Screen 1 | Film Screen 1 | Film Screen 1 |
| Focus | SMALL | SMALL | SMALL | SMALL |
| Left Field | NO | NO | NO | NO |
| Center Field | YES | YES | YES | YES |
| Right Field | NO | NO | NO | NO |
| Receptor | 1 | 1 | 1 | 1 |
| Density | 0 | 0 | 0 | 0 |
| AEC Fields Orient. | 1-2-3 Portrait | 1-2-3 Portrait | 1-2-3 Portrait | 1-2-3 Portrait |
| AutoPosition On | NO | NO | NO | NO |
| Auto Position | 0 | 0 | 0 | 0 |
| Auto Pos Offset | -999999 | -999999 | -999999 | -999999 |
| Receptor Ori. On | NO | NO | NO | NO |
| PortraitLandscape | Portrait | Portrait | Portrait | Portrait |
| Filter On | NO | NO | NO | NO |
| Filter | 0 | 0 | 0 | 0 |
| Collimator On | YES | YES | YES | YES |
| CollimatorWidth | -1.0 | -1.0 | 300.0 | -1.0 |
| CollimatorHeight | -1.0 | -1.0 | 600.0 | -1.0 |
| CollimatorCentering | N/A | N/A | N/A | N/A |
| SID On | YES | YES | YES | YES |
| SID | 150.0 | 150.0 | 150.0 | 150.0 |

Fig. 5-23

11. Following protocols (Radiography 2-4):

- Set AutoPosition On to YES
- Define the appropriate Auto Position number
- Set Collimator On to NO
- Leave SID On set to NO

Setup

Stitching protocol setup (option)

| | NAME | Very Small | Small | Medium | Large |
|---|---------------------|----------------|----------------|----------------|----------------|
| | Rad kV | 40 | 68 | 76 | 84 |
| | Rad mA | 50.0 | 200.0 | 200.0 | 200.0 |
| | ms | 10.0 | 80.0 | 80.0 | 80.0 |
| | Technique | MA/MS | MA/MS | MA/MS | MA/MS |
| | Film | Film Screen 1 | Film Screen 1 | Film Screen 1 | Film Screen 1 |
| | Focus | SMALL | SMALL | SMALL | SMALL |
| | Left Field | NO | NO | NO | NO |
| | Center Field | YES | YES | YES | YES |
| | Right Field | NO | NO | NO | NO |
| | Receptor | 1 | 1 | 1 | 1 |
| | Density | 0 | 0 | 0 | 0 |
| | AEC Fields Orient. | 1-2-3 Portrait | 1-2-3 Portrait | 1-2-3 Portrait | 1-2-3 Portrait |
| | AutoPosition On | NO | NO | NO | NO |
| | Auto Position | 0 | 0 | 0 | 0 |
| | Auto Pos Offset | -999999 | -999999 | -999999 | -999999 |
| ▶ | Receptor Ori. On | NO | NO | NO | NO |
| | PortraitLandscape | Portrait | Portrait | Portrait | Portrait |
| | Filter On | NO | NO | NO | NO |
| | Filter | 0 | 0 | 0 | 0 |
| | Collimator On | NO | NO | NO | NO |
| | CollimatorWidth | -1.0 | -1.0 | -1.0 | -1.0 |
| | CollimatorHeight | -1.0 | -1.0 | -1.0 | -1.0 |
| | CollimatorCentering | N/A | N/A | N/A | N/A |
| | SID On | NO | NO | NO | NO |
| | SID | -1.0 | -1.0 | -1.0 | -1.0 |
| * | | | | | |

3523

Fig. 5-24

Setup

Stitching protocol setup (option)

6 Maintenance

6.1 General



WARNING!

Before working with service and maintenance that does not require power: Turn off the power and lock the main switch.



WARNING!

High voltage!

Risk of serious personnel injury or death!

Only trained service technicians may install, service and maintain the product.

No unauthorized personell may remove any covers.



WARNING!

Risk of electrical shock.

If covers are removed, live parts are exposed.



WARNING!

Squeezing hazard can occur between the vertical lift segments when moving in Z-direction.



WARNING!

Squeezing hazard can occur between detector holder and detector wagon when tilting the detector holder.



WARNING!

Reduced safety when intentionally disabling of safety mechanism.

Maintenance

General



WARNING!

Remaining energy may exist when the equipment is switched off.

Wait at least 15 seconds before working on the system.



WARNING!

Be aware of possible squeezing hazards when the covers are removed.

CAUTION!

When the mini console is turned OFF, the detector holder cannot be moved up or down using the brake release for Z-movement.

The detector holder must be fixed to the main unit frame while the parts of the detector holder are being replaced.

CAUTION!

Use gloves when in contact with grease.

Note!

For maintenance of components attached to the system (tube, generator, collimator etc.), refer to chapter 1 and system documentation.

This chapter contains the instructions necessary for annual maintenance:

- Alignments and settings
- Preventive maintenance
- Performance testing

To guarantee the safety of the patient and to ensure the functions and availability, the operator and third parties shall follow the instructions in this chapter.

If any malfunction is detected, the entire equipment must be taken out of use until the malfunction is eliminated or usage of the system is approved by a service technician from the supplier or by the local technical staff trained by the supplier.

The Manufacturer recommends use of the 16 *Appendix B*, Page 535.

Annual checks shall be performed either by local technical staff trained by the supplied or authorized service representatives. Daily and monthly checks are normally performed by the user/operator and is found in the Operation Manual.

6.2 Generator

Refer to the *Regular Maintenance* chapter of the Generator manual.

Maintenance

Imaging system

6.3 Imaging system

Refer to the Canon Manual Service documentation.

6.4 Detector

Refer to the Canon Manual Service documentation.

6.5 OTC

1. Clean all wheel tracks.
2. Clean all wheels.
3. Check that the installation bolts for the ceiling rails are tightened with 47 Nm.
Check the rest of installation, all the way up to the ceiling.




Fig. 6-1

4. Check the installation bolts (12 pcs) for the transverse rails with an Allen key.

Note! _____

Do not turn the bolts if they are not loose. They are fastened with Loctite.

If the bolts are loose, they shall be tightened with 47 Nm. Use Loctite 243.




Fig. 6-2

5. Check the installation bolts (8 pcs) for the Z-column with an Allen key.

Note! _____

Do not turn the bolts if they are not loose. They are fastened with Loctite.

If the bolts are loose, they shall be tightened with 47 Nm. Use Loctite 243.




Fig. 6-3

6. Check the installation bolts (4 pcs) for the turning plate with an Allen key.

Note! _____

Do not turn the bolts if they are not loose. They are fastened with Loctite.

If the bolts are loose, they shall be tightened with 9.8 Nm. Use Loctite 243.

To reach the bolts, remove the cover under the horizontal turning plate, the gearbox and the magnets, see Fig. 4-96 .

Then the two bolts are visible (A).




Fig. 6-4

Turn the plate 90° and the other two bolts comes visible (B).

Remove the magnet and check the installation bolts (C, 4 pcs) for the attachment flange.




Fig. 6-5

After the installation, check the Beta according to *Calibration of Beta-axis*, Page 219.

7. Check the wedge-lock between the tube and collimator installation. You should be able to move the collimator 45° without any play.
8. Remove the cover and check that the belt is tightened. The tooth belt can be flexible ± 2 mm. If the tooth belt has to be tightened see the instruction below.

The tooth belts are adjusted by the Manufacturer, and normally no further adjustments are needed.




Fig. 6-6

- Loosen the bolt (B).
 - Turn the eccentric bolt (C).
 - The tooth belt (A) should be flexible ± 2 mm.
- If the tooth belt is too tight, the alpha will be heavy to move manually.
9. Check the lifting cord for damage and make sure that it runs smoothly. It might be subject for exchange when tension gets to low.




Fig. 6-7

10. Check all outer cabling for damage.
11. Check the protective earth resistance, refer to for further instructions. Measure protective earth resistance on open metal on the following points:
 - X-ray tube
 - collimator
 - alpha (1.3 PE)
 - display
 - alpha/beta arm (1A PE)
 - column phase
 - ceiling wagon
 - frequency converter plate
 - electrical plate
 - electrical plate 1.1 traverse
 - traverse wagon Y
 - Measure according to IEC 60601-1
 - Measurement on more points may be needed depending on the installation




Fig. 6-8 Measure points, protective earth.

1. Display
2. Tube

- | | |
|---------------------------|------------------------|
| 3. Column phase | 5. Alpha (1.3 PE) |
| 4. Alpha/Beta arm (1A PE) | 6. Collimator (Option) |




Fig. 6-9 Measure point, protective earth traverse wagon Y.

1. Traverse wagon Y




Fig. 6-10 Measure points, protective earth ceiling wagon.

- | | |
|----------------------------------|------------------------------|
| 1. Electrical plate | 3. Frequency converter plate |
| 2. Electrical plate 1.1 traverse | 4. Ceiling wagon |

12. Measure leakage current ≤ 0.5 mA. Measure according to IEC 60601-1.

13. Test the emergency buttons and see that they work properly.

See *Chapter 2 "Safety"* for description on how the emergency stop should react on command.

14. Check the guard function with a force gauge. Fix the force gauge to the manoeuvre handle and resist when the OTC runs upward respective downward.

The guard function shall activate by $170 \text{ N} \pm 30 \text{ N}$.

If the guard function activates by $170 \text{ N} \pm 30 \text{ N}$ adjust the guard function according to 4.6.13.10 *Calibration of guard function (Z-axis)*, Page 245.


15. Check the column segments (full stroke). The column should run smooth and silent.
Observe that the column normally have a membrane of oil, see paragraph 25.
16. Check that there are no oil leak from the gear box or motor.
If any of those problems occur, please contact dealer.
17. Check the brake for the column motor. The brake shall activate when:
 - the movements have stopped or
 - the emergency stop activates during movement.
18. Move the ceiling suspended unit manually to all positions and make sure it runs smoothly.
19. Check the read-outs for tube rotation. Turn the alpha and beta to the index stop and check that correct measurement is displayed.
20. Check the read-outs for the SID in a Table position. Measure between the X-ray tube focal spot and the active detector surface of the detector. The measured value shall correspond with the displayed value.
21. Check the read-outs for the SID in a Wallstand position. Measure between the X-ray tube focal spot and the active detector surface of the detector. The measured value shall correspond with the displayed value.
22. Check the buttons on the manoeuvre handle, they shall not be damaged or stuck when they are pressed. To check the function of the maneuver buttons use the service software, see 4.11 *Automatic collimator test*, Page 283.
23. Read and follow the chapter *Operating the System* in the *Operation Manual* .
 - Check that the OTC function according to the description.
 - Check all the functions and motorized movements.
 - Different installations could have different options installed.

Maintenance

Two column table

6.6 Two column table


1. Check the tightening of bolts fixing the table to the floor.
Tightening torque 25 Nm.
2. Check the function and clean the table top ball bearings.
Remove the table top.
The ball bearings shall be secured to the table and run smoothly.
3. Clean the table top profiles.



3541

Fig. 6-11

4. Clean the profiles for the image receptor tray and detector wagon wheels.



3540

Fig. 6-12

5. Check the cabling to the table top brakes.
Remove the cover.
Check the condition of the cables and the cable chain. Replace if necessary.




Fig. 6-13

6. Check the condition of the table top brake pads.
7. Check the X-Y function of the table top brakes.
 - a Install the table top, see .
 - b Release the table top brakes and place a dynamometer against the table top and push slowly.

The table top should run smoothly in X or Y direction, it must be possible to move the table top with a force under 30 N.
 - c Lock the brakes and place a dynamometer against the table top and push slowly.

No movement of the table top using a force under

X-direction < 200 N

Y-direction < 300 N

Turn off the power to the system and the table top shall be locked.

Adjust the brakes if necessary, see 6.6.1 *Y-brakes, adjustment*, Page 321 and 6.6.2 *X-brakes, adjustment*, Page 323.
8. Check the column segments on the table (full stroke).

The column segments should run smoothly without noise.

Lubricate the columns if necessary.

Use grease Castrol Alpha SP 220.
9. Check the buttons on the foot control X/Y/Z.

The buttons should not be damaged or get stuck when pressed.
10. Batteries in the wireless foot control (option).

The batteries shall be changed at a minimum once a year, see Table 6-1 *Battery Replacement*.

When changing the batteries, visually inspect the gasket for signs of degradation.
11. Check the table guard function (option).
 - a Fix a dynamometer to the table top.
 - b Lower the table.
 - c The guard function should activate when the force exceeds 200 N +/-70 N.

6.6.1 Y-brakes, adjustment

1. Move the rail up and down.

Maintenance

Two column table

- The brake plate should be aligned (A) with the brake unit.
- The wheel must be in contact with the brake plate.

When the distance between the brake unit and the brake plate is correct – the spring underneath the brake unit will lift up the brake unit. The small gap (approx. 1 mm) ensures the brake to work correctly.




Fig. 6-14

1. Brake plate
2. Brake unit
3. Wheel




Fig. 6-15

The brake force is depending on the distance between the magnets and the brake bar.

6.6.1.1 Low brake force or brake release problems

Larger distance in the rear end than in the front end will reduce the braking force.

The general distance between the brake unit and the brake plate is too large




Fig. 6-16

If the brake unit does not releases correctly and get stuck, adjust the distance:

1. Align the brake unit and the brake plate when the magnets are active (i.e. the brake is released).
2. Make sure the gap is approx. 1 mm underneath the brake unit.

6.6.1.2 High brake force

Larger distance in the front end than in the rear end will increase the braking force.

The general distance between the brake unit and the brake plate is too small.

The table top tends to jam when the brake unit is released.

1. Align the brake unit and the brake plate when the magnets are active (i.e. the brake is released).
2. Make sure the gap is approx. 1 mm underneath the brake unit.

6.6.2 X-brakes, adjustment

The brake force is depending on the distance between the magnets and the brake bar.




Fig. 6-17

1. Brake unit
2. Table top frame
3. Shim
4. Table top profile
5. Brake Lining
6. Wheel
7. Distance between the brake unit and the table top

6.6.2.1 Low brake force or brake release problems

Larger distance in the rear end than in the front end will reduce the braking force.

The general distance between the brake unit and the brake plate is too large

If the brake unit does not releases correctly and get stuck:

1. Add another shim underneath the brake unit.
2. Make sure the gap is approx. 1 mm underneath the brake unit.

6.6.2.2 High brake force

Larger distance in the front end than in the rear end will increase the braking force.

The general distance between the brake unit and the brake plate is too small.

The table top tends to jam when the brake unit is released.

1. If the brake releases correctly, the distance between the brake unit and the table top profile is too small.
Remove shim from underneath the brake unit to increase the distance.
2. If the brake doesn't release correctly the distance is too big
Add shims to the brake.

6.7 Wall stand

1. Check the tightening of bolts fixing the wall stand to the floor.
Tightening torque 15 Nm.
2. Check the Z-chain attachment.
 - a Remove the front, back and top cover, see .
 - b Check the chain locks A and B.
 - c Check the circlips at the fastening of the axis C.




Fig. 6-18

3. Check the Z movement.
The lift mechanism should be balanced and run smoothly without noise.
4. Check the Z-mechanical end stops.
 - a Check the position and condition of the end stops.
There are four end stops, two at the top and two at the bottom of the column.
5. Check the function of the Z-brake.
 - a When in idle mode (Z-brake active), use a dynamometer to measure the force needed to move the detector wagon.
No movement of the detector wagon using a force under 200 N .
 - b The detector wagon should run smoothly when the brake is released.
6. Batteries in the wireless foot control (option).
The batteries shall be changed at a minimum once a year, see Table 6-1 *Battery Replacement*.


When changing the batteries, visually inspect the gasket for signs of degradation.

7. Check the buttons on the foot control Z.

The buttons should not be damaged or get stuck when pressed.

6.7.1 Tilttable wagon

8. Check the function of the detector tilt.



For service purposes, the WS detector tilt axis can be manually operated.

- Disconnect 3.1J14 from 3.1J14A and connect it to 3.1J14B.
Switch 3.1SW01 can now be used to move the Tilt axis in positive and negative direction.

Note! _____

Be careful when moving the Tilt axis from 3.1SW01. Safety features are disabled.

Note! _____

Re-connect 3.1J14 to its original position after service intervention.

6.8 System

1. Measure the system protective earth.
See 4.2 *Measure protective earth*, Page 170.
2. Check the emergency stops.
See 2.9 *Emergency stop*, Page 22.
1. Check the synchronization circuit.
 - a Press the synchronization control (1) on the wall stand. The diode D17 (2) on 1.5SBB01 shall light up.
The diode shall not light up when the synchronization control is deactivated.




Fig. 6-19

- b Press the foot pedal (if present), the diode D17 (2) on 1.5SBB01 shall light up.
The diode shall not light up when the foot pedal is deactivated.
2. Check the Z safety zone.

Drive the OTC and wall stand detector upwards as high as possible.

 - a Point the tube towards the detector at the wall stand.
 - b Activate the wall stand tracking and sync the OTC with the wall stand detector (confirm that the servo light is permanent on).
 - c Move the detector to the lowest position and the OTC shall follow the wall stand the whole stroke.

Deactivate wall stand tracking and point the tube towards the floor.

 - a Position the OTC over the table.
 - b Position the table top 700 mm over the floor.
 - c Activate the table tracking and sync the OTC with the table (confirm that the servo light is permanent on).
 - d Drive the OTC to SID 100, servo light is flashing.
 - e Drive the table downwards and the OTC shall follow the table and stop 1240 mm over the floor (the OTC Z safety height).

6.8.1 Check the positioning index of the OTC

1. Check the positioning index of the OTC.
 2. Check the table detector signals.
Activate the table tracking.
- No detector present
Remove the detector and slide in the detector holder tray.



Fig. 6-20 No detector present

- Detector present
Insert a detector and slide in the detector holder tray.



Fig. 6-21 Detector present

- Tray out of position (rotated)
Push/rotate the detector out of position when it is in the detector holder.




Fig. 6-22 Tray out of position

- Tray out of position
Pull out the detector tray from the detector holder.




Fig. 6-23 Tray out of position

3. Check the wall stand detector signals.
Activate the wall stand tracking.

- No detector present
Remove the detector and slide in the detector holder tray.



Fig. 6-24 No detector present

- Detector present
Insert a detector and slide in the detector holder tray.



Fig. 6-25 Detector present

- Tray out of position (rotated)
Push/rotate the detector out of position when it is in the detector holder.




Fig. 6-26 Tray out of position

- Tray out of position
Pull out the detector tray from the detector holder.




Fig. 6-27 Tray out of position

4. Check the table SID.
 - a Activate the table tracking and sync the system (confirm that the servo light is on).
 - b Measure between the X-ray tube focal spot and the active image receptor surface of the detector.
 - c The measured SID shall correspond with the displayed SID.
The SID must not differ more than $\pm 1\%$.
5. Check the indication light and collimator light.

Select table flexible mode on the image system:

- a Make sure the table indication light is lit or flashing and that the OTC display handle shows the corresponding mode.
- b Move the table top, the collimator lamp shall turn on.

Select wall stand flexible mode on the image system:

- a Make sure the wall stand indication light is lit or flashing and that the OTC display handle shows the corresponding mode.
 - b Move the wall stand Z up or down, the collimator lamp shall turn on.
6. Check the function of the AEC chamber.
See 4.6.25 *AEC calibration*, Page 273.
Calibrate if necessary.
 7. Verify the measured DAP value (Area dose:dGycm²).
 - a Measure the value with a dos meter.
 - b Calculate the dap value.
 - c Compare the calculated value to the image system value.
 8. Clean all outer surfaces.
 9. Disconnect the power plug and wipe off dust and dirt with a dry cloth.
 10. Check all outer cables for damage.
 11. Make sure that the Operation manual is present and up to date.

Maintenance






Battery replacement

6.9 Battery replacement

Batteries in wireless remote control and foot controls should be replaced annually.

6.9.1 Foot control

Table 6-1 Battery Replacement

| | |
|---|--|
| 1. Remove the screw covers using a small flat bladed screwdriver or similar. Un-screw the lid. |  |
| 2. Release the battery clip hinge by firmly, but carefully, prising the clip posts outward. |  |
|   | |
| 3. Fit the batteries, taking care to observe the polarity as marked on the PCB. Push the clip back into place by holding the sides of the clip. Do not push on the antenna when clipping back into place. | |
| 4. Screw the lid back into place- Press the screw covers back into place, using the flat part of the flat bladed screwdriver or alternatively. Loosely fit both covers. Press the whole assembly down onto a flat clean work surface. |  |

6.9.2 Remote Control




Fig. 6-28

Battery type 2 x 1,5V AAA / LR03

1. Turn OFF the transmitter
2. Remove the belt clip (2 screws)
3. Remove the back cover (3 screws)
4. Replace 2 x 1.5V AAA batteries
5. Remount back cover and belt clip.
6. Turn transmitter ON and confirm function.

6.9.3 Generator Control Board

Every five years:

- Replace the lithium battery on the generator control board. Refer to the generator manual for the battery replacement procedure. Battery type: Timekeeper SRAM

6.10 Software version / update

There are different software systems in the product.

1. Generator
2. Cabinet
3. Overhead tube support
4. Table
5. Wall stand

The software can be updated as described in the upgrade instructions, attached to the update document.

6.10.1 The software and its update location point

The software is physically located according to the table below:

| | System software | Connection point for software upload* | Upgrade instructions (UDI) |
|----|-----------------------|---------------------------------------|---|
| 1. | Cabinet | See upgrade instruction. | SwUDI_0180-4C_x_y_z.pdf |
| 2. | Overhead tube support | See upgrade instruction. | SwUDI_0180-4C_x_y_z.pdf |
| 3. | Table | See upgrade instruction. | SwRLN_0055_x_y_z-.pdf SwUDI_0180-4C_x_y_z.pdf and SwRLN_0181_x_y_Z.pdf |
| 4. | Wall stand | See upgrade instruction. | SwUDI_0180-4C_x_y_z.pdf |

7 Diagnostic

7.1 General

The OTC display will show error messages in case of fault.

7.1.1 Description

System messages are shown in the output view in the service software in the following format:

<Type><Node><Component><Reason><Extra>

Where:

- Type, defines the severity of the System message. This may be information, warning or error.
- Node, the node that sent the System message.
- Component, the component that caused the error.
- Reason, the cause of the message.
- Extra, four bytes of extra information. These bytes are always sent, even with messages that do not have any extra information.




Fig. 7-1

7.1.2 Error handling two column table

A node is always in a specified state. When all nodes are working correctly and no errors have been detected the system, and the nodes, are in the ENABLE state. It is only possible to perform active commands in this state, if a node is in some other state it is only possible to request information from a node. As soon as a problem is detected the node changes its internal state. In the system two different error states are specified; one that it's possible to recover from (ERROR) and one that is not (UNRECOVERABLE ERROR). One special state is the DISABLE state that is used to force a node to not perform any active commands. It is possible to change to ENABLE state with just one command, for example in case of an emergency stop button pressed.

It is also possible to check state of the node via the LED-indication on the control board of the node. The CB-board have a number of diodes (LED) that are used as indication on different states and events in the system, following is a description on each diodes value.




Fig. 7-2 Placement of the diodes on the CB-board.

| Diode 1 | Diode 2 | Node State | Priority |
|---------|---------|---------------------------|----------|
| Off | Off | Enable | 4 = Low |
| Off | On | Disable | 3 |
| On | Off | Startup/Init | 2 |
| On | On | NonRecoverableError/Error | 2 = High |

Diode 1 and 2 will indicate the node state.

Diode 3 shall toggle each time a message is received.

Diode 4 indicates that logic power exists.

The diode indication will always reflect the state priority for the physical node. A node that receives CAN messages for a number of nodes will indicate the state with the highest priority, for example if one logical node is in the enable state and the other is in the disable state shall the diodes show the disable state indication.

7.1.3 System message two column table

7.1.3.1 General

If the action says "Contact dealer" shall the entire error messages be noted and given to dealer.

That a valid System software release is used can be checked by the service software, the release should be shown in the lower right corner of the service software. It may also be checked by comparing the node and service software version shown in the service software with the versions stated in the RVL_0055S_SW document.

7.1.3.2 Description

A System message consists of the following parts, Type, Node, Component, Reason and Extra. Where:

- Type, defines the severity of the system message. This may be information, warning or error.
- Node, the node that sent the system message.
- Component, the component that caused the error.
- Reason, the cause of the message.
- Extra, four bytes of extra information. These bytes are always sent, even with messages that don't have any extra information. The extra information is shown as up to 4 parts, with the following format: <part number>:<description>< number of bytes used.>.

Definitions

The following ids are used to identify the node in a system message.

IDs used to identify the different nodes in a system message

| Node | Id |
|--------|----|
| Master | 1 |
| Z1 | 2 |
| Z2 | 3 |
| Guard | 4 |

7.1.3.3 All Nodes

Component Id 01, Software Error

| Reason | Description and status of System | Extra | Corrective action |
|-------------------|----------------------------------|-------|--|
| 01, Default error | Internal Software error. | N.a. | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 02, Error Value | Internal Software error. | N.a. | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |

Component Id 02, Base Node

| Reason | Description and status of System | Extra | Corrective action |
|----------------------|---|--|--|
| 01, Watchdog timeout | The node has detected that a watchdog was not received in time. | 1: Component. 1 byte. 2: Time-out time in ms. 2 bytes. | <ul style="list-style-type: none"> - Check that all nodes are functional. - Check that the CAN bus cables are correctly connected. |
| 02, Checksum error | The node has detected a checksum error in the parameter memory. | 1: The calculated checksum. 1 byte. 2: Stored inverted checksum. 1 byte. 3: Stored checksum. 1 byte. | <ul style="list-style-type: none"> - Download the correct parameter file. - Change board. |

| | | | |
|---------------------|--|---|--|
| 03, Unknown command | The node has detected a CAN command that is not implemented in the node. | 1: The unknown command. 1 byte. 2: Sender part of the CAN identifier. 2 bytes. | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 04, Logic power low | The node has detected that the logic power is low. | Not used. | <ul style="list-style-type: none"> - Check the 24 V logic voltage, measure at the logic power connector to the board. |

7.1.3.4 Motor Nodes

Definitions

The following collision types is defined.

Table 7-1 Description of the different collision types

| Collision type | Description | Corrective action |
|----------------|--|---|
| 1 | Control error larger than specified by the "max position error" parameter. | <ul style="list-style-type: none"> - Remove any blocking obstacle. - Check the mechanics. - Check that the correct parameter file is used. |
| 2 | Time out, did not reach final position in time. | <ul style="list-style-type: none"> - Remove any blocking obstacle. - Check the mechanics. - Check that the correct parameter file is used. |
| 3 | No power, the power to the DC-board was switched off during a movement. | <ul style="list-style-type: none"> - Check the 36V power voltage (measure at the power connector to the DC-board). - Check the DC-board fuse. |
| 4 | Drive unit externally inhibited. | <ul style="list-style-type: none"> - Check that the voltage between J3:2-J3:6 and J3:3-J3:6 (on the DC-boards) are zero volts. |
| 5 | Position transducer has not moved, in spite that the output voltage has had an output voltage for a time. The voltage is specified in the "moved voltage" parameter and the time is specified in the "moved time" parameter. | <ul style="list-style-type: none"> - Remove any blocking obstacle. - Check the mechanics. - Check that the correct parameter file is used. - Check the potentiometer. |

Diagnostic

General

Component Id 03, Motor Node

| Reason | Description and status of System | Extra | Corrective action |
|----------------------------|---|----------------------------|--|
| 01, Transducer diff error | A motor node equipped with two position transducers, whose positions differs more than specified. | Not used. | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check the position transducers. |
| 02, Transducer not present | The position transducer is not connected to the node. | Not used. | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check the position transducer. |
| 03, Collision | A collision has occurred. | 1: Collision type. 1 byte. | <ul style="list-style-type: none"> - See Table 7-1 <i>Description of the different collision types</i> |
| 04, Encoder overflow | An encoder overflow has been detected. | Not used. | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check the encoder. - Contact dealer. |
| 05 Uncontrolled movement | An uncontrolled movement has been detected. | Not used. | <ul style="list-style-type: none"> - Check if it was an actual movement or just a false position reading that caused the uncontrolled movement. - Check the potentiometer. |

Component Id 04, Driver Error

| Reason | Description and status of System | Extra | Corrective action |
|-----------------------|--|-----------|---|
| 01, Servo on error | Failed to perform a servo on | Not used. | <ul style="list-style-type: none"> - Check the 36V power voltage. - Check the DC-board fuse. - Check that the voltage between J3:2-J3:6 and J3:3-J3:6 (on the DC-boards) are zero volts. |
| 02, Temperature error | Temperature of the driver is too high. | Not used. | <ul style="list-style-type: none"> - Let the DC-board cool off. |

| | | | |
|-------------------------------|--|-----------|--|
| 03, Shoot through error | Shoot through currents detected in the H-bridge of the driver. | Not used. | - Check for shortcuts in motor cabling and motor. Both between cables and toward chassis. - Change board. |
| 04, Output current error | Error with the output current from the driver. | Not used. | - Check the 36V power voltage. - Check the DC-board fuse. |
| 05, Output over voltage error | Error with the output voltage on the driver. | Not used. | - Check that the correct parameter file is used. - Contact dealer. |
| 06, Driver watchdog error | A watchdog error from the driver was detected. | Not used. | - Check that the correct parameter file is used. - Contact dealer. |
| 07, Communication error | Failed to communicate with the driver. | Not used. | - Check that the correct parameter file is used. - Contact dealer. |
| 08, Motor error | Error with the motor detected. | Not used. | - Check that the correct parameter file is used. - Contact dealer. |

Component Id3, CAN Driver Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 4, Timer Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 10, Communication Interface Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Diagnostic

General

Component Id 11, ACAN Component

| Reason | Description and status of System | Extra | Corrective action |
|------------------------------|---|-------|---|
| 01 Message not decoded | Internal software error. | | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 02 Add node reason | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 03 Bus off | CAN-bus error. | N.a | <ul style="list-style-type: none"> - Check that the CAN bus cables are correctly connected. - Check that the CAN bus cables aren't damaged. - Change boards. |
| 04 Bus off not present | A previously reported CAN error has now been cleared. | N.a | |
| 05 Error warning | CAN-bus error. | N.a | <ul style="list-style-type: none"> - Check that the CAN bus cables are correctly connected. - Check that the CAN bus cables aren't damaged. - Change boards. |
| 06 Error warning not present | A previously reported CAN error has now been cleared. | N.a | |
| 07 RX buffer overflow | Internal software error. | N.a | <ul style="list-style-type: none"> - Contact dealer. |
| 08 SJA1000 data overrun | Internal software error. | N.a | <ul style="list-style-type: none"> - Contact dealer. |

| | | | |
|-----------------------|--------------------------|-----|--|
| 09 Transmit error | CAN-bus error. | N.a | <ul style="list-style-type: none"> - Check that the CAN bus cables are correctly connected. - Check that the CAN bus cables aren't damaged. |
| 10 TX buffer overflow | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the CAN bus cables are correctly connected. - Check that the CAN bus cables aren't damaged. - Contact dealer. |

Component Id 12, ASAP Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 13, Data Reader Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 20, JMATH Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 21, Linked List Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Diagnostic

General

Component Id 30, Event Server Component

| Reason | Description and status of System | Extra | Corrective action |
|---------------------|----------------------------------|-------|--|
| 01 Add event reason | Internal software error. | N.a | - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |

Component Id 31, Event Source Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 32, Client Manager Component

| Reason | Description and status of System | Extra | Corrective action |
|----------------------|----------------------------------|-------|--|
| 01 Client id invalid | Internal software error. | N.a | - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 02 Add client reason | Internal software error. | N.a | - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |

Component Id 33, Call Back Receiver Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 34, System Message Manager

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 35, Time Out Server Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 36, Memory Manager Component

| Reason | Description and status of System | Extra | Corrective action |
|---------------------|----------------------------------|-------|--|
| 01 Memory exhausted | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |

Component Id 40, System Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 41, Master Component

| Reason | Description and status of System | Extra | Corrective action |
|----------------------------|----------------------------------|--------------------------------------|--|
| 01 Enable nodes timeout | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 02 Enable managers timeout | Internal software error. | 1: Line number in the code. 4 bytes. | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |

Diagnostic

General

| | | | |
|----------------------------|---|--------------------------------------|--|
| 03 Unexpected disable node | Internal software error. | 1: Line number in the code. 4 bytes. | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 04 Emergency stop | An emergency stop button was activated. | Not used. | <ul style="list-style-type: none"> - Release emergency button. |
| 06 Event queue overflow | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 08 Unknown node | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |

Component Id 42, Configuration Component

| Reason | Description and status of System | Extra | Corrective action |
|-----------------------|---|--|---|
| 01 Parameter checksum | An checksum error has been detected. | 1: The calculated checksum. 1 byte. 2: Stored inverted checksum. 1 byte. 3: Stored checksum. 1 byte. | <ul style="list-style-type: none"> - Download the correct parameter file. - Change board. |

Component Id 50, Movement Manager Component

| Reason | Description and status of System | Extra | Corrective action |
|---------------------|----------------------------------|-------|--|
| 01 Add movement | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 02 Unknown movement | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |

Component Id 51, Movement Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 54, Single Movement Component

| Reason | Description and status of System | Extra | Corrective action |
|----------------------|-----------------------------------|---|---|
| 01 Start not allowed | A start of a movement was denied. | 1: Start allowed result. 1 byte. 2: Movement direction. 1 byte. 3: Source id. 2 bytes, see tables at page 8-18. | <ul style="list-style-type: none"> - Check that the table top is levelled, this is checked by: Difference between Z1 and Z2 height (read in service software) should be less than 4 mm. - Use the service software to check the angle given from the tilt sensor. If appropriate calibrate the tilt sensor. |

Diagnostic

General

Component Id 55, Auto-position Component

| Reason | Description and status of System | Extra | Corrective action |
|------------------|---|--|--|
| 01 Movement fail | A start of an auto position movement failed | 1: Start allowed result. 1 byte. 2: Line number in the code. 3 bytes. | - Check that the table top is levelled, this is checked by: Difference between Z1 and Z2 height (read in service software) should be less than 4 mm. - Use the service software to check the angle given from the tilt sensor. If appropriate calibrate the tilt sensor. |
| 02 All paused | Internal software error. | N.a | - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |

Component Id 56, Brake Movement Component

| Reason | Description and status of System | Extra | Corrective action |
|------------------------------|--|---|--|
| 01 Incorrect configuration | The brake movement was told to start a directional movement. | 1: source id.4 byte. | - Check that a valid System software release is used. - Check the configuration. |
| 02 Unlock brakes not allowed | It was not possible to unlock the brakes. | 1: Start allowed result. 1 byte. 2: source id.3 bytes, see tables. | - Check that the table top is levelled. - Check the angle given from the tilt sensor. |

Component Id 57, Double Movement Component

| Reason | Description and status of System | Extra | Corrective action |
|--------------------------|-----------------------------------|---|--|
| 01 Start not allowed | A start of a movement was denied. | 1: Start allowed result. 1 byte. 2: Movement direction. 1 byte. 3: Source id. 2 bytes (see tables). | - Check that the table top is levelled, this is checked by: Difference between Z1 and Z2 height (read in service software) should be less than 4 mm. - Use the service software to check the angle given from the tilt sensor. If appropriate calibrate the tilt sensor. |
| 02 End set point timeout | Internal software error. | Not used. | - Contact dealer. |

Component Id 70, Supervisor Component

| Reason | Description and status of System | Extra | Corrective action |
|---------------------------------|--|--|--|
| 01 Table top alignment error | The table top is not level. | 1: Height difference between Z1 and Z2, in 0.1 mm. 4 bytes | - Press foot pedal until table top is levelled; this may require that the pedal is pressed more than once. |
| 02 Tilt sensor full movement | The tilt sensor does not prevent any movement. | 1: Table top angle (0.01°), given from the tilt sensor. 4 bytes. | |
| 03 Tilt sensor restricted angle | The tilt sensor does prevent movement. | 1: Table top angle (0.01°), given from the tilt sensor. 4 bytes. | - Press foot pedal until table top is levelled; this may require that the pedal is pressed more than once. - If table top is levelled (measure with water level) calibrate the tilt sensor. |
| 04 Guard crash detected | The guard board has detected a crash. | 1: Crash direction, 1 for a positive crash and 2 for a negative crash. 1 byte. | - Remove obstacle. |

Diagnostic

General

Component Id 80, Node Component

| Reason | Description and status of System | Extra | Corrective action |
|----------------------------------|----------------------------------|-------|--|
| 01 Message decode | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 02 Communication not established | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |

Component Id 81, Slave Node Component

| Reason | Description and status of System | Extra | Corrective action |
|--------------------------|----------------------------------|---|--|
| 01 watchdog timeout | A watchdog timeout occurred. | 1: Source id. 1 byte. 2: Line number in the code. 2 bytes. | <ul style="list-style-type: none"> - Check the state of the node (shown I service software). - Check the LED's on the board (for error indication). |
| 02 Unexpected node state | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 03 Set state failed | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 04 Acknowledge status | Internal software error. | N.a | <ul style="list-style-type: none"> - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |

| | | | |
|-----------------|--------------------------|-----|--|
| 05 Init timeout | Internal software error. | N.a | - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |
| 06 Node ready | Internal software error. | N.a | - Check that the correct parameter file is used. - Check that a valid System software release is used. - Contact dealer. |

Component Id 82, Motor Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 83, Guard Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 90, Foot Pedal Component

| Reason | Description and status of System | Extra | Corrective action |
|------------------------------|----------------------------------|---|---------------------|
| 01 Switch active at start up | A pedal was active at start up. | 1: Current foot pedal input status. 4 bytes. The following masks are used: Z up 0x0000 0001 Z down 0x0000 0002 X brake 0x0000 0004 Y brake 0x0000 0008 XY brake 0x0000 0200 DMG 0x0000 0100 | - Check foot pedal. |

Diagnostic

General

| | | | |
|--------------------------------|---|-----------|--|
| 01 Switch active at start up | The time between activation/deactivation of the Z up/down and the dmg switch was too large. | Not used. | - Check foot pedal. |
| 03 Switch function deactivated | The activated switch functionality was deactivated. | Not used. | - Some earlier error caused that this function has been deactivated. |

Component Id 91, Tilt Sensor Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

Component Id 93, Emergency Switch Component

| Reason | Description and status of System | Extra | Corrective action |
|---|--|---|---------------------------------|
| 01 Switch active at start up | An emergency switch was active at start up. | 1: Current emergency switch input status. 4 bytes. The following masks are used: Internal 0x00000400 External 0x00000800 | - Check the emergency switches. |
| 02 Internal emergency switch is activated | The internal emergency switch was activated. | Not used. | |
| 03 External emergency switch is activated | The external emergency switch was activated. | Not used. | |
| 04 Emergency switch released | The last emergency switch was deactivated. | Not used. | |

Component Id 94, ASAP Client Component

| Reason | Description and status of System | Extra | Corrective action |
|--------|----------------------------------|-------|-------------------|
| N.a. | | | |

7.1.3.5 Master Node

Definitions

The information in the tables below refer to the notes in the column “Extra” in the tables above.

Table 7-2 IDs used to identify the movements.

| Movement ID | Number | Description |
|------------------------|--------|--|
| Z1 movement | 0 | Z1 column |
| Z2 movement | 1 | Z2 column |
| Table top x movement | 2 | Table top X-direction |
| Table top y movement | 3 | Table top Y-direction |
| Table top movement | 16 | Table top Z-direction |
| Auto-position movement | 32 | Auto-positioning table top Z-direction |

Table 7-3 IDs used to identify the different parts within the master.

| Source ID | ID |
|------------------------|----|
| None | 0 |
| Internal | 1 |
| Supervisor | 2 |
| System | 3 |
| Master | 4 |
| Movement manager | 10 |
| Movement Z1 | 11 |
| Movement Z2 | 12 |
| Movement table top X | 13 |
| Movement table top Y | 14 |
| Movement table top | 15 |
| Movement auto-position | 16 |
| System message manager | 30 |
| Motor Z1 | 40 |
| Motor Z2 | 41 |
| Guard | 42 |
| Foot pedal | 50 |

Diagnostic

General

| | |
|------------------|----|
| Emergency switch | 51 |
| Tilt sensor | 52 |
| CLI handler | 60 |
| ACAN client | 61 |

Table 7-4 IDs used to identify the different start allowed results.

| Movement | Number | Description |
|-------------------------------|---------------|------------------------|
| OK | 0 | Ok to start. |
| Supervisor not enabled | 1 | |
| Auto-position already started | 2 | |
| Tilted | 3 | Table top not level. |
| Crash | 4 | Guard crash active. |
| Error | 5 | An error has occurred. |

Table 7-5 IDs used to identify the different movement directions.

| Movement | Number | Description |
|--------------------|---------------|----------------------|
| No direction | 0 | Ok to start. |
| Positive direction | 1 | |
| Negative direction | 2 | |
| Unknown direction | 3 | Table top not level. |

7.1.4 CB800-board

7.1.4.1 Fault handling

There are three types of notifications showing different events occurring, for example a collision. They are listed below in ranking order.

1. ERROR — The error information appears as a red bar in the lower part of the display. Sound; two beeps.
2. WARNING - Appears as a grey bar in the lower part of the display. Sound; one beep.
3. INFO - Not shown to the user. Only registered in the setting menu.

Notifications

- 1) Error

When an error occurs, an Error pop-up window will appear in the display.




Fig. 7-3 Error pop-up window

The Error pop-up window will disappear when the user pushes the close button.



Fig. 7-4 Close button

Diagnostic

General

When closing the Error pop-up window (Fig. 7-3 *Error pop-up window*), a red information bar will appear (see Fig. 7-5 *Error information bar, Table* and Fig. 7-6 *Error information bar, Wall stand*).




Fig. 7-5 *Error information bar, Table*




Fig. 7-6 *Error information bar, Wall stand*

When the user pushes the red information bar, the Error pop-up window will appear again. The Error information bar (lower part of the window) is present until the error is fixed or the system is restarted.

2) Warning

A warning message will appear in a Warning information bar (lower part of the display), when the handling of the system justifies that.

The Warning information bar will be cleared if/when a new warning is displayed, or after time.

The latest sent warning is shown.




Fig. 7-7 Warning information bar, Table




Fig. 7-8 Warning information bar, Wall stand

When pushing the Warning information bar, (see Fig. 7-7 *Warning information bar, Table* and Fig. 7-8 *Warning information bar, Wall stand*), a pop-up window will appear (see Fig. 7-9 *Pop-up window — Warning information bar* and Fig. 7-10 *Pop-up window — Information bar*).



Fig. 7-9 Pop-up window — Warning information bar

When the user closes the pop-up window, the Warning Information bar will appear again. The Warning pop-up window will also appear again, when the user pushes the information bar.




Fig. 7-10 Pop-up window — Information bar

The *Warning pop-up window* disappears when the user pushes the close button.



Fig. 7-11 Close button










Log

The *Log file* is part of the *Setting menu* and reached by pressing the gear or the *Error/Warning messenger bars*.




CB800-board

General Description

The symbols in the table below are throughout this document used to show the different LED states.



| LED symbol | | Description |
|---|---|------------------------|
| Slow (1Hz) | Fast (5Hz) | |
|  | | Off. |
|  | | Constant green. |
|  | | Constant red. |
|  |  | Blinking green |
|  |  | Blinking red. |
|  |  | Alternating green/red. |

The top (first) LED is used to show the overall status of the board, the usage of the other three depends on the first.

| Top LED | Description | Limitations |
|---|---|---|
|  | Everything is ok, both software and hardware, the application is running. The usage of the other LEDs may be different for every board in the system. The System Manual shall for every board describe the usage of these LEDs. | None of the other LEDs may show constant or blinking red. |
|  | Reserved for Boot applications. | None of the other LEDs may show constant or blinking red. |
|  | The application (or bootloader) has encountered an error. The reason may be a hardware error but the error cause cannot be exactly pinpointed as a hardware error. The usage of the other LEDs may be different for every board in the System. The System Manual shall for every board describe the usage of these LEDs. | None |





Diagnostic

General

| Top LED | Description | Limitations |
|---|---|-------------|
|  | A hardware error has been detected. The usage of the other LEDs shall be identical for all boards in all Systems. | None |
|  | May be used to show that the application (or bootloader) has encountered an error. Constant red or alternating green/red should be used instead. | |

Hardware Error

The table below shows the LED indications for various hardware errors.

| LED | Description | Limitations |
|---|--|---|
|  | No bootloader image found. | This is shown by the bootstrap application. |
|  | RAM error. The memory test found an error in the SDRAM. | |
|  | NAND-flash error. A boot application image was found, but the image had a CRC error. This may also be an undetected SDRAM error. | |
|  | Processor internal error. | |

Second LED

| State | Description |
|-------------|---|
| Off | No connection with generator. |
| Solid green | Communication with generator established. |

Third LED

| State | Description |
|----------------|---|
| Off | No connection with ceiling system. |
| Flashing green | Communication with ceiling system established, ceiling system is not in "Enable" state. |
| Solid green | Communication with ceiling system established, ceiling system is in "Enable" state. |

Bottom LED


| State | Description |
|----------------|---|
| Off | No connection with IS. |
| Flashing green | Connected to IS but “ <i>StartCommunication</i> ” not yet received. |
| Solid green | Communicating with IS. |


8 Electrical drawings


| | | |
|----------|--|-----|
| 8.1 | System block diagram..... | 362 |
| 8.1.1 | System..... | 362 |
| 8.1.1.1 | 1000 System C..... | 363 |
| 8.1.2 | Image system | 365 |
| 8.1.2.1 | Image system C | 365 |
| 8.1.2.2 | CXDI TS and WS 401 or 701 Wireless | 367 |
| 8.1.2.3 | CXDI TS and WS 401 or 701C Wireless WS with charging | 369 |
| 8.1.2.4 | CXDI TS 401 or 701C Wireless and WS 401 compact..... | 371 |
| 8.1.2.5 | CXDI TS 401 or 701 CXDI TS 401 with charging and WS 401 or 701C wireless | 373 |
| 8.1.2.6 | CXDI TS and WS 401_701 wireless with charging | 375 |
| 8.1.2.7 | CXDI TS 401 701 wireless with charging and WS 401 compact..... | 377 |
| 8.1.2.8 | CXDI TS 401 compact and WS 401 or 701C Wireless | 379 |
| 8.1.2.9 | CXDI TS 401 compact and WS 401 Wireless with charging | 381 |
| 8.1.2.10 | CXDI TS 401 or 701C Wireless with charging and WS 401 or 701C Wireless | 383 |
| 8.1.2.11 | CXDI TS and WS 401 compact..... | 385 |
| 8.1.2.12 | CXDI TS and WS 401 compact 2 x free | 387 |
| 8.1.2.13 | CXDI TS 401C and WS 410 or 710C Wireless | 389 |
| 8.1.2.14 | CXDI TS 401C and WS 410 or 710C Wireless with charging | 391 |
| 8.1.2.15 | CXDI TS 410 or 710C Wireless and WS 401 compact | 393 |
| 8.1.2.16 | CXDI TS and WS 410 or 710C Wireless | 395 |
| 8.1.2.17 | CXDI TS and WS 410 or 710C Wireless, WS with charging | 397 |
| 8.1.2.18 | CXDI TS 410 or 710C Wireless with charging and WS 401 compact | 399 |
| 8.1.2.19 | CXDI TS 410 or 710C Wireless with charging and WS 410 or 710C Wireless | 401 |
| 8.1.2.20 | CXDI TS and WS 410 or 710C Wireless with charging | 403 |
| 8.1.3 | Subsystem | 405 |
| 8.1.3.1 | System 0073 2 | 405 |
| 8.1.4 | Overhead tube crane..... | 407 |
| 8.1.4.1 | Overhead tube crane..... | 407 |
| 8.1.5 | System cabinet | 409 |
| 8.1.5.1 | System cabinet | 409 |
| 8.1.6 | Two column table | 411 |
| 8.1.6.1 | Table 2 columns | 411 |
| 8.1.7 | Wall stand | 413 |
| 8.1.7.1 | Wall stand 0073 | 413 |
| 8.1.7.2 | Detector holder 14x17, top, center | 415 |
| 8.1.7.3 | Detector holder 14x17 or 17x17 | 417 |
| 8.1.7.4 | Detector holder 17x17 | 419 |
| 8.1.7.5 | Detector holder 17x17_fix | 421 |
| 8.2 | Unit block diagram | 423 |
| 8.2.1 | Image system | 423 |
| 8.2.1.1 | Image system C | 423 |
| 8.2.2 | Two column table | 425 |
| 8.2.2.1 | Bluetooth foot switch | 425 |
| 8.2.2.2 | Detector holder 14x17 | 427 |
| 8.2.2.3 | Detector holder 17x17 | 429 |
| 8.2.2.4 | Detector holder 17x17 Fix | 431 |
| 8.2.2.5 | Detector holder 14x17 17x17, table | 433 |
| 8.2.2.6 | Detector movement | 435 |
| 8.2.2.7 | Emergency stop | 437 |


Electrical drawings


| | | |
|----------|---|-----|
| 8.2.2.8 | Power..... | 439 |
| 8.2.2.9 | Table top brakes..... | 441 |
| 8.2.2.10 | Z Movement..... | 443 |
| 8.2.3 | Wall stand | 445 |
| 8.2.3.1 | Bluetooth foot switch | 445 |
| 8.2.3.2 | CAN | 447 |
| 8.2.3.3 | Detector holder 14x17, top, center | 449 |
| 8.2.3.4 | Detector holder 14x17 or 17x17, top, center | 451 |
| 8.2.3.5 | Detector holder 17x17 Fix | 453 |
| 8.2.3.6 | Detector holder 17x17 | 455 |
| 8.2.3.7 | Emergency stop | 457 |
| 8.2.3.8 | Handlebar..... | 459 |
| 8.2.3.9 | Power..... | 461 |
| 8.2.3.10 | Tilt drive..... | 463 |
| 8.2.3.11 | WS tilt, ind, top, bottom, R or L..... | 465 |
| 8.2.3.12 | Z-movement | 467 |
| 8.2.4 | OTC..... | 469 |
| 8.2.4.1 | Wiring diagram: OTC — WRD-0073—CS 2_p1..... | 469 |
| 8.2.4.2 | Wiring diagram: OTC — WRD-0073—CS 2_p2..... | 471 |
| 8.2.4.3 | Wiring diagram: OTC — WRD-0073—CS 2_p3..... | 473 |
| 8.2.4.4 | Wiring diagram: OTC — WRD-0073—CS 2_p4..... | 475 |
| 8.2.4.5 | Wiring diagram: OTC — WRD-0073—CS 2_p5..... | 477 |
| 8.2.4.6 | Wiring diagram: OTC — WRD-0073—CS 2_p6..... | 479 |
| 8.2.4.7 | Wiring diagram: OTC — WRD-0073—CS 2_p7..... | 481 |
| 8.2.4.8 | Wiring diagram: OTC — WRD-0073—CS 2_p8..... | 483 |
| 8.2.4.9 | Wiring diagram: Z Column — WRD_0070—003—250..... | 485 |
| 8.2.4.10 | Wiring diagram: Drive unit X-Y — WRD-0070—099—223 | 487 |
| 8.2.4.11 | Collimator control, AL02 | 489 |
| 8.2.4.12 | Collimator control OP30 | 491 |
| 8.2.4.13 | Remote control | 493 |
| 8.2.4.14 | DAP meter | 495 |
| 8.2.4.15 | X-ray tube | 497 |
| 8.2.4.16 | Display | 499 |
| 8.2.5 | System cabinet | 501 |
| 8.2.5.1 | AEC chamber | 501 |
| 8.2.5.2 | Collimator control | 503 |
| 8.2.5.3 | Generator system..... | 505 |
| 8.2.5.4 | Power 380V, 400V or 480V 3 phase, page 1 | 507 |
| 8.2.5.5 | Power 380V, 400V or 480V 3 phase, page 2 | 509 |








































































SBD_0073-TS_2_Det_H_14x17
SBD_0073-TS_2_Det_H_14x17x17
SBD_0073-TS_2_Det_H_17x17
SBD_0073-TS_2_Det_H_17x17_fix
JBD_0073-TS_BT_Z_foot_sw
JBD_0073-TS_Coll_handlebar
JBD_0073-TS_Det_move
JBD_0073-TS_EM_stop
JBD_0073-TS_2_Power
JBD_0073-TS_Table_top_brakes
JBD_0073-TS_Z-Drive









































































































ARCOMA AB
0470-706900


0073
1.X
Wiring diagram

| | | |
|-------------|----------|------------|
| Designed by | Drawn by | Sheet |
| MAT | MAT | 07 |
| Date | Rev | Next sheet |
| 2020-09-02 | 2.1 | 08 |











Revision notes! Proj.4202 ChangeCeil disp to J3.

This drawing is ARCOMAS property and shall not be copied or shown to third person without ARCOMAS permission.

Wire type.
If nothing else stated.
AWG 28-16 300V
AWG 14-1 600V

| | | | | | |
|--|--|--------------------------------------|-------------------------------------|---------------------------------------|----------------|
| Product 0073 | | Approved by - date MAT 2015-04-23 | | Signature - date | |
| Type of drawing Unit block diagram | | Drawn by MAT | | Checked by - date Signature - date | |
| Description Collimator Siemens AL02 | | | Drawing nr UBD_0073_CS_Coll_AL02 | | Sheet 1 / 1 |
| | | | Revision 2.1 | | |







Revision notes: ÄB0140523_01A


This drawing is ARCOMAS property and shall not be copied or shown to third person without ARCOMAS permission.


Wire type.
If nothing else stated.
AWG 28-16 300V
AWG 14-1 600V

| | | | | | |
|--|-----------------|--------------------------------------|--|------------------|--|
| Product 0073 | | Approved by - date MAT 2015-04-23 | | Signature - date | |
| Type of drawing Unit block diagram | Drawn by MAT | Checked by - date | | Signature - date | |
| Description Remote control ceiling suspended unit | | Drawing nr UBD_0073_CS_Remote | | Sheet 1 / 1 | |
| | | | | Revision 1.1 | |










Revision notes! 4202 Changed name to C, Change to 0055-750-011 at 2.DAID01

This drawing is ARCOMAS property and shall not be copied or shown to third person without ARCOMAS permission.

Wire type.
If nothing else stated.
AWG 28-16 300V
AWG 14-1 600V

| | | | | | |
|---|-----------------|--------------------------------------|--|------------------|--|
| Product 0073 | | Approved by - date MAT 2016-03-02 | | Signature - date | |
| Type of drawing Unit block diagram | Drawn by MAT | Checked by - date | | Signature - date | |
| Description AEC Chamber connected to generator | | | | Sheet 1 / 1 | |
| | | | | Revision 2.1 | |
| Drawing nr UBD_0073_AEC_C | | | | | |




Revision notes! See last page.

This drawing is ARCOMAS property and shall not be copied or shown to third person without ARCOMAS permission.

Wire type.
If nothing else stated.
AWG 28-16 300V
AWG 14-1 600V

| | | | | | |
|---------------------------------------|-----------------|-------------------------------------|--|--------------------------------|----------------|
| Product 0073 | | Approved by - date | | Signature - date | |
| Type of drawing Unit block diagram | Drawn by MAT | Checked by - date MAT 2013-08-06 | | Signature - date | |
| Description SC Collimator | | | | Drawing nr UBD_0073_SC_Coll | Sheet 1 / 1 |
| | | | | Revision 1.1 | |




Revision notes:
This drawing is ARCOMAS property and shall not be copied or shown to third person without ARCOMAS permission.


Wire type:
If nothing else stated:
AWG 28-16 300V
AWG 14-1 600V

| | | | | | |
|---|-----------------|--------------------------------------|--|-------------------------------|----------------|
| Product 0073 | | Approved by - date MAT 2020-05-11 | | Signature - date | |
| Type of drawing Unit block diagram | Drawn by MAT | Checked by - date | | Signature - date | |
| Description SC Generator - system. Variant C | | | | Drawing nr UBD-0073_SC_2_C | Sheet 1 / 1 |
| | | | | Revision 1.1 | |

Electrical drawings

Unit block diagram





9 Fuses

The fuses part number, size, type, designation and function are listed in the table below. Turn off the power to the product when removing and replacing fuses. Replace only with the exactly same type of fuses.

9.1 OTC

Fuse chart electrical plate 1.1

| Designation | Size | Type | Manufacturer | Function |
|-------------|------|--------------|--------------------|------------|
| 1.1F01 | 4AD | C60SP 1P D4A | Schneider Electric | 115V Freq. |
| 1.1F02 | 4AD | C60SP 1P D4A | Schneider Electric | 115V Freq. |
| 1.1F03 | 6AD | C60SP 1P C6A | Schneider Electric | 36V AC |
| 1.1F04 | 6AD | C60SP 1P C6A | Schneider Electric | 24V AC |

Fuse chart Display Unit

| Designation | Size | Type | Manufacturer | Function |
|-------------|------|--|--------------|--------------------|
| 1.3F01 | 1AT | 326 series - SloBlo ceramic body 6.3x32 mm | Littlefuse | Display 24 V power |

9.2 System cabinet

Fuse chart electrical plate 4.2

| Designation | Size | Type | Manufacturer | Function |
|-------------|------|---------------|--------------------|-------------------|
| 4.2F01 | C20A | C60SP 3P C20A | Schneider Electric | Mains power |
| 4.2F02 | C1A | C60SP 1P C1A | Schneider Electric | Internal 230 VAC |
| 4.2F03 | C6A | C60SP 2P C6A | Schneider Electric | Ceil 2x115 VAC |
| 4.2F04 | C6A | C60SP 2P C6A | Schneider Electric | Table 2x115 VAC |
| 4.2F05 | C6A | C60SP 1P C6A | Schneider Electric | Detectors 230 VAC |

9.3 Two column table

Fuse chart electrical plate 2.1

| Designation | Size | Type | Manufacturer | Function |
|-------------|------|--------------|--------------------|--------------|
| 2.1F01 | 6A | C60SP 1P C6A | Schneider Electric | 24 VDC Logic |

Fuse chart 2.1DC01 and 2.1DC02

| Designation | Size | Type | Manufacturer | Function |
|-------------|------|--|--------------|--------------------|
| 2.1DC01–F1 | 15A | 326 series - 3AG SloBlo glass body 6.3x32 mm | Littlefuse | 36 VDC motor power |
| 2.1DC01–F2 | 15A | 326 series - 3AG SloBlo glass body 6.3x32 mm | Littlefuse | 36 VDC motor power |

Fuses

Wall stand Z motorized

9.4 Wall stand Z motorized

Fuse chart 4.4FIB01 placed in the system cabinet

| Designation | Size | Type | Manufacturer | Function |
|-------------|------|--|--------------|----------------|
| 3.1F01 | 10AT | 326 series - 3AB SloBlo ceramic body 6.3x32 mm | Littlefuse | 36 VDC Z-motor |
| 3.1F02 | 3AT | 326 series - 3AB SloBlo ceramic body 6.3x32 mm | Littlefuse | WS 24 V Logic |

10 Technical specification

10.1 Electrical Characteristics

| | |
|------------------------------|--|
| Mains voltage for the System | 400 V 3N, 50/60 Hz 400 V 3~ 480 V 3~ Long-time (positioning) 2 A 50/60 Hz. Momentary (exposure): 150 A, 50/60 Hz (Short term peak value), (recommended fuse 63 A, thermal breaker, B curve.) Class 1 |
| Heat dissipation | 1713 BTU/H |

| Generator Series and Mains Voltage | Generator Momentary Line Current | Apparent Mains Resistance | Recommended Minimum | | | |
|------------------------------------|----------------------------------|---------------------------|---|--------------------------|---------------------------------|----------------------|
| | | | Mains Disconnect to Generator (15 ft/5 m max) | Generator Service Rating | Distribution Transformer Rating | Ground Wire Size |
| 50 kW 400 VAC, 3p | 100 A | 0.17 Ω | 13.3 mm ² | 100 A | 65 kVa | 13.3 mm ² |
| 65 kW 400 VAC, 3p | 125 A | 0.13 Ω | | | 85 kVa | |
| 80 kW 400 VAC, 3p | 155 A | 0.10 Ω | | | 105 kVa | |
| 50 kW 480 VAC, 3p | 80 A | 0.24 Ω | | | 65 kVa | |
| 65 kW 480 VAC, 3p | 105 A | 0.19 Ω | | | 85 kVa | |
| 80 kW 480 VAC, 3p | 130A | 0.15 Ω | | | 105 kVa | |

Technical specification

Environmental Requirements

10.2 Environmental Requirements

| | |
|---|------------------------------------|
| Ambient transport and storage temperature | -25°C - +70°C |
| Ambient operating temperature | +10°C- +40°C |
| Transport and storage humidity (relative) | 10-90%, non-condensing |
| Operating humidity (relative) | 30-75% RH, non-condensing |
| Maximum transport and storage altitude | 3000 m |
| Maximum operating altitude | 3000 m |
| Maximum air pressure | 700–1060 hPa |
| Noise | 55dB or less (except single noise) |

10.3 Ceiling suspended X-ray tube support

10.3.1 General

| | |
|---------------------------------|---------|
| Rotation range ceiling (beta) | >340° |
| Rotation range tube arm (alpha) | >±135° |
| Column (Z stroke) | 1750 mm |

10.3.2 Configuration

| | |
|-----|--|
| OTC | The OTC is a mechanical part of an X-ray system. |
|-----|--|

10.3.3 Weight

| | |
|---|------------|
| Total weight Overhead tube crane (4x4m traverse and rail) including cabling | 372 kg |
| Overhead tube crane (including tube and collimator, ceiling wagon, column) | 165 kg |
| Traverse (X-ray assembly, 4 m) | 95 kg |
| Ceiling rail Y (4 m standard) | 28 kg/each |

10.3.4 Electrical Characteristics

| | |
|---------------|--|
| Mains voltage | 230 VAC, 50/60 Hz center tapped single phase 4 A |
|---------------|--|

10.3.5 Classification

Classification according to IEC 60601-1.

| | |
|-------------------------------------|--|
| Class | Class I equipment. All dead metal parts of the equipment are electrical connected to protective earth. |
| Applied part | Type B |
| Protection against ingress of water | IPXO |
| Mode of operation | Intermittent operation: 20%, maximum 1 min. ON / 4 min. OFF |
| Use of anaesthetic mixtures | The equipment is not suitable for use in the presence of flammable anaesthetic mixtures with air or with oxygen or with nitrous oxide. |

Technical specification

Ceiling suspended X-ray tube support

10.3.6 Speed

| | Low speed | Maximum speed |
|--|-----------|---------------|
| Z movement | 60 mm/s | |
| X movement | 250 mm/s | 500 mm/s |
| Y movement | 250 mm/s | 500 mm/s |
| α movement | 16°/s | |
| β movement | 16°/s | |
| Image receptor holder movement (with 50 kg mass) | 166 mm/s | 350 mm/s |

10.4 Cabinet

10.4.1 Dimensions

| | |
|---------------------------|---------------------|
| Dimensions (L x W x H) mm | 750 x 600 x 1125 mm |
|---------------------------|---------------------|

10.4.2 Weight

| | |
|---------|------------|
| Cabinet | Max 134 kg |
|---------|------------|

Technical specification

Table

10.5 Table

10.5.1 Column

| | |
|---|--------|
| Lowest table top position (from the floor to the table top surface) | 550 mm |
| Column (Z stroke) | 380 mm |

10.5.2 Table Top

| | |
|------------------------------------|------------------|
| Table top dimensions | 2424 mm x 850 mm |
| Table top transparent area | 2400 mm x 613 mm |
| Table top thickness | 21,5 mm |
| Length of stroke, X direction | ± 600 mm |
| Length of stroke, Y direction | ± 150 mm |
| Movement range of the imaging unit | >650 mm |
| Movement range of the detector | up to 850 mm |

10.5.3 Weight

| | |
|----------------------|----------------------|
| Table | Approximately 150 kg |
| Imaging unit | Approximately 21 kg |
| Table top | Approximately 47 kg |
| Maximum patient load | 300 kg |

10.5.4 Electrical Characteristics

| | |
|--|-------|
| Maximum power without external electronics | 500 W |
|--|-------|

10.5.5 Attenuation Equivalent

| | |
|-----------------|---------------------------|
| Table top | < 0.9 mm AL at 3.7 mm HVL |
| Detector holder | ≤ 0.6 mm AL at 3.7mm HVL |

10.6 Wall stand

| | |
|------------------|--------------|
| Column, Z stroke | 1580 +10/-10 |
|------------------|--------------|

| | |
|---|------------|
| Rotation range detector holder wagon (Only the tiltable detector holder wagon). | -20° - 90° |
|---|------------|

10.6.1 Attenuation equivalent

| | |
|-----------------|----------|
| Detector holder | ≤ 0.6 mm |
|-----------------|----------|

10.6.2 Weight

| | |
|------------|------------|
| Wall stand | 200 kg ±10 |
|------------|------------|

10.6.3 Speed

| | |
|------------|----------------------|
| | Maximum speed |
| Z movement | 200 mm/s |

Technical specification

Wall stand

11 Options

Refer to document *200219M01_2.1_Precision i5_Technical Data Sheet* for available system options.

Options

12 Accessories

12.1 General



WARNING!

Due to squeezing hazards from motorized movements, only accessories approved by the Manufacturer are allowed for the 0072.

| Part no. | Description |
|--------------|--|
| 0510-099-001 | Cable carriage (1 pc) |
| 0072-099-210 | External servo button incl. emergency stop |
| 0512-099-001 | Unistruts for rails 4x4m |
| 0512-099-002 | Unistruts for rails 4x5m |
| 0512-099-003 | Mounting kit, unistruts for rails 4x4m |
| 0512-099-004 | Mounting kit, unistruts for rails 4x5m |

12.1.1 Table

| Part no. | Description |
|--------------|--|
| 0072-095-170 | Patient kit incl.; |
| | - Compression belt cost effective |
| | - Patient handgrip (2 pcs) |
| | - Mattress |
| 0072-099-014 | Patient handgrip |
| 0055-099-001 | Mattress, Comfort |
| 0055-099-007 | Mattress, 2200 mm |
| 0055-099-009 | Hand control for automatic collimator (1 pc) |
| 0072-099-011 | Lateral cassette holder |
| 0072-099-004 | X, Y, Z Foot control |
| 0055-099-025 | X, Y Foot control strip type |
| 0072-099-028 | Compression belt cost effective |
| 0072-099-029 | Compression belt high-end |
| 0080-099-051 | Form pad small- rectangle |

Accessories

General

| Part no. | Description |
|--------------|------------------------|
| 0080-099-050 | Form pad medium- wedge |
| 0080-099-052 | Form pad large- head |

12.1.2 Wallstand

| Part.no. | Description |
|--------------|--------------------------------------|
| 0072-099-307 | Stitching; patient protection shield |
| | Stitching removable footstep |
| 0182-099-320 | Wall brackets WS |

12.1.3 Detector

| Part.no. | Description |
|-----------------------------------|----------------|
| CXDI-401C, wireless 43x43 compact | Canon detector |
| CXDI-402C, wireless 43x43 | Canon detector |
| CXDI-410C, wireless 43x43 | Canon detector |
| CXDI-701C, wireless 35x43 | Canon detector |
| CXDI-702C, wireless 35x43 | Canon detector |
| CXDI-710C, wireless 35x43 | Canon detector |
| CXDI-810C, wireless ~28x35 | Canon detector |

12.1.4 Grid

| Part.no. | Description |
|--------------|---|
| 0180-099-050 | Grid 40 lp/cm, 10:1 Ratio, F115, Al type |
| 0180-099-051 | Grid 40 lp/cm, 10:1 Ratio, F150, Al type |
| 0180-099-052 | Grid 40 lp/cm, 10:1 Ratio, F180, Al type |
| 0180-099-060 | Grid 52 lp/cm, 10:1 Ratio, F110, Al type |
| 0180-099-076 | Grid 52 lp/cm, 10:1 Ratio, F140, Al type |
| 0180-099-061 | Grid 52 lp/cm, 10:1 Ratio, F180, Al type |
| 0180-099-082 | Grid 52 lp/cm, 10:1 Ratio, F115, Carbon cover |
| 0180-099-083 | Grid 52 lp/cm, 10:1 Ratio, F180, Carbon cover |

13 Spare parts

Refer to Spare part catalogue documents 1000-095-052_x.y and 1000-095-072_x.y for the spare part list.

13.1 General

Note! _____

Contact the manufacturer for information about how to exchange spare parts.

Spare parts

General

14 Waste disposal

The manufacturing company is responsible for disposal of the product. To avoid environment pollution and human injury, we therefore request that you contact the manufacturer or your dealer if you wish to cease operation of your product with the intention of disposal.

For disposal of other components, refer to corresponding documentation.

Please follow the rules and regulations of your relevant authorities in the disposal of this product, accessories, options, consumables, media and their packing materials.

Waste disposal

15 Appendix A

15.1 Glossary

A

| | |
|-------------|--|
| Accessories | Extra facilities to the product which easily can be mounted by the user. |
| AEC | Automatic Exposure Control |
| Alpha | A direction for a rotation movement. |

B

| | |
|------------|---|
| Beta | A direction for a rotation movement. The tube turns around the Z-axis. |
| Btu/hr | British thermal unit/hour |
| BU/Back-up | A precautionary measure that shuts off the exposure, if the AEC chamber does not. |
| Bucky | See Detector holder. |

C

| | |
|-----------|--|
| CE | A CE-marked product verifies that the Manufacturer guarantees that the product fulfils the EU fundamental health, environment and security requirements. |
| Centering | The field of image is centered over the detector. |
| Collision | Either a physical collision with an obstacle or the node cannot reach its end position. |
| CR | Image plates. |

D

| | |
|-----------|--|
| DAP meter | Dose Area Product meter. The DAP-meter is placed next to the collimator and measures the amount of X-ray radiation that leaves the collimator. |
| Diode | Electrical component that leads voltage and current in one direction. |
| Dealer | See "Supplier". |
| Detector | Image receptor for X-ray that does not require a cassette. The reception and transfer of an image is digital. |

E

Appendix A

Glossary

| | |
|----------|--|
| EMC | Electromagnetic Compatibility. |
| End stop | See mechanical end stop and software end stop. |
| Exposure | An image is taken against an image receptor. |

F

G

| | |
|----------------|---|
| Guard function | Collision detection of the Z-movement (option). |
| Guard sensor | A sensor in the top of the Z-column that registers variations of force. |

H

I

| | |
|-----------------------|---|
| IEC | International Electrotechnical Commission. |
| Image receptor | Receptor for images; Film, CR, DR or Cassette. |
| Image receptor holder | Holder for the image receptor (Film, CR, DR or Cassette). |
| Index | Mechanical position markings, for instance alpha 0°, +90° and -90°. |
| Intermittence | The number of repetitions / unit of time. Recurrent cycles. |
| ISO | International Organization for Standardization. |

J

K

L

M

| | |
|---------------------|--|
| Mechanical end stop | A physical device that stops an automatic or manual movement if the software end stop is out of order. |
| Motorized movement | A motor assisted movement. |

N

| | |
|------|---|
| Node | A control and supervision unit, consists of printed circuit board and node specific software. |
|------|---|

O

| | |
|---------|--|
| O.D. | Optic Density. |
| Options | Extra facilities that demand updating of the System software and hardware before use. Options demand installation of an authorized service technician. |

P

| | |
|----------|---------------------------------------|
| Position | A location in the room (X, Y and Z). |
|----------|---------------------------------------|

Q

R

S

| | |
|-------------------|--|
| SID | Source to image distance. The distance between the focus spot in the X-ray tube and the active image receptor surface. FFD is also used. |
| Software end stop | A non-physical device that stops an automatic or manual movement. The software end stop is placed before the mechanical end stop. |
| SSW | Service software. |
| Supplier | The company that sells the System to the user (hospital). |

T

| | |
|-------------|--|
| Table frame | The metallic frame that carries the Table top. The frame is attached to the bottom of the Table top. |
|-------------|--|

U

V

W

| | |
|--------------|--|
| Working area | The size of the Table top including X- and Y-stroke. |
|--------------|--|

X

| | |
|------------|--------------------------------------|
| X-movement | The System moves in the X-direction. |
|------------|--------------------------------------|

Y

| | |
|------------|--------------------------------------|
| Y-movement | The System moves in the Y-direction. |
|------------|--------------------------------------|

Z

Appendix A

Glossary

| | |
|------------|--------------------------------------|
| Z-node | The Z-node controls the Z-movement. |
| Z-movement | The System moves in the Z-direction. |

16 Appendix B

16.1 Maintenance checklists

16.1.1 Annual maintenance checklist

Make a copy of this form before filling in.

If there is any discrepancy please use the table and make a note.

Hospital:.....

ID No:..... Room:.....

Sign:..... Date:.....

16.1.1.1 System

- ☐ 1. Measure the system protective earth.
- ☐ 2. Check the emergency stops.

16.1.1.2 OTC

- ☐ 1. Check the tightening of bolts fixing the Y-rails to the Unistrut rails. _____ (Nm)
- ☐ 2. Check the tightening of bolts fixing the X-rails distance plates (total 12 screws). _____ (Nm)
- ☐ 3. Clean the side position wheels and check for damage.
- ☐ 4. Check the tightening of screws for the X-ray tube turning plate. _____ (Nm)
- ☐ 5. Check the lifting cord for damage and make sure it runs smoothly.
- ☐ 6. Check the safety switch in the column.
- ☐ 7. Check the alignment of the X-ray and light field.
- ☐ 8. Check the alignment of the OTC.
- ☐ 9. Check the tube angulation.
- ☐ 10. Check the tightening of the four X-ray clamp screws. _____ (Nm)
- ☐ 11. Check the X-ray tube for oil leakage.
- ☐ 12. Check that there is no play between the collimator and the X-ray tube.

Appendix B

Maintenance checklists

- ☐ 13. Check the function of the column Z contactor.
- ☐ 14. Check the function of the manoeuvre handle buttons.
- ☐ 15. Check the function of the column Z brake.
- ☐ 16. Check the OTC column segments (full stroke).
- ☐ 17. Clean the wheel tracks.
- ☐ 18. Clean the wheels.
- ☐ 19. Check the fastening of the OTC wagon side position wheel. _____ (Nm)
- ☐ 20. Check the movement of the OTC to all positions in X-, Y- and Z-directions.

16.1.1.3 Two column table

- ☐ 1. Check the tightening of bolts fixing the table to the floor. _____ (Nm)
- ☐ 2. Check the function and clean the table top ball bearings.
- ☐ 3. Clean the table top profiles.
- ☐ 4. Clean the profiles for the image receptor tray and detector wagon wheels.
- ☐ 5. Check the cabling to the table top brakes.
- ☐ 6. Check the condition of the table top brake pads.
- ☐ 7. Check the X-Y function of the table top brakes. X: _____ (Nm)
Y: _____ (Nm)
- ☐ 8. Check the column segments on the table (full stroke).
- ☐ 9. Check the buttons on the foot control X/Y/Z.
- ☐ 10. Batteries in the wireless foot control (option).
- ☐ 11. Check the table guard function (option). _____ (Nm)

Appendix B

Maintenance checklists

16.1.1.4 Wall stand

- ☐ 1. Check the tightening of bolts fixing the wall stand to the floor. _____ (Nm)
- ☐ 2. Check the Z-chain attachment.
- ☐ 3. Check the Z movement.
- ☐ 4. Check the Z-mechanical end stops.
- ☐ 5. Check the function of the Z-brake. _____ (Nm)
- ☐ 6. Batteries in the wireless foot control (option).
- ☐ 7. Check the buttons on the foot control X/Y/Z.
- ☐ 8. Check the function of the detector tilt (option). _____ (Nm)

16.1.1.5 System part 2

- ☐ 1. Check the synchronization circuit.
- ☐ 2. Check the Z safety zone.
- ☐ 3. Check the positioning index of the OTC.
- ☐ 4. Check the table detector signals.
- ☐ 5. Check the wall stand detector signals.
- ☐ 6. Check the table SID.
- ☐ 7. Check the indication light and collimator light.
- ☐ 8. Check the function of the AEC chamber.
- ☐ 9. Verify the measured DAP value (Area dose:dGycm2).

Measured value: _____

Calculated value: _____

- ☐ 10. Clean all outer surfaces.
- ☐ 11. Disconnect the power plug and wipe off dust and dirt with a dry cloth.
- ☐ 12. Check all outer cables for damage.
- ☐ 13. Make sure that the Operation manual is present and up to date.

Appendix B

Maintenance checklists

16.1.1.6 Remark

| | Remark | Action | Internal note |
|-----|--------|--------|---------------|
| 1. | <hr/> | <hr/> | <hr/> |
| 2. | <hr/> | <hr/> | <hr/> |
| 3. | <hr/> | <hr/> | <hr/> |
| 4. | <hr/> | <hr/> | <hr/> |
| 5. | <hr/> | <hr/> | <hr/> |
| 6. | <hr/> | <hr/> | <hr/> |
| 7. | <hr/> | <hr/> | <hr/> |
| 8. | <hr/> | <hr/> | <hr/> |
| 9. | <hr/> | <hr/> | <hr/> |
| 10. | <hr/> | <hr/> | <hr/> |

17 Installation report

17.1 Attention

The installation report is an important form for Arcoma AB to receive feed-back from our dealers, in order to keep track of delivered systems and their current status. The report is required from all performed installations in order to comply with CFR 21 §1020.30.

The CE-mark to MDD Class II products is fulfilled through MDD ANNEX II 93/42/EEC where our Quality system is an essential part.

We kindly ask you to take the time needed to fulfil the report. The installation report form are delivered with each system (included in the Service and Installation Manual). There is also a digital form (this document) available which can be used.

Please send the fulfilled and signed report to service@arcoma.se. Sending the report confirms that you have installed the unit and that it is working properly on site.

If you encounter product related issues during the installation, it is important that we receive this information as input to our CAPA-process (Corrective and Preventive Action). For such reports please contact service@arcoma.se (+46 470 70 69 70).

Best regards, ARCOMA AB.

INFORMATION FROM THE DEALER

Product Identification

Equipment type: _____

System Serial number: _____

Date: _____

Dealer: _____

Installer: _____

Site Identification

Hospital/address: _____

Department: _____

Lab/room: _____

☐ I hereby confirm that the installation is performed in accordance with this Installation and service manual.

Signature of Installer

Date

Signature



CANON MEDICAL SYSTEMS USA, INC.